

Infortrend

External RAID Controller & Subsystem



Generic Operation Manual

Revision 1.62

Firmware Version: 3.31h



Asia Pacific**(International headquarter)****Infortrend Technology, Inc.**8F, No. 102 Chung-Shan Rd., Sec. 3
Chung-Ho City, Taipei Hsien, Taiwan**Tel:** (886)-2-2226-0126**Fax:** (886)-2-2226-0020

sales@infortrend.com.tw

support@infortrend.com.tw

www.infortrend.com.tw

Americas**Infortrend Corporation**3150 Coronado Drive, Unit C
Santa Clara, CA 95054, USA**Tel:** (408) 988-5088**Fax:** (408) 988-6288

sales@infortrend.com

support@infortrend.com

www.infortrend.com

China**Infortrend Technology, Limited**Room 1210, West Wing, Tower One,
Junefield Plaza, No. 6 Xuanwumen Street,
Xuanwu District, Beijing, China.

Post code: 100052

Tel: 8610-63106168**Fax:** 8610-63106188

sales@infortrend.com.cn

support@infortrend.com.cn

www.infortrend.com.cn

Europe (EMEA)**Infortrend Europe Limited**5 Elmwood, Crockford Lane
Chineham Business Park
Basingstoke, Hampshire
RG24 8WG, UK**Tel:** +44-1256-70-77-00**Fax:** +44-1256-70-78-89

sales@infortrend-europe.com

support@infortrend-europe.com

www.infortrend-europe.com

Copyright © 2003**This Edition First Published 2003**

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written consent of Infortrend Technology, Inc.

Disclaimer

Infortrend Technology makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Furthermore, Infortrend Technology reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation to notify any person of such revisions or changes. **Product specifications are also subject to change without notice.**

Trademarks

Infortrend and the Infortrend logo are registered trademarks and SentinelRAID, EonRAID, EonStor, RAIDWatch, and other names prefixed with "IFT" are trademarks of Infortrend Technology, Inc.

PowerPC is a registered trademark of International Business Machines Corporation and Motorola Inc.

DEC and Alpha are registered trademarks of Compaq Computer Corp. (formerly of Digital Equipment Corporation). Microsoft, Windows, Windows NT and MS-DOS are registered trademarks of Microsoft Corporation in the U.S. and other countries.

Novell and NetWare are registered trademarks of Novell, Inc. in the U.S. and other countries.

SCO, OpenServer, and UnixWare are trademarks or registered trademarks of The Santa Cruz Operation, Inc. in the U.S. and other countries.

Solaris is a trademark of SUN Microsystems, Inc.

UNIX is a registered trademark of The Open Group in the U.S. and other countries. All other names, brands, products or services are trademarks or registered trademarks of their respective companies.

RMA Policy

Please visit our websites

(www.infortrend.com/www.infortrend.com.tw/www.infortrend.com.cn/www.infortrend-europe.com) where our RMA policy is given a detailed explanation.

Supported Models

This manual supports the following Infortrend controllers/subsystems:

- SentinelRAID: SCSI-based external RAID controllers (including the 5.25" full-height and 1U canister configuration)
- EonRAID: Fibre-based external RAID controllers (including the 5.25" full-height and 1U canister controller head configurations)
- EonStor: subsystems that come with SCSI or Fibre host channels.
- IFT-6230 and 6330 series ATA RAID subsystems.

Printed in Taiwan

Table of Contents

Functional Table of Contents	xiii
---	-------------

Chapter 1 RAID Functions: An Introduction

1.1 Logical Drive.....	1
1.2 Logical Volume.....	1
What is a logical volume?.....	1
1.3 RAID Levels.....	2
What are the RAID levels?	2
NRAID.....	3
JBOD	3
RAID 0	4
RAID 1	4
RAID (0+1).....	4
RAID 3	5
RAID 5	5
1.4 Spare Drives	6
Global and Local Spare Drives	6
1.5 Identifying Drives	8
Flash Selected SCSI Drive	8
Flash All SCSI Drives	8
Flash All but Selected Drives.....	8
1.6 Rebuild	9
Automatic Rebuild and Manual Rebuild.....	9
1. Automatic Rebuild.....	9
2. Manual Rebuild.....	10
3. Concurrent Rebuild in RAID (0+1).....	11
1.7 Logical Volume (Multi-Level RAID).....	12
What is a logical volume?.....	12
Spare drives assigned to a logical volume?	14
Limitations:.....	15
Partitioning: partitioning the logical volume?	15
Different write policies within a logical volume?.....	16
RAID expansion with logical volume?.....	16
Different controller settings using logical volume?	16
A logical volume with logical drives of different levels?	17
Multi-level RAID systems.....	17

Chapter 2 RAID Planning

2.1 Considerations	1
2.2 Configuring the Array:	5
2.3 Operation Theory	7
2.3.1 I/O Channel, SCSI ID, and LUN	7
2.3.2 Grouping Drives into an Array	7
2.3.3 Making Arrays Available to Hosts	9
2.4 Tunable Parameters	10

Chapter 3 Accessing the Array through Serial Port and Ethernet

3.1	RS-232C Serial Port	1
3.1.1	Configuring RS-232C Connection via Front Panel	2
3.1.2	Starting RS-232C Terminal Emulation.....	3
3.2	Out-of-Band via Ethernet	4
	Method 1	4
	Method 2	5
	What Is the “Disk Reserved Space?”.....	6
	Other Concerns.....	6
	Web-Based Management.....	6
	Requirements.....	6
3.2.1	Connecting Ethernet Port:.....	7
3.2.2	Configuring the Controller	7
3.2.3	NPC Onboard	11
	The SNMP_TRAP section	12
	The EMAIL section.....	12
	The BROADCAST section.....	12

Chapter 4 LCD Screen Messages

4.1	The Initial Screen	1
4.2	Quick Installation Screen	1
4.3	Logical Drive Status	2
4.4	Logical Volume Status	3
4.5	SCSI Drive Status	4
4.6	SCSI Channel Status	5
4.7	Controller Voltage and Temperature	6
4.8	Cache Dirty Percentage	7
4.9	View and Edit Event Logs	7

Chapter 5 LCD Keypad Operation

5.1	Power on RAID Enclosure	1
5.2	Caching Parameters	1
	Optimization Modes	1
	Optimization Mode and Stripe Size.....	2
	Optimization for Random or Sequential I/O	3
	Write-Back/Write-Through Cache Enable/Disable	3
5.3	View Connected Drives:	5
5.4	Creating a Logical Drive	6
	Choosing a RAID Level:.....	6
	Choosing Member Drives:	6
	Logical Drive Preferences:.....	6
	Maximum Drive Capacity:	7
	Spare Drive Assignments:	7
	Disk Reserved Space:	7
	Write Policy:	7
	Initialization Mode:	8
	Stripe Size:.....	8
	Beginning Initialization.....	8
5.5	Creating a Logical Volume	10
	Initialization Mode	10
	Write Policy	10

	Logical Volume Assignment	11
5.6	Partitioning a Logical Drive/Logical Volume	12
5.7	Mapping a Logical Volume/Logical Drive to Host LUN	13
5.8	Assigning Spare Drive and Rebuild Settings	14
	Adding a Local Spare Drive	14
	Adding a Global Spare Drive	15
	Rebuild Settings.....	15
5.9	Viewing and Editing Logical Drives and Drive Members	16
	Deleting a Logical Drive	16
	Deleting a Partition of a Logical Drive.....	17
	Assigning a Name to a Logical Drive.....	18
	Rebuilding a Logical Drive	18
	Regenerating Logical Drive Parity	19
	Media Scan.....	20
	Write Policy.....	21
5.10	Viewing and Editing Host LUNs.....	22
	Viewing and Deleting LUN Mappings	22
	Pass-through SCSI Commands	22
5.11	Viewing and Editing SCSI Drives.....	23
	Scanning New SCSI Drive	23
	Identifying a Drive	24
	Deleting Spare Drive (Global / Local Spare Drive)	25
5.12	Viewing and Editing SCSI Channels	25
	Redefining Channel Mode	25
	Setting a SCSI Channel's ID - Host Channel.....	26
	Viewing IDs.....	26
	Adding a Channel ID.....	26
	Deleting a Channel ID.....	27
	Setting a SCSI Channel's Primary ID - Drive Channel	27
	Setting a SCSI Channel's Secondary ID - Drive Channel	28
	Setting Channel Bus Terminator	28
	Setting Transfer Speed.....	29
	Setting Transfer Width.....	30
	Viewing and Editing SCSI Target - Drive Channel	30
	Slot Number.....	31
	Maximum Synchronous Transfer Clock	31
	Maximum Transfer Width	31
	Parity Check	32
	Disconnecting Support.....	32
	Maximum Tag Count	32
	Restore to Default Setting.....	33
5.13	System Functions	34
	Mute Beeper	34
	Change Password	34
	Changing Password.....	35
	Disabling Password	35
	Reset Controller.....	35
	Shutdown Controller	36
	Controller Maintenance.....	36
	Saving NVRAM to Disks.....	36
	Restore NVRAM from Disks	37
	Adjust LCD Contrast.....	37
5.14	Controller Parameters.....	38
	Controller Name	38
	LCD Title Display Controller Name.....	38
	Password Validation Timeout	38

Controller Unique Identifier	38
Controller Date and Time.....	39
Time Zone.....	39
Date and Time	39
5.15 SCSI Drive Utilities	41
SCSI Drive Low-level Format.....	41
SCSI Drive Read/Write Test.....	42

Chapter 6 Terminal Screen Messages

6.1 The Initial Screen.....	1
6.2 Main Menu	2
6.3 Quick Installation.....	2
6.4 Logical Drive Status	4
6.5 Logical Volume Status	5
6.6 SCSI Drive Status	6
6.7 SCSI Channel's Status	7
6.8 Controller Voltage and Temperature	9
6.9 Viewing Event Logs on the Screen.....	10

Chapter 7 Terminal Operation

7.1 Power on RAID Enclosure	1
7.2 Caching Parameters	1
Optimization Modes	1
Optimization Mode and Stripe Size.....	3
Optimization for Random or Sequential I/O	3
Write-Back/Write-Through Cache Enable/Disable	3
7.3 Viewing the Connected Drives.....	4
7.4 Creating a Logical Drive.....	5
Choosing a RAID Level:.....	6
Choosing Member Drives:	6
Logical Drive Preferences:.....	6
Maximum Drive Capacity:	6
Assign Spare Drives:	7
Disk Reserved Space	7
Logical Drive Assignments:.....	7
Write Policy	7
Initialization Mode	8
Stripe Size.....	8
7.5 Creating a Logical Volume.....	10
7.6 Partitioning a Logical Drive/Logical Volume	11
7.7 Mapping a Logical Volume to Host LUNs	13
7.8 Assigning Spare Drive, Rebuild Settings.....	15
Adding Local Spare Drive	15
Adding a Global Spare Drive.....	16
7.9 Viewing and Editing Logical Drive and Drive Members	16
Deleting a Logical Drive	17
Deleting a Partition of a Logical Drive.....	17
Assigning a Name to a Logical Drive	17
Rebuilding a Logical Drive	18
Regenerating Logical Drive Parity.....	19
Media Scan	19
Write Policy	20

7.10	Viewing and Editing Host LUNs	21
	Viewing or Deleting LUN Mappings	21
	Edit Host-ID/WWN Name List	21
	Pass-through SCSI Commands	21
7.11	Viewing and Editing SCSI Drives	22
	Scanning New Drive	23
	Slot Number.....	23
	Drive Entry	23
	Identifying Drive	23
	Deleting Spare Drive (Global / Local Spare Drive)	24
7.12	Viewing and Editing SCSI Channels	25
	Redefining Channel Mode	25
	Viewing and Editing SCSI IDs - Host Channel	26
	Viewing and Editing SCSI IDs	26
	Adding a SCSI ID (Primary/Secondary Controller ID)	26
	Deleting an ID	27
	Setting a Primary Controller's SCSI ID - Drive Channel	27
	Setting a Secondary Controller's SCSI ID - Drive Channel	28
	Setting Channel Terminator.....	28
	Setting a Transfer Speed.....	28
	Drive Channel	28
	Setting the Transfer Width.....	29
	Viewing and Editing SCSI Target / Drive Channel.....	30
	Slot Number.....	30
	Maximum Synchronous Transfer Clock	31
	Maximum Transfer Width	31
	Parity Check	31
	Disconnecting Support.....	32
	Maximum Tag Count	32
	Data Rate.....	32
7.13	System Functions	34
	Mute Beeper	34
	Change Password	34
	Changing the Password.....	35
	Setting a New Password.....	35
	Disabling the Password	36
	Reset Controller.....	36
	Shutdown Controller	36
	Adjust LCD Contrast.....	37
7.14	Controller Parameters	38
	Controller Name	38
	LCD Title Display Controller Name.....	38
	Saving NVRAM to Disks	38
	Restore NVRAM from Disks.....	39
	Password Validation Timeout	40
	Controller Unique Identifier	40
	Set Controller Date and Time	42
	Time Zone	42
	Date and Time.....	42
7.15	Drive Information	43
	View Drive Information.....	43
	SCSI Drive Utilities	43
	SCSI Drive Low-level Format	44
	SCSI Drive Read/Write Test.....	45

Chapter 8 Fibre Operation

8.1	Overview	1
8.2	Major Concerns	2
8.3	Supported Features	4
	Fibre Chip.....	4
	Multiple Target IDs:.....	4
	Drive IDs:.....	5
	In-band Fibre and S.E.S. Support:.....	5
8.4	Configuration: Host and Drive Parameters	6
	Channel Mode:.....	6
	Primary and Secondary Controller IDs:.....	6
	Redundant Controller Cache Coherency Channel (RCC Channel):.....	7
	View Channel WWN.....	7
	View Device Port Name List (WWPN).....	8
	View and Edit Fibre Drive.....	8
	User-Assigned ID (Scan SCSI Drive).....	8
	View Drive Information.....	9
	View and Edit Host-Side Parameters.....	9
	1. Fibre Channel Connection Option:.....	10
	View and Edit Drive-Side Parameters.....	10
	2. Drive-Side Dual Loop:.....	10
	Controller Unique Identifier.....	11
	Controller Communications over Fibre Loops.....	12
8.5	Multi-Host Access Control: LUN Filtering	14
	Creating LUN Masks.....	15
	WWN Name List.....	16
	Logical Unit to Host LUN Mapping.....	16
	LUN Mask (ID Range) Configuration:.....	18
	Filter Type: Include or Exclude.....	19
	Access Mode: Read Only or Read/Write.....	19
	Sample Configuration:.....	20
	Configuration Procedure:.....	21

Chapter 9 Advanced Configurations

9.1	Fault Prevention	1
	S.M.A.R.T.	1
	9.1.1 Clone Failing Drive:.....	2
	Replace after Clone:.....	2
	Perpetual Clone:.....	3
	9.1.2 S.M.A.R.T. (Self-Monitoring, Analysis and Reporting Technology).....	5
	Configuration Procedure.....	7
	Enabling the S.M.A.R.T. Feature.....	7
	Examining Whether Your Drives Support S.M.A.R.T.	8
	Using S.M.A.R.T. Functions.....	9
9.2	Host-side and Drive-side SCSI Parameters	11
	9.2.1 Host-side SCSI Parameters.....	11
	Maximum Concurrent Host LUN Connection ("Nexus" in SCSI):.....	11
	Number of Tags Reserved for each Host-LUN Connection:.....	12
	Maximum Queued I/O Count:.....	13
	LUNs per Host SCSI ID.....	13
	LUN Applicability:.....	13
	Peripheral Device Type:.....	14
	In-band (SCSI or Fibre):.....	14

Peripheral Device Type Parameters for Various Operating Systems:.....	15
Cylinder/Head/Sector Mapping:.....	16
9.2.2 Drive-side Parameters:.....	18
SCSI Motor Spin-Up.....	18
SCSI Reset at Power-Up.....	19
Disk Access Delay Time.....	20
SCSI I/O Timeout.....	20
Maximum Tag Count (Tag Command Queuing).....	21
Detection of Drive Hot Swap Followed by Auto Rebuild.....	22
SAF-TE and S.E.S. Enclosure Monitoring.....	22
Periodic Drive Check Time.....	23
Idle Drive Failure Detection.....	23
Periodic Auto-Detect Failure Drive Swap Check Time.....	23
Auto-Assign Global Spare Drive.....	24
9.3 Monitoring and Safety Mechanisms.....	25
Dynamic Switch Write-Policy.....	25
View Peripheral Device Status.....	25
Controller Auto-Shutdown - Event Trigger Operations.....	26
9.4 Disk Array Parameters.....	27
Rebuild Priority.....	27
Verification on Writes.....	28
9.5 Controller Self-Monitoring.....	29
9.5.1 Changing Monitoring Thresholds.....	29

Chapter 10 Redundant Controller

10.1 Operation Theory.....	1
10.1.1 Considerations Related to Physical Connection.....	2
Using SCSI-Based Controllers.....	2
Using Fibre-Based Controllers.....	3
10.1.2 Grouping Hard Drives and LUN Mapping.....	4
Logical Drive, Logical Volume, and Logical Partitions.....	5
System Drive Mapping:.....	6
Primary and Secondary IDs.....	6
Mapping.....	7
10.1.3 Fault-Tolerance.....	8
What Is a Redundant Controller Configuration?.....	8
How does Failover and Failback Work?.....	9
A. Channel Bus.....	9
B. Controller Failover and Failback.....	11
Replacing a Failed Unit:.....	11
Firmware Synchronization.....	11
Rolling Firmware Upgrade.....	11
C. Active-to-Active Configuration:.....	12
D. Traffic Distribution.....	12
E. Controller Failure.....	13
Symptoms.....	13
Connection:.....	14
10.2 Preparing Controllers.....	15
10.2.1 Requirements:.....	15
Cabling Requirements:.....	15
Controller Settings: General Procedure.....	16
10.2.2 Limitations.....	17
10.2.3 Configurable Parameters.....	17
Primary or Secondary.....	17
Active-to-Active Configuration.....	18

Active-to-Standby Configuration	18
Cache Synchronization	18
Battery Support	18
10.3 Configuration	20
10.3.1 Setup Flowchart	21
10.3.2 Via Front Panel Keypad	21
Redundant Configuration Using Automatic Setting.....	21
Enable Redundant Controller	21
Autoconfig.....	22
Controller Unique ID.....	22
Redundant Configuration Using Manual Setting	22
1.Enable Redundant Controller	23
2.Controller Unique ID.....	23
Starting the Redundant Controllers.....	23
Creating Primary and Secondary ID	24
Drive Channel	24
Host Channel	24
Assigning a Logical Drive/Logical Volume to the Secondary Controller	25
Mapping a Logical Drive/Logical Volume to the Host LUNs	26
Front Panel View of Controller Failure	26
When and how is the failed controller replaced?	27
10.3.3 Via Terminal Emulation.....	28
Redundant Configuration Using Automatic Setting.....	28
Redundant Configuration Using Manual Setting	29
Creating Primary and Secondary ID	30
Assigning Logical Drives to the Secondary Controller	31
Mapping a Logical Drive/Logical Volume to the Host LUNs	32
Terminal Interface View of Controller Failure.....	33
What will happen when one of the controllers fails?	33
10.3.4 When and How Is the Failed Controller Replaced?	33
Forcing Controller Failover for Testing.....	35
RCC Status (Redundant Controller Communications Channel)	36
Secondary Controller RS-232	36
Remote Redundant Controller	36
Cache Synchronization on Write-Through	37

Chapter 11 Record of Settings

11.1 View and Edit Logical Drives.....	1
Logical Drive Information	1
Partition Information.....	2
11.2 View and Edit Logical Volumes.....	3
Logical Volume Information	3
Partition Information.....	3
11.3 View and Edit Host LUN's.....	4
LUN Mappings	4
Host-ID/WWN Name List.....	4
11.4 View and Edit SCSI Drives.....	6
11.5 View and Edit SCSI Channels.....	7
11.6 View and Edit Configuration Parameters.....	8
Communication Parameters	8
PPP Configuration.....	8
Caching Parameters	9
Host Side SCSI Parameters	9
Drive Side SCSI Parameters	9

Disk Array Parameters	10
Redundant Controller Parameters.....	10
Controller Parameters	10
11.7 View and Edit Peripheral Devices.....	11
Set Peripheral Device Entry.....	11
Define Peripheral Device Active Signal	11
View System Information.....	11
11.8 Save NVRAM to Disk, Restore from Disk.....	12
11.9 RAID Security: Password	12
RAID Security	12

Chapter 12 Array Expansion

12.1 Overview	1
Note on Expansion	2
12.2 Mode 1 Expansion:.....	4
Adding Drives to a Logical Drive.....	4
Add-Drive Procedure	4
12.3 Mode 2 Expansion:.....	7
Copy and Replace Drives with Drives of Larger Capacity	7
Copy and Replace Procedure.....	7
12.4 Making Use of the Added Capacity: Expand Logical Drive	9
12.5 Expand Logical Volume.....	11
12.6 Configuration Example: Volume Extension in Windows 2000®	12
Limitations When Using Windows 2000.....	12
Example:.....	12

Appendix A LCD Keypad Navigation Map

Appendix B Firmware Functionality Specifications

Basic RAID Management:	1
Advanced Features:.....	2
Caching Operation:	3
RAID Expansion:.....	4
Fibre Channel Support:.....	5
S.M.A.R.T. Support:	6
Redundant Controller:.....	6
Data Safety:	7
System Security:.....	8
Environment Management:	9
SAF-TE/S.E.S. support	9
User Interface:.....	10
RAIDWatch on-board.....	10
RS-232C Terminal	10
Remote Manageability:.....	10
JBOD-Specific:.....	11
Others:	11

Appendix C System Functions: Upgrading Firmware

Upgrading Firmware	1
--------------------------	---

New Features Supported with Firmware 3.21	1
Background RS-232C Firmware Download:	1
Redundant Controller Rolling Firmware Upgrade:	1
Redundant Controller Firmware Sync-version:	2
Upgrading Firmware Using In-band SCSI + RAIDWatch Manager	2
Establish the In-band SCSI connection in RAIDWatch Manager	2
Upgrade Both Boot Record and Firmware Binaries.....	3
Upgrade the Firmware Binary Only.....	4
Upgrading Firmware Using RS-232C Terminal Emulation.....	4
Establishing the connection for the RS-232C Terminal Emulation	5
Upgrading Both Boot Record and Firmware Binaries	5
Upgrading the Firmware Binary Only	6

Appendix D Event Messages

Appendix E Remote Administration Using Dial-Out Modem

E.1 Remote Terminal Emulation Using Modem	2
Hardware Connection	3
Setting Controller using the RS-232C Terminal Interface.....	3
Configuring the Modem Port.....	3
Modem Initialization Command.....	4
Modem Operating Modes	5
Initializing Modem	5
Baud rate, Data Routing and Enable Terminal Emulation	6
Connection from the Remote Terminal.....	6
Viewing Connection Status	7
Setting the Controller Using the Front Panel.....	7
Configure Modem Port.....	7
Modem Initialization Command.....	8
Modem Operating Modes	8
Initializing Modem	9
Baud Rate, Data Routing and Enable Terminal Emulation.....	9
Establish the Connection from the Remote Terminal	9
Verifying Modem Connection	9
E.2 Dial-out for Event Notifications.....	10
Dial-out to a Terminal or a Pager?	10
Setting Dial-out Function Through the Terminal Emulation	11
Dial-out Command.....	11
Auto Dial-out on Initialization.....	11
Dial-out Time out.....	12
Dial-out Retry Count.....	12
Dial-out Retry Interval	12
Dial-out on Event Condition	13
Setting Dial-out Function Through the Front Panel.....	13
Dial-out Command	14
Auto Dial-out on Initialization.....	14
Dial-out Timeout.....	14
Dial-out Retry Count.....	15
Dial-out Retry Interval	15
Dial-out on Event Condition	15

Functional Table of Contents

This functional table of contents helps you to quickly locate the descriptions of firmware functions.

Chapter 1	Functional Description	Page number
1.4.2	Identifying Drives	1-8
	Flash Selected SCSI Drive	1-8
	Flash All SCSI Drives	1-8
	Flash All but Selected Drives	1-8
1.4.3	Automatic rebuild and manual rebuild	1-9
	Automatic rebuild	1-9
	Manual rebuild	1-10
1.4.4	Concurrent Rebuild in RAID (0+1)	1-11

Chapter 3	Out-of-Band via Serial Port and Ethernet	Page number
	Communication Parameters: configuring RS-232 connection	3-1
	Configuring serial port via front panel	3-2
	Using RAIDWatch: Method 1	3-4
	Using RAIDWatch: Method 2	3-5
	Configuring Ethernet connection: reserved space and port IP	3-7
	NPC Onboard	3-11

Chapter 4	LCD Screen Messages	Page number
	View and Edit Event Logs	4-7

Chapter 5 / Chapter 7	Starting RAID via the LCD Panel/Terminal Emulation	Page number: LCD/ Terminal
	Starting RAID Configuration	
5.2/7.2	Caching Parameters	5-1/7-1
	Optimization mode and stripe size	5-2/7-3
	Optimization for sequential or random I/O	5-3/7-3
	Write-Back/Write-Through Cache Enable/Disable	5-3/7-3
5.3/7.3	Viewing Connected Drives	5-5/7-4
5.4/7.4	Creating a Logical Drive	5-6/7-5
	Choosing a RAID Level	5-6/7-6
	Choosing Member Drives	5-6/7-6
	Maximum Drive Capacity	5-7/7-6
	Spare Drive Assignments	5-7/7-7
	Logical Drive Assignments	7-7
	Disk Reserved Space	5-7/7-7
	Write Policy	5-7/7-7
Initialization Mode	5-8/7-8	

	Stripe Size	5-8/7-8
	Beginning initialization	5-8/
5.5/7.5	Creating a Logical Volume	5-10/7-10
	Initialization Mode	5-10/7-10
	Write Policy	5-10/7-10
	Logical Volume Assignment	5-11/7-10
5.6/7.6	Partitioning a Logical Drive/Logical Volume	5-12/7-11
5.7/7.7	Mapping a Logical Drive/Logical Volume to Host LUNs	5-13/7-13
5.8/7.8	Assigning Spare Drive, Rebuild Settings	5-14/7-15
	Adding a Local Spare Drive	5-14/7-15
	Adding Global Spare Drive	5-15/7-16
	(Logical Drive) Rebuild Settings	5-15
5.9/7.9	Viewing and Editing Logical Drives and Drive Members	5-16/7-16
	Deleting a Logical Drive	5-16/7-17
	Deleting a Partition of a Logical Drive	5-17/7-17
	Assigning a Logical Drive Name	5-18/7-17
	Rebuilding a Logical Drive	5-18/7-18
	Regenerating Logical Drive Parity	5-19/7-19
	Media Scan	5-20/7-19
5.10/7.10	Viewing and Editing Host LUNs	5-22/7-21
	Viewing and Deleting LUN Mappings	5-22/7-21
	Pass-through SCSI Commands	5-22/7-21
5.11/7.11	Viewing and Editing SCSI Drives	5-23/7-22
	Scanning a New SCSI Drive	5-23/7-23
	Identifying a Drive	5-24/7-23
	Deleting Spare Drive (Global/Local Spare Drive)	5-25/7-24
5.12/7.12	Viewing and Editing SCSI Channels	5-25/7-25
	Viewing and Re-defining Channel Mode	5-25/7-25
	Setting Channel ID/Host Channel	5-26/7-26
	Viewing channel ID	5-26/7-26
	Adding a Channel ID	5-26/7-26
	Deleting a Channel ID	5-27/7-27
	Setting a Channel's Primary ID/Drive Channel	5-27/7-27
	Setting a Channel's Secondary ID/Drive Channel	5-28/7-28
	Setting a SCSI Channel's Terminator	5-28/7-28
	Setting the Transfer Speed	5-29/7-28
	Setting the Transfer Width	5-30/7-29
	Viewing and Editing a SCSI Target/Drive Channel	5-30/7-30
	Slot Number	5-31/7-30
	Maximum Synchronous Transfer Clock	5-31/7-31
	Maximum Transfer Width	5-31/7-31
	Parity Check	5-32/7-31
	Disconnecting Support	5-32/7-32
Maximum Tag Count	5-32/7-32	
Restoring the Default Setting (SCSI Bus)	5-33	
Data Rate	7-32	
5.13/7.13	System Functions	5-34/7-34
	Mute Beeper	5-34/7-34
	Change Password	5-35/7-34
	Disabling the Password	5-35/7-36
	Reset Controller	5-35/7-36
	Shutdown Controller	5-36/7-36
	Saving Configuration Data	
	Saving NVRAM to Disks	5-36/7-38
	Restore NVRAM from Disks	5-37/7-39
	Adjust LCD contrast	5-37/7-37

5.14/7.14	Controller Parameters	5-38/7-38
	Controller Name	5-38/7-38
	LCD Title Display Controller Name	5-38/7-38
	Time Zone	5-39/7-41
	Date and Time	5-39/7-41
	Setting Password	
	Password Validation Timeout	5-38/7-40
	Controller Unique Identifier	5-38/7-40
5.15/7.15	SCSI Drive Utilities	5-41/7-43
	Low-level format	5-41/7-44
	Read/Write test	5-42/7-45

Chapter 8	Fibre Operation	Page number
8.5	Host and Drive Parameters	8-6
	View and Edit Fibre Channel	8-6
	Channel Mode	8-6
	Primary and Secondary Controller IDs	8-6
	RCC Communications Channel (for cache coherency)	8-7
	View Channel WWN	8-7
	View Device Port Name List (WWPN)	8-8
	View and Edit Fibre Drives	8-8
	User-Assigned ID (Scan Fibre Drive)	8-8
	View Drive Information	8-9
	View and Edit Host-side Parameters	8-9
	Fibre Connection Types	8-10
	View and Edit Drive-side Parameters	8-10
	Connecting Drives with Dual Loop	8-10
	Controller Unique Identifier	8-11
	Controller Communications over Fibre Loops	8-12
8.5	Multi-host Access Control: LUN Filtering	8-14
	Creating LUN Masks	8-15
	WWN Name List	8-16
	Logical Unit to Host LUN Mapping	8-16
	LUN Mask (ID Range) Configuration	8-18
	Filter Type: Include or Exclude	8-19
	Access Mode: Read Only or Read/Write	8-19
	Configuration Procedure	8-21

Chapter 9	Advanced Configurations	Page number
9.1	Fault Prevention	9-1
	Clone Failing Drive	9-2
	Replace after Clone	9-2
	Perpetual Clone	9-3
9.1.2	S.M.A.R.T. with enhanced features	9-5
	S.M.A.R.T. Features (Enabling S.M.A.R.T.)	9-7
	"Detect Only"	9-7
	"Detect, Perpetual Clone"	9-7
	"Detect, Clone + Replace"	9-8
9.2	Host-side & Drive-side SCSI Parameters	9-11
9.2.1	Host-side SCSI Parameters	9-11
	Number of Tags Reserved for each Host-LUN Connection	9-12
	Maximum Queued I/O Count	9-13

	LUNs per Host SCSI ID	9-13
	LUN Applicability	9-13
	Peripheral Device Type	9-14
	In-band SCSI/Fibre	9-14
	Peripheral Device Type for Various Operating Systems	9-15
	Peripheral Device Type Settings	9-15
	Cylinder/Head/Sector Mapping	9-16
9.2.2	Drive-side Parameters	9-18
	SCSI Motor Spin-up	9-18
	SCSI Reset at Power-up	9-19
	Disk Access Delay Time	9-20
	SCSI I/O Timeout	9-20
	Maximum Tag Count (Tag Command Queuing)	9-21
	Detection of Drive Hot Swap Followed by Auto Rebuild	9-22
	SAF-TE and S.E.S. Enclosure Monitoring	9-22
	Periodic Drive Check Time	9-22
	Idle Drive Failure Detection	9-23
	Periodic Auto-Detect Swap Check Time	9-23
	Auto-assign Global Spare Drive	9-24
9.3	Monitoring and Safety Mechanisms	9-25
	Dynamic Switch Write-Policy	9-25
	View Peripheral Device Status (enclosure modules)	9-25
	Controller Auto-Shutdown – Event Trigger Option	9-26
9.4	Logical Drive Integrity – Disk Array Parameters	9-27
	Rebuild Priority	9-27
	Verification on Writes	9-28
9.5	Controller Self-Monitoring	9-29
	Changing Monitoring Thresholds	9-29

Chapter 10	Redundant Controller Configuration	Page number: LCD/Terminal
10.3	Configuration	10-19
10.3.1	Via Front Panel Keypad	10-20
	Redundant Configuration Using Automatic Setting	10-21
	Redundant Configuration Using Manual Setting	10-22
	Starting the Redundant Controllers	10-23
	Creating Primary and Secondary IDs	10-24
	Assigning a Logical Drive/Logical Volume to the Secondary Controller	10-25
	Mapping a Logical Drive/Logical Volume to the Host LUNs	10-26
	Front Panel View of Controller Failure	10-26
	When and How is the Failed Controller Replaced	10-27
10.3.2	Via Terminal Emulation	10-28
	Redundant Configuration Using Automatic Setting	10-28
	Redundant Configuration Using Manual Setting	10-29
	Creating Primary and Secondary IDs	10-30
	Assigning a Logical Drive/Logical Volume to the Secondary Controller	10-31
	Mapping a Logical Drive/Logical Volume to the Host LUNs	10-32
	Terminal View of Controller Failure	10-33
10.3.3	When and How is the Failed Controller Replaced	10-34
	Forcing Controller Failure for Testing	10-35
	RCC status (RCC channels)	10-36
	Secondary Controller RS-232	10-36

	Remote Redundant Controller	10-36
	Cache Synchronization on Write-Through	10-37

Chapter 12	Array Expansion	Page number
12.1	RAID Expansion	12-1
12.2	Mode 1 Expansion: Adding Drive to a logical drive	12-4
12.3	Mode 2 Expansion: Copy & Replace Drive with drives of larger capacity	12-7
12.4	Expand Logical Drive (Making use of the added capacity)	12-9
12.5	Expand Logical Volume	12-11
12.6	Example: RAID Expansion in Windows 2000	12-12

Appendix C	Controller Maintenance	Page number:
	Upgrading Firmware	C-1
	New Features Supported with Firmware 3.21	C-1
	Background RS-232 Firmware Download	C-1
	Redundant Controller Rolling Firmware Download	C-1
	Redundant Controller Firmware Sync-version	C-2
	Upgrading Firmware Using In-band SCSI + RAIDWatch Manager	C-2
	Establish the In-band SCSI connection in RAIDWatch Manager	C-2
	Upgrade Both Boot Record and Firmware Binaries	C-3
	Upgrade the Firmware Binary Only	C-4
	Upgrading Firmware Using RS-232 Terminal Emulation	C-4
	Establishing the connection for the RS-232 Terminal Emulation	C-5
	Upgrading Both Boot Record and Firmware Binaries	C-5
	Upgrading the Firmware Binary Only	C-6

Appendix E	Remote Administration Using Dial-Out Modem	Page number:
	Configuring the modem port	C-3
	Modem initialization command	C-4
	Modem operation modes	C-5
	Initializing modem	C-5
	Baud rate, data routing, and enable terminal emulation	C-6
	Connection from the remote terminal	C-6
	Viewing connection status	C-7
	Dial-out for Event Notification	C-10
	Dial-out command	C-11
	Auto dial-out on initialization	C-11
	Dial-out timeout	C-12
	Dial-out retry count	C-12
	Dial-out retry interval	C-12
	Dial-out on event conditions	C-13

List of Tables

Chapter 1

Table 1 - 1 RAID Levels.....	1-2
------------------------------	-----

Chapter 2

Table 2 - 1 RAID Levels.....	2-4
Table 2 - 2 Controller Parameter Settings	2-10

Chapter 5

Table 5 - 1 RAID Levels, Optimization Modes, and Stripe Size	5-8
--	-----

Chapter 7

Table 7 - 1 RAID Levels, Optimization Modes, and Stripe Size	7-3
--	-----

Chapter 9

Table 9 - 1 Peripheral Device Type Parameters	9-16
Table 9 - 2 Peripheral Device Type Settings:	9-16
Table 9 - 3 Cylinder/Head/Sector Mapping under Sun Solaris	9-17

Chapter 10

Table 10 - 1 ID Mapping Status (Normal Operation)	10-10
Table 10 - 2 ID Mapping Status (Controller Failed)	10-10

List of Figures

Chapter 1

Figure 1 - 1 Logical Drive.....	1-1
Figure 1 - 2 NRAID	1-3
Figure 1 - 3 JBOD.....	1-3
Figure 1 - 4 RAID 0.....	1-4
Figure 1 - 5 RAID 1	1-4
Figure 1 - 6 RAID (0+1)	1-4
Figure 1 - 7 RAID 3.....	1-5
Figure 1 - 8 RAID 5.....	1-5
Figure 1 - 9 Local (Dedicated) Spare	1-6
Figure 1 - 10 Global Spare	1-6
Figure 1 - 11 Global Spare Rebuild	1-6
Figure 1 - 12 Mixing Local and Global Spares.....	1-7

Figure 1 - 13 Automatic Rebuild	1-9
Figure 1 - 14 Manual Rebuild.....	1-10
Figure 1 - 15 Logical Volume	1-12
Figure 1 - 16 Logical Drive Composed of 24 Drives	1-13
Figure 1 - 17 Logical Volume with 4 Logical Drives	1-13
Figure 1 - 18 Logical Volume with Drives on Different Channels.....	1-14

Chapter 2

Figure 2 - 1 Optimization Setting.....	2-3
Figure 2 - 2 Array Configuration Process.....	2-5
Figure 2 - 3 SCSI ID/LUNs.....	2-7
Figure 2 - 4 Connecting Drives	2-7
Figure 2 - 5 Physical locations of drive members	2-8
Figure 2 - 6 Partitions in Logical Configurations	2-8
Figure 2 - 7 Mapping Partitions to Host ID/LUNs.....	2-9
Figure 2 - 8 Mapping Partitions to LUNs under ID	2-9

Chapter 5

Figure 5 - 1 Drive Space Allocated to the Last Partition	5-17
--	------

Chapter 7

Figure 7 - 1 Drive Space Allocated to the Last Partition	7-17
--	------

Chapter 8

Figure 8 - 1 Storage Pool.....	8-14
Figure 8 - 2 Host-LUN Mapping	8-15
Figure 8 - 3 LUN Mask.....	8-15
Figure 8 - 4 LUN Filtering - Configuration Sample.....	8-20

Chapter 9

Figure 9 - 1 SCSI ID/LUNs.....	9-11
--------------------------------	------

Chapter 10

Figure 10 - 1 Dual-Controller Using SCSI-Based Controllers	10-2
Figure 10 - 2 Dual-Controller Configuration Using Fibre-Based Controllers.....	10-3
Figure 10 - 3 Grouping Hard Drives.....	10-5
Figure 10 - 4 Partitioning of Logical Units	10-6
Figure 10 - 5 Mapping System Drives (Mapping LUNs)	10-7
Figure 10 - 6 Mapping System Drives (IDs).....	10-8
Figure 10 - 7 Redundant Controller Channel Bus	10-9
Figure 10 - 8 Controller Failover	10-10
Figure 10 - 9 Traffic Distribution.....	10-12
Figure 10 - 10 Controller Failover	10-13

Chapter 12

Figure 12 - 1 Logical Drive Expansion	12-3
Figure 12 - 2 Expansion by Adding Drive.....	12-4
Figure 12 - 3 Expansion by Copy & Replace	12-7

Appendix E

Figure E - 1 Remote Terminal Emulation	E-2
Figure E - 2 Dial-Out for Event Notification	E-10

About This Manual

This manual provides all of the necessary information that a system administrator needs to configure and maintain one of Infortrend's external RAID controllers or subsystems. For hardware-related information, please refer to the *Hardware Manual* that came with your RAID controller. Also available is the *User's Manual* for the Java-based GUI RAID manager for remote and concurrent management of RAID systems.

The order of the chapters is arranged in accordance with the steps necessary for creating a RAID.

The terminal screen displays as well as the LCD messages may vary when using controllers running different firmware versions.

Chapter 1	introduces basic RAID concepts and configurations, including RAID levels, logical drives, spare drives, and the use of logical volumes. It is recommended that users unfamiliar with RAID technologies should read this chapter before creating a configuration.
Chapter 2	tells the user how to begin with a RAID. At the beginning of this chapter, we raise some basic questions of which the user should know the answers prior to creating a RAID.
Chapter 3	teaches the user how to configure the RS-232C terminal emulation interface and the connection through a LAN port.
Chapter 4	helps the user to understand screen messages on the LCD display.
Chapter 5	gives step-by-step instructions on creating a RAID using the LCD keypad panel.
Chapter 6	teaches the user how to interpret the information found on the RS-232 terminal emulation.
Chapter 7	gives step-by-step instructions on how to create a RAID via the RS-232 session.
Chapter 8	includes all the Fibre channel-specific functions implemented since the firmware release 3.12.
Chapter 9	provides the advanced options for RAID configuration. Some of the new functions from firmware release 3.11 and above are given the detailed explanations in this chapter.
Chapter 10	addresses the concerns regarding the redundant controller configuration and the configuration process.
Chapter 11	provides the recording forms with which a system administrator can make a record of his configuration.

Chapter 12	shows how to expand a configured array or logical volume.
Appendix A	outlines the menu structure of the LCD front panel operation.
Appendix B	lists the important firmware features supported with the firmware version, arranged in accordance with the latest firmware version as of press date.
Appendix C	teaches the user how to upgrade firmware and boot record.
Appendix D	lists all of the controller event messages.
Appendix E	details the use of Modem dial-out functionality

Firmware Version & Other Information

Firmware version: 3.31h and above

Part number for this manual: M0000U0G16

Date: 7/30/03

Revision History:

- Version 1.0:
 - initial release
- Version 1.1:
 - added redundant controller configuration
- Version 1.2:
 - Added host-side and drive-side SCSI parameters
 - added S.M.A.R.T. with implemented Fault-Prevention methods.
 - added system functions
 - added Fault-bus configuration to be compatible with 3101 and 3102 series
 - added Host-side interface installation details
 - added Event Messages for error message identification
 - added all advanced functions available since 2.23K and 3.11F upward
 - added a functional table of content for quick searching functions
 - moved SCSI/Fibre Cable Specifications to Hardware Manual
- Version 1.3:
 - added Chapter 8 "Fibre Operation" for the new functions available since firmware release 3.12.
- Version 1.4:
 - added firmware features available with firmware revisions 3.14, 3.15, and 3.21
 - revised details about redundant controllers, host LUN mapping, etc.
 - modified string definitions in Chapter 14 "In-band SCSI Drives and Utilities" section
 - corrected descriptions of "Controller Unique Identifier"
 - added the configuration process for out-of-band configuration via LAN port
- Version 1.5:
 - removed Chapter 14
 - revised the descriptions for some functional items
 - added firmware features available from revision 3.25


- Version 1.61:
- added features available by revision 3.31
 - removed Appendix E
 - moved array expansion to Chapter 12
 - added variable stripe size, write policy per array
 - added media scan
 - added controller immediate array availability, time zone, date and time setting
 - added IO channel diagnostics
 - added controller Auto-Shutdown and cache-flush mechanisms
 - added system monitoring via enclosure modules
 - added disabling cache coherency using write-through mode
 - added descriptions about new firmware utility items
 - added details about enabling RAIDWatch and its sub-modules via Ethernet port
- Version 1.62:
- added functions previously included in controller Hardware Manual
 - added remote redundant
 - updated firmware event messages
 - updated LCD panel navigation map
 - added Appendix E - Dial-Out Modem

RAID Functions: An Introduction

Redundant Arrays of Independent Disks, or RAID, offers the following advantages: Availability, Capacity, and Performance. Choosing the right RAID level and drive failure management can increase Capacity and Performance, subsequently increasing Availability. Infortrend's external RAID controllers provide complete RAID functionality and enhanced drive failure management.

1.1 Logical Drive

Figure 1 - 1 Logical Drive



Logical Drive

The advantages mentioned above are achieved by creating “logical drives.” A logical drive is an array of independent physical drives. The logical drive appears to the host as a contiguous volume, the same as a local hard disk drive does.

The following section describes the different methods to create logical arrays of disk drives, such as spanning, mirroring and data parity. These methods are referred to as “RAID levels.”

1.2 Logical Volume

What is a logical volume?

The concept of a logical volume is very similar to that of a logical drive. A logical volume is the combination of one or several logical drives. These logical drives are combined into a larger capacity using the RAID 0 method (striping). When data is written to a logical volume, it is first broken into data segments and then striped across different logical drives in a logical volume. Each logical drive

then distributes data segments to its member drives according to the specific RAID level it is composed of.

The member logical drives can be composed of the same RAID level or each of a different RAID level. A logical volume can be divided into a maximum of 64 partitions. During operation, the host sees a non-partitioned logical volume or a partition of a logical volume as one single physical drive.

1.3 RAID Levels

RAID stands for Redundant Array of Independent Disks. Using a RAID storage subsystem has the following advantages:

- Provides disk spanning by weaving all connected drives into one single volume.
- Increases disk access speed by breaking data into several blocks when reading/writing to several drives in parallel. With RAID, storage speed increases as more drives are added as the channel bus allows.
- Provides fault-tolerance by mirroring or parity operation.

What are the RAID levels?

Table 1 - 1 RAID Levels

RAID Level	Description	Capacity	Data Availability
NRAID	Non-RAID	N	
RAID 0	Disk Striping	N	==NRAID
RAID 1 (0+1)	Mirroring Plus Striping (if N>1)	N/2	>>NRAID ==RAID 5
RAID 3	Striping with Parity on dedicated disk	N-1	>>NRAID ==RAID 5
RAID 5	Striping with interspersed parity	N-1	>>NRAID ==RAID 5
RAID 10 (Logical Volume)	Striping with RAID 1 logical drives	/	>>NRAID >>RAID 5
RAID 30 (Logical Volume)	Striping with RAID 3 logical drives	/	>>NRAID >>RAID 5
RAID 50 (Logical Volume)	Striping with RAID 5 logical drives	/	>>NRAID >>RAID 5

NOTE: Drives on different channels can be included in a logical drive and logical drives of different RAID levels can be used to


compose a logical volume. There are more combinations than RAID 10, 30, and 50.

RAID Level	Performance Sequential	Performance Random
NRAID	Drive	Drive
RAID 0	R: Highest W: Highest	R: High W: Highest
RAID 1 (0+1)	R: High W: Medium	R: Medium W: Low
RAID 3	R: High W: Medium	R: Medium W: Low
RAID 5	R: High W: Medium	R: High W: Low

NRAID

Disk Spanning

Figure 1 - 2 NRAID




NRAID	
Minimum Disks required	1
Capacity	N
Redundancy	No

NRAID stands for Non-RAID. The capacity of all drives is combined to become one logical drive (no block striping). In other words, the capacity of the logical drive is the total capacity of the physical member drives. NRAID does not provide data redundancy.

JBOD

Single Drive Control

Figure 1 - 3 JBOD




JBOD	
Minimum Disks required	1
Capacity	1
Redundancy	No

JBOD stands for Just a Bunch of Drives. The controller treats each drive as a stand-alone disk, therefore each drive is an independent logical drive. JBOD does not provide data redundancy.

RAID 0

Disk Striping

Figure 1 - 4 RAID 0




RAID 0	
Minimum Disks required	2
Capacity	N
Redundancy	No

RAID 0 provides the highest performance but no redundancy. Data in the logical drive is striped (distributed) across several physical drives.

RAID 1

Disk Mirroring

Figure 1 - 5 RAID 1




RAID 1	
Disks required	2
Capacity	N/2
Redundancy	Yes

RAID 1 mirrors the data stored in one hard drive to another. RAID 1 can only be performed with two hard drives. If there are more than two hard drives, RAID (0+1) will be automatically applied.

RAID (0+1)

Disk Striping with Mirroring

Figure 1 - 6 RAID (0+1)



RAID (0+1)	
Minimum Disks required	4
Capacity	N/2
Redundancy	Yes

RAID (0+1) combines RAID 0 and RAID 1 - Mirroring and Striping. RAID (0+1) allows multiple drive failure because of the full redundancy of the hard drives. If there are more than two hard drives assigned to perform RAID 1, RAID (0+1) will be automatically applied.


IMPORTANT!

- “RAID (0+1)” will not appear in the list of RAID levels supported by the controller. If you wish to perform RAID 1, the controller will determine whether to perform RAID 1 or RAID (0+1). This will depend on the number of drives that has been selected for the logical drive.

RAID 3

Disk Striping with Dedicated Parity Disk

Figure 1 - 7 RAID 3




RAID 3	
Minimum Disks required	3
Capacity	N-1
Redundancy	Yes

RAID 3 performs Block Striping with Dedicated Parity. One drive member is dedicated to storing the parity data. When a drive member fails, the controller can recover/regenerate the lost data of the failed drive by comparing and re-calculating data on the remaining drives.

RAID 5

Striping with Interspersed Parity

Figure 1 - 8 RAID 5



RAID 5	
Minimum Disks required	3
Capacity	N-1
Redundancy	Yes


RAID 5 is similar to RAID 3 but the parity data is not stored in a dedicated hard drive. Parity information is interspersed across the drive array. In the event of a drive failure, the controller can recover/regenerate the lost data of the failed drive by comparing and re-calculating data on the remaining drives.

RAID 30 and **RAID 50** are implemented as logical volumes, please refer to the preceding discussions for details.

1.4 Spare Drives


Global and Local Spare Drives

Figure 1 - 9 Local (Dedicated) Spare



Local Spare Drive is a standby drive assigned to serve one specified logical drive. When a member drive of this specified logical drive fails, the Local Spare Drive becomes a member drive and automatically starts to rebuild.


Figure 1 - 10 Global Spare



Global Spare Drive not only serves one specified logical drive. When a member drive from any of the logical drives fails, the Global Spare Drive will join that logical drive and automatically starts to rebuild.

Global Spare Drives serve any logical drive.

Figure 1 - 11 Global Spare Rebuild




The example on the left provides both Local Spare Drive and Global Spare Drive functions. On certain occasions, applying these two functions together will better fit various needs. Take note though that the **Local Spare Drive** always has higher priority than the **Global Spare Drive**.

When a member drive from any logical drive fails, the Global Spare Drive joins that logical drive and automatically starts to rebuild.

In the example shown below, the members of Logical Drive 0 are 9 GB drives, and the members in Logical Drives 1 and 2 are 4 GB drives.

Figure 1 - 12 Mixing Local and Global Spares



It is not possible for the 4 GB Global Spare Drive to join Logical Drive 0 because of its insufficient capacity. However, using a 9GB drive as the Global Spare drive for a failed drive that comes from Logical Drive 1 or 2 will bring huge amount of excess capacity since these logical drives require 4 GB only. In the diagram below, the 9 GB Local Spare Drive will aid Logical Drive 0 once a drive in this logical drive fails. If the failed drive is in Logical Drive 1 or 2, the 4 GB Global Spare drive will immediately give aid to the failed drive.


A Local Spare always has higher priority than a Global Spare.

1.5 Identifying Drives

Assuming there is a failed drive in the RAID 5 logical drive, make it a point to replace the failed drive with a new, healthy drive to keep the logical drive working.

If, when trying to remove a failed drive you mistakenly remove the wrong drive, you will no longer be able to access the logical drive because you have inadequately failed another drive.

To prevent this from happening, the controller provides an easy way to identify the faulty drive. By forcing certain drive LEDs to light for a configurable period of time, the faulty drive can be identified, and thus reducing the chance of removing the wrong drive. This function can be especially helpful in an installation site operating with hundreds of drives.





Flash Selected SCSI Drive

The Read/Write LED of the drive you selected will light steadily for a configurable period of time, from 1 to 999 seconds.

Flash All SCSI Drives

The Read/Write LEDs of all connected drives will light for a configurable period of time. If the LED of the defective drive did not light on the “Flash Selected SCSI Drive” function, use “Flash All SCSI Drives” to verify the fault. If the “Flash All SCSI Drives” function is executed, and the defective drive’s LED still does not respond, it can be a drive tray problem or the drive is dead.



Flash All but Selected Drives

Except the selected drive, the Read/Write LEDs of all connected drives will light for a configurable period of time ranging from 1 to 999 seconds. If an administrator can not be sure of the exact location of specific drive, this function will help to indicate where it is. This can prevent removal of the wrong drive when a drive fails and is about to be replaced.


The drive identifying function can be selected from “Main Menu”/”View and Edit SCSI Drives”/”Identify SCSI Drives.”

1.6 Rebuild

Automatic Rebuild and Manual Rebuild

1. Automatic Rebuild

Figure 1 - 13 Automatic Rebuild



Rebuild with Spare: When a member drive in a logical drive fails, the controller will first examine whether there is a Local Spare Drive assigned to this logical drive. If yes, rebuild is automatically started.

If there is no Local Spare available, the controller will search for a Global Spare. If there is a Global Spare, rebuild automatically begins using the Global Spare.

Failed Drive Swap Detect: If neither Local Spare Drive nor Global Spare Drive is available, and the "**Periodic Auto-Detect Failure Drive Swap Check Time**" is "Disabled," the controller will not attempt to rebuild unless the user applies a forced-manual rebuild.

When the "**Periodic Auto-Detect Failure Drive Swap Check Time**" is "Enabled" (i.e., a check time interval has been selected), the controller will detect whether a faulty drive has been swapped (by checking the failed drive's channel/ID). Once the failed drive has been replaced by a healthy drive, the rebuild will begin immediately.

If the failed drive is not swapped but a local spare is added to the logical drive, rebuild will begin with the spare.


If the S.M.A.R.T. function is enabled on drives and the reaction scheme is selected for securing data on a failing drive, spare will also be used for restoring data. Please refer to Chapter 9, Advanced Functions, for more details.

2. Manual Rebuild

When a user applies forced-manual rebuild, the controller will first examine whether there is any Local Spare assigned to the logical drive. If yes, it will automatically start to rebuild.

If there is no Local Spare available, the controller will search for a Global Spare. If there is a Global Spare, logical drive rebuild will be automatically conducted.

Figure 1 - 14 Manual Rebuild



If none of the spares are available, the controller will examine the SCSI channel and ID of the failed drive. Once the failed drive has been replaced by a healthy one, it starts to rebuild using the new drive. If there is no available drive for rebuilding, the controller will not attempt to rebuild until the user applies another forced-manual rebuild.


3. Concurrent Rebuild in RAID (0+1)

RAID (0+1) allows multiple drive failures and rebuild to be concurrently conducted on more than one of its members. Drives newly swapped must be scanned and set as Local Spares. These drives will be used for rebuild at the same time (you do not need to repeat the rebuild process for each member drive).

1.7 Logical Volume (Multi-Level RAID)

What is a logical volume?

Figure 1 - 15 Logical Volume




A logical volume is a combination of RAID 0 (Striping) and other RAID levels. Data written to a logical volume is first broken into smaller data segments and striped across different logical drives in a logical volume. Each logical drive then distributes data segments to its member drives according to its mirroring, parity, or striping scheme. A logical volume can be divided into a maximum of eight partitions. During normal operation, the host sees a non-partitioned logical volume or a partition of a partitioned logical volume as one single physical drive.

The benefits of using a logical volume have been achieved by:

1. Extending the MTBF (mean time between failure) by using more redundancy drives (spare drives).
2. Decreasing the time to rebuild and reducing the chance of data loss by simultaneous drive failures because drives are included in different drive groups using a multi-level logical structure.
3. Avoiding the chance of data loss by channel bus failure with flexible drive deployment.

As diagramed below, numerous drives can be included in a logical drive, and one of them is used for redundancy. By grouping these drives into several logical drives, and then into a logical volume, chance of failing two drives in a logical unit is greatly reduced. Each logical drive can have one or more local spares. A failed drive can be immediately replaced by a local spare, reducing the risk of losing data if another should fail soon afterwards.


Figure 1 - 16 Logical Drive Composed of 24 Drives



Configuration A - One logical drive with all 24 drives

As illustrated above, Configuration A is a RAID 5 logical drive consisting of 24 physical drives. Configuration B is a logical volume made of four RAID 5 logical drives.

Figure 1 - 17 Logical Volume with 4 Logical Drives



Configuration B - One logical volume with 4 logical drives

Configuration B can help to reduce the chance of encountering points of failure:

a) Higher Redundancy: Configuration A has one dedicated spare, while Configuration B allows the configuration of four spares. In Configuration B, the risk of simultaneous drive failure in a logical drive is significantly reduced than in Configuration A. The total array capacity is comparatively smaller by the use of spares.


b) Less Rebuild Time: The time during rebuild is a time of hazard. For example, a RAID 5 logical drive can only withstand single drive failure, if another drive fails during the rebuild process, data will be lost. The time span for rebuilding a faulty drive should be

minimized to reduce the possibility of having two drives to fail at the same time.

Configuration A is a large logical drive and takes a long time to rebuild. All members will be involved during the rebuild process. In Configuration B, the time span is shorter because only 6 members will participate when rebuilding any of the logical drives.

c) Channel Failure Protection: Channel failure may sometimes result from absurd matters like a cable failure. A channel failure will cause multiple drives to fail at the same time and inevitably lead to a fatal failure. Using a logical volume with drives coming from different drive channels can get around this point of failure.

Figure 1 - 18 Logical Volume with Drives on Different Channels



As illustrated above, should one of the drive channels fail, each logical drive loses one of its members. Logical drives still have the chance to rebuild its members. Data remains intact and the rebuild can be performed after the failed channel is recovered. No access interruptions to the logical volume will be experienced from the host side.

Spare drives assigned to a logical volume?

A Local Spare can not be assigned to a Logical Volume. If a drive fails, it fails as a member of a logical drive; therefore, the controller allows Local Spare's assignment to logical drives rather than logical volumes.

Limitations:

The logical volume can not have any logical drive stated as "fatal failed." If there is any failed drive in any of its member logical drives, controller will start to rebuild that logical drive. Should any of the member logical drives fail fatally, the logical volume fails fatally and data will not be accessible.

To avoid a logical volume failure:

- 1.** Logical drives as members to a logical volume should be configured in RAID levels that provide redundancy - RAID levels 1 (0+1), 3, or 5.
- 2.** Rebuild the logical drive as soon as possible whenever a drive failure occurs. Use of local spares is recommended.
- 3.** A logical drive should be composed of physical drives from different drive channels. Compose the logical drive with drives from different drive channels to avoid the fatal loss of data caused by bus failure.

Partitioning - partitioning the logical drive or partitioning the logical volume?

Once a logical drive has been divided into partitions, the logical drive can no longer be used as a member of a logical volume. The members of a logical volume should have one partition only with the entire capacity.

If you want to use a partitioned logical drive for a logical volume, delete the other partitions in this logical drive until there remains one partition only with the entire capacity. Mind that deleting the partition of the logical drive will also destroy all data. Data should be backed up before making partition configuration.

When a logical drive is used as a member to a logical volume, this logical drive can no longer be partitioned in "View and Edit Logical Drives." Instead, the Logical Volume can be partitioned into 8 in "View and Edit Logical Volume."

The procedure for partitioning a logical volume is the same as that for partitioning a logical drive. After the logical volume has been partitioned, map each partition to a host ID/LUN to make the partitions available as individual drives.

As members of a logical volume, all logical drives will be forced to adopt a consistent write policy. Whenever the write policy of a logical volume is changed, for example, the corresponding setting in its members will also be changed.

RAID expansion with logical volume?

The Logical Volume can also be expanded using the RAID expansion function. The concept of expanding a logical volume is similar to that of expanding a logical drive. To perform RAID expansion on a logical drive, replace each member physical drive with a drive of larger capacity or add a new drive, then perform logical drive expansion to utilize the newly-added capacity. For information about RAID expansion, please refer to Chapter 9 "Advanced Configurations."

To perform RAID expansion on a logical volume, expand each member logical drive, then perform "RAID Expansion" on the logical volume.

Steps to expand a Logical Volume:

1. Expand each member logical drive.
2. Expand the logical volume.
3. Map the newly-added capacity (in the form of a new partition) to a host LUN.

IMPORTANT!

- *If a logical unit has already been partitioned, and you wish to expand its capacity, the added capacity will be appended to the last partition. You will not be able to proceed with expansion using firmware version earlier than 3.27 when the unit already has 8 partitions.*
 - *Unless you move your data and merge two of the partitions, you will be not allowed to expand your logical volume. This is a precautionary limitation on logical unit expansion.*
-

Different controller settings using logical volume?

Redundant Controller:

Without logical volume - logical drives can be assigned to the primary or the secondary controller. The host I/Os directed to a logical drive will be managed by the controller which owns the

logical drive. If a controller fails, the host I/Os originally assigned to the failed controller will be taken over by the existing controller. When the controller fails back (failed controller being replaced by a new one), logical drives will be returned to the replacement controller in its original configuration.

With logical volume - logical volumes can also be assigned to different controllers. The only difference is logical volumes will be used as base units when shifting control during controller failure.

A logical volume with logical drives of different levels?

Multi-level RAID systems

- 1. RAID (0+1)** - this is a standard feature of Infortrend RAID controllers. It brings the benefits of RAID 1 (high availability) and RAID 0 (enhanced I/O performance through striping). Simply choose multiple drives (more than two) to compose a RAID 1 logical drive, RAID (0+1) will be automatically implemented.
- 2. RAID (3+0)** - a logical volume is a multi-level RAID implementation. A logical volume is a logical composition which stripes data across several logical drives (the RAID 0 method). A logical volume with several RAID 3 members can be considered as a RAID (3+0), or RAID 53 as defined in "The *RAID* Book" (from The RAID Advisory Board).
- 3. RAID (5+0)** - a logical volume with several RAID 5 members.

RAID Planning

This chapter summarizes the RAID configuration procedures and provides some useful tools for first-time configuration:

- | | |
|---------------------------|--|
| 2.1 Considerations | things you should know before setting up the array |
| 2.2 Configuring the Array | the basic configuration procedure |
| 2.3 Operation Theory | a brief introduction to data bus and system drive mapping |
| 2.4 Tunable Parameters | a useful tool that helps you to have a glimpse of important parameters |

2.1 Considerations

After you understand the basic ideas behind RAID levels, you may still be wondering how to begin. Here are the answers to some questions that may help you through the decision making.

1. How many physical drives do you have?

When initially creating the drive groups, you should know how many drives you have in your RAID system or in the JBOD attached to the RAID controlling unit.

2. How many drives on each drive channel?

The optimal system planning is always a compromise between pros and cons. As a general rule, the number of drives you should connect on each channel equals the data bus bandwidth divided by the maximum transfer rate you can get from each of your hard drives. Knowing the mechanical performance of your hard drives can help to determine how many drives to be connected over a drive channel.

Always use fast and large drives of the same capacity for your disk array. A logical drive composed of an adequate number of

larger drives can be more efficient than that of many but smaller drives.

3. How many drives would you like to appear to the host computer?

It must be decided what capacity will be included in a logical configuration of drives, be it a logical drive or a logical volume. A logical configuration of drives will appear to the host as a single capacity volume.

You may compose a large logical volume consisting of drives on different drive channels, and have it partitioned into smaller partitions. Each partition will appear as an independent capacity volume. In a performance-oriented configuration, you may configure the same number of drives into several RAID 0 logical drives just to get the most out of the array performance.

4. What kind of host application?

The frequency of read/write activities can vary from one host application to another. The application can be a SQL server, Oracle server, Informix, or other data base server of a transaction-based nature. Applications like video playback and video post-production editing require read/write activities of larger files coming in a sequential order.

Choose an appropriate RAID level for what is the most important for a given application – capacity, availability, or performance. Before creating your RAID, you need to choose an optimization scheme and optimize each array/controller for your application. Stripe size and write policy can be adjusted on a per logical drive basis.

5. Dual loop, hub, or switch?

Unpredictable situations like a cable coming loose can cause system down time. Fibre channel dual loop or redundant data paths using flexible LUN mapping method can guarantee there is no single point of failure. The use of Fibre channel hub or switch makes cabling and topology more flexible. Change the channel mode, connection type, and other associated settings to adjust the controller to your demands.

6. Optimization Mode

Figure 2 - 1 Optimization Setting



You should select an optimization scheme best suited to your applications before configuring a RAID array. Once the optimization mode is selected, it will be applied to all arrays in the system.

Two options are available: Sequential I/Os and Random I/Os. You may refer to the “Caching Parameters” section in Chapter 5 and Chapter 7 for the stripe size variables and its relations with RAID levels.

Numerous controller parameters are tuned for each optimization mode. Although stripe size can be adjusted on a per logical drive basis, users are not encouraged to make a change to the default values.

For example, smaller stripe sizes are ideal for I/Os that are transaction-based and randomly accessed. However, using the wrong stripe size can cause problems. When an array of the 4KB stripe size receives files of 128KB size, each drive will have to write many more times to store data fragments of the size of 4KB.

Unlike the previous firmware versions, controller optimization mode can be changed without changing the array stripe size.

The default values in optimization modes guarantee the optimal performance for most applications. Consult Table 2-2 for all the controller parameters that are related to system performance and fault-tolerance.

7. What RAID level?

Different RAID levels provide varying levels of performance and fault tolerance.

Table 2 - 1 RAID Levels

RAID Level	Description	Capacity	Data Availability
NRAID	Non-RAID	N	N/A
RAID 0	Disk Striping	N	==NRAID
RAID 1 (0+1)	Mirroring Plus Striping (if N>1)	N/2	>>NRAID ==RAID 5
RAID 3	Striping with Parity on dedicated disk	N-1	>>NRAID ==RAID 5
RAID 5	Striping with interspersed parity	N-1	>>NRAID ==RAID 5
Logical Volume	Striping one or more logical drives of different RAID levels	*	Higher; depends on its members

RAID Level	Performance Sequential	Performance Random
NRAID	Drive	Drive
RAID 0	R: Highest W: Highest	R: High W: Highest
RAID 1 (0+1)	R: High W: Medium	R: Medium W: Low
RAID 3	R: High W: Medium	R: Medium W: Low
RAID 5	R: High W: Medium	R: High W: Low
Logical Volume	Depends on its members; see above	Depends on its members

8. Any spare drives?

(Swap Drive Rebuild / Spare Drive Rebuild)

Spare drives allow for the unattended rebuilding of a failed drive, heightening the degree of fault tolerance. If there is no spare drive, data rebuild has to be manually initiated by replacing a failed drive with a healthy one.

As is often ignored, a spare drive (whether dedicated or global) must have a capacity no smaller than the members of a logical drive.

9. Limitations?

Firmware 3.31 and above support 64-bit LBA. A maximum of 64TB capacity can be included in single logical drive.

Up to 128 members can be included in each logical drive.


Extreme array sizes can cause operational problems with system backup and should be avoided.

2.2 Configuring the Array:

2.2.1 Starting a RAID System

Here is a flowchart illustrating basic steps to be taken when configuring a RAID system. Hardware installation should be completed before any configuration takes place.

Figure 2 - 2 Array Configuration Process



Drives must be configured and the controller properly initialized before a host computer can access the storage capacity.

1. Use the LCD panel, terminal program, or the RAIDWatch manager to start configuring your array.
2. When powered on, the controller scans all the hard drives that are connected through the drive channels. If a hard drive is connected after the controller completes initialization, use the "Scan SCSI Drive" function to let the controller recognize its presence.
3. Optimize controller's parameters for your applications.
4. Configure one or more logical drives to contain your hard drives based on the desired RAID level, and/or partition the logical drive or logical volume into one or several partitions.

NOTE:

- *A "Logical Drive" is a set of drives grouped together to operate under a given RAID level and it appears as a single contiguous volume. The controller is capable of grouping drives into as many as 128 logical drives, configured in the same or different RAID levels.*
 - *A total of 32 "Logical Volumes" can be created each from one or several logical drives. A logical drive or logical volume can be divided into a maximum of 64 "Partitions."*
-

5. The next step is to make logical drives or storage partitions available through the host ports. When associated with a host ID or LUN number, each capacity volume appears as one system drive. The host SCSI or Fibre adapter will recognize the system drives after the host bus is re-initialized.
6. The last step is to save your configuration profile in the host system drive or to the logical drives you created.

The controller is totally independent from host operating system. Host operating system will not be able to tell whether the attached storage is a physical hard drive or the virtual system drives created by the RAID controller.

2.3 Operation Theory

2.3.1 I/O Channel, SCSI ID, and LUN

Depending on the interface used by a RAID system, a SCSI drive channel (SCSI bus) can connect up to 15 drives (excluding the RAID controller itself). A Fibre channel 125 drives in a loop. Each device occupies one unique ID.





Figure 2 - 3 SCSI ID/LUNs

The figure on the left illustrates the idea of mapping a system drive to host ID/LUN combinations. The host ID is like a cabinet, and the drawers are the LUNs (LUN is short for Logical Unit Number). Each cabinet (host ID) can have up to 32 drawers (LUNs). Data can be made available through one of the LUNs of a host ID. Most host adapters treat a LUN like another device.

2.3.2 Grouping Drives into an Array


Figure 2 - 4 Connecting Drives



The physical connection of a RAID controller should be similar to the one shown above. Drives are connected through I/O paths that have been designated as drive channels.


The next diagram shows two logical configurations of drives and the physical locations of its members. Using drives from different channels can lower the risk of fatal failure if one of the drive channels should fail. There is no limitation on the locations of spares.

Figure 2 - 5 Physical locations of drive members



A drive can be assigned as the Local Spare Drive that serves one specific logical drive, or as a Global Spare Drive that participates in the rebuild of any logical drive. Spares automatically joins a logical drive when a drive fails. Spares are not applicable to logical drives that have no data redundancy (NRAID and RAID 0).

Figure 2 - 6 Partitions in Logical Configurations




You may divide a logical drive or logical volume into partitions of desired capacity, or use the entire capacity as a single volume.

1. It is not a requirement to partition any logical configuration. Partitioning helps to manage a massive capacity.
2. Note that a logical drive can not be included in a logical volume if it has already been partitioned.

2.3.3 Making Arrays Available to Hosts

Figure 2 - 7 Mapping Partitions to Host ID/LUNs




Host ID mapping is a process that associates a logical configuration of drives with a host channel ID/LUN. To avail logical partitions on host channel(s), map each partition to a host ID or one of the LUNs under host IDs. Each ID or LUN will appear to the host adapter as one virtual hard drive.

There are alternatives in mapping for different purposes:

1. Mapping a logical configuration to IDs/LUNs on different host channels allows two host computers to access the same array. This method is applicable when the array is shared in a clustering backup.
2. Mapping partitions of an array to IDs/LUNs across separate host channels can distribute workload over multiple data paths.
3. Mapping across separate host channels also helps to make use of all bandwidth in a multi-path configuration. Firmware automatically manages the process when one data path fails and the workload on the failed data path has to be shifted to the existing data paths.

Figure 2 - 8 Mapping Partitions to LUNs under ID



2.4 Tunable Parameters

Fine-tune the controller and the array parameters for your host applications. Although the factory defaults guarantee the optimized controller operation, you may refer to the table below to facilitate tuning of your array. Some of the performance and fault-tolerance settings may also be changed later during the preparation process of your disk array.

Take this table as a checklist and make sure you have each item set to an appropriate value.

Table 2 - 2 Controller Parameter Settings

- ① Parameters that should be configured at the initial stage of system configuration
- ② Parameters that can be changed later
- ③ Non-critical

User-Defined Parameters	Default	Alternate Settings
Fault Management:		
① Automatic Logical Drive Rebuild - Spare Drive	Enabled when Spare Drive is available	RAID 1 + Local Spare RAID 3 + Local Spare RAID 5 + Local Spare Global Spare
① S.M.A.R.T.	Disabled	Detect Only Perpetual Clone Clone + Replace
③ Clone Failing Drive	Manual function	Replace After Clone Perpetual Clone
① Rebuild Priority	Low (higher priority requires more system resource)	Low Normal Improved High
① Verification on Write	Disabled	On LD Initialization On LD Rebuild On Normal Drive Writes
③ SDRAM ECC	Disabled	Enabled
① Event Notification	Reports to user interface and onboard alarm	Over Dial-out Modem Over SNMP Trap Over Java-Based Management Software
① System Events	System default	Upper and Lower event triggering thresholds configurable
Controller:		
① Channel Mode	*	Host, Drive, RCCOM, Drive + RCCOM
① Host and Drive channel IDs	*	*
① Controller Unique Identifier	Preset on some models	hex number from 0 to FFFFF (FW 3.25 and above)
② Data rate	Auto	Depends on problems solving

① Date and time	N/A	
① Time zone	+ 8 hrs	

Optimization Mode:

① Write-back Cache	Enabled	Disabled
① Array stripe size	Related to controller general setting	4KB to 256KB
① Optimization for Random/Sequential	Sequential	Either
② Array write policy	Related to controller general setting	W/B or W/T

SCSI Parameters:

① Data Transfer Rate	*	Async. To 100.0MHz
① Maximum Tag Count	32	1-128
① Maximum Queued I/O Count	32	32 to 1024
② LUN's per SCSI ID	8	Up to 32
① Periodic Drive Check Time	Disabled	Enabled
① Periodic SAF-TE and SES Device Check Time	5	Disabled to 60 seconds
① Periodic Auto-Detect Failure Drive Swap Check Time	Disabled	5 to 60 seconds
① Number of Host-LUN Connection	32	1 to 1024
① Tag per Host-LUN Connection	32	1 to 256
① Wide Transfer	*	Enabled/Disabled
① Parity Check	Disabled	Enabled

Spin-Up Parameters:

① Motor Spin-Up	Disabled	Enabled
① Reset at Power-UP	Enabled	Disabled
① Initial Disk Access Delay	*	None to 75 seconds

Fibre Channel Parameters:

① Fibre Connection Options	*	Loop Only Point-to-Point Only Loop Preferred Point-to-Point Preferred
① Fibre Channel Dual-Loop	Enabled	Enabled by cabling connection
① Host ID/WWN name list	*	User configurable
① LUN Filtering	*	Host Access Filter Control Configurable - filter type - access right - name
① RCC through Fibre channel	*	Dedicated or sharing drive channel(s)

Array Configuration:		
① Disk reserved space	256MB	64KB – backward compatible
② Array assignment	Primary controller	Secondary controller
① Array partitioning	1	Up to 64

Others:		
③ Password	N/A	User-Defined; Password Validation Timeout: 1 to Always Check Configurable
③ LCD Display Controller Name	N/A	User-Defined

Accessing the Array through Serial Port and Ethernet

3.1 RS-232C Serial Port

Infortrend's controllers and subsystems can be configured via a PC running a VT-100 terminal emulation program, or a VT-100 compatible terminal. RAID enclosures usually provide one or more DB-9 RS-232C ports. Simply use an RS-232C cable to connect between the controller/enclosure's RS-232C port and the PC serial (COM) port.

Make sure you use the included null modem (IFT-9011) to convert the serial port signals. A null modem might have been provided inside your enclosure. The Null Modem has the serial signals swapped for connecting to a standard PC serial interface.

The following are guidelines on using the serial port:

- The serial port's default is set at 38400 baud, 8 bit, 1 stop bit and no parity. Use the COM1 serial port of the controller.
- In most cases, connecting RD, TD, and SG is enough to establish the communication with a terminal.
- If you are using a PC as a terminal, any VT-100 terminal emulation software will suffice. Microsoft® Windows includes a terminal emulation program as presented with the "(Hyper) Terminal" icon in the Accessories window.
- For other details of connecting serial port, please refer to the *Hardware Manual* that came with your controller.

3.1.1 Configuring RS-232C Connection via Front Panel

Take the following steps to change the baud rate using the front panel keypad:

Press **ENT** for two seconds to enter the Main Menu. Press ▼ or ▲ to select "View and Edit Configuration ..", then press **ENT**.

```
View and Edit
Config ParmS  ↕
```

Select "Communication Parameters ..", then press **ENT**.

```
Communication
Parameters ..
```

Select "RS-232 Configuration ..", then press **ENT**.

```
RS-232C
Configuration ..
```

Select "COM1 Configuration ..", then press **ENT**.

```
COM1
Configuration ..
```

Select "Baud-rate 38400 ..", then press **ENT**.

```
Baud-rate 38400
..
```

The baud rate default is 38400. If other baud rate is preferred, press ▼ or ▲ to select the baud rate, then press **ENT** for 2 seconds to confirm the selected baud rate. Set identical baud rate to your RAID array and your terminal computer.


```
Baud-rate 38400
Change to 19200?
```

- The following baud rates are available: 2400, 4800, 9600, 19200 and 38400.
- Terminal connection should work properly using the above setting. You may check the following options in your COM port configuration if you encounter problems:
 1. "Comm Route Dir ..": The communication route should be configured as "direct to port" instead of "through PPP".
 2. "Term Emul. Enab ..": Make sure the terminal function has not been accidentally disabled.

3.1.2 Starting RS-232C Terminal Emulation

The keys used when operating via the terminal are as follows:


← → ↑ ↓	To select options
[Enter]	To go to a submenu or to execute a selected option
[Esc]	To escape and go back to the previous menu
[Ctrl] [L]	The controller will refresh the screen information



IMPORTANT!

- *If the RS-232C cable is connected while the controller is powered on, press [Ctrl] [L] to refresh the screen information.*
-

The initial screen appears when the controller finishes self-test and is properly initialized. Use ↑ ↓ arrow keys to select terminal emulation mode, then press [ENTER] to enter the Main Menu.



Choose a functional item from the main menu to begin configuring your RAID.

3.2 Out-of-Band via Ethernet

The RAIDWatch manager software provides graphical interface to RAID subsystems. There are two different ways to install the RAIDWatch software if Ethernet connection is preferred:

Method 1

Installing to a management computer


Install RAIDWatch on a management computer and setup the RAID controller's TCP/IP settings. You may then access the array by opening a software session with the controller IP address.

Steps:

1. Connect the RAID system' Ethernet port to a local network. Your management computer must have a valid network connection.
2. Configure your RAID controller for TCP/IP settings. Please refer to 3.2.2 Configuring the Controller.
3. If you have problems setting up an IP, contact your LAN administrator for a valid IP and appropriate values about subnet mask and gateway values.
4. Install Java Runtime (version 1.2.2 or 1.3) and use RAIDWatch's installer program. The installer program, install.htm, can be located in the CD-ROM that came with your system. The program will guide you through the rest of the installation procedure.
5. Start the manager program and enter the controller's IP address.



6. Double-click the Ethernet icon to start configuring your array.




Method 2

Installing to the RAID system

Segregate a reserved space on your arrays and setup the RAID controller's TCP/IP settings. RAIDWatch's main programs can be stored on the reserved space. Open a browser from your management computer and enter the controller IP address followed by "grm.htm" as your URL (e.g., <http://xx.xx.xx.xx/grm.htm>) to start the software.

Steps:

1. Connect the RAID system's Ethernet port to a local network. Your management computer must have a valid network connection.
2. Create a reserved space on your array(s). For more details, please refer to 3.2.2 Configuring the Controller.
3. Set up the related TCP/IP configurations to enable the Ethernet port and the http service will be automatically activated.
4. FTP RAIDWatch program files to the controller IP address.
5. Open your browser to access the RAID system. Enter the controller IP address followed by "grm.htm" as your URL.
6. It may take a while for the manager to start. When started for the first time, Java Applet will be loaded.
7. Double-click the Ethernet icon to start configuring your array.



What Is the “Disk Reserved Space?”

RAIDWatch and Reserved Space:

- There is no need to install the RAIDWatch program to your management computer if you access the software using the controller Ethernet port. In order to simplify the installation process, system firmware already contains important software agents.
- User’s configuration data and the manager’s main programs are kept in a small section of disk space on each data drive. The segregated disk space is called a “Disk Reserved Space.” When configuring a logical drive, firmware automatically segregates a 256MB of disk space from each of the member drives.
- Because the manager’s main program is run from the reserved space on drives, in the event of single controller failure, the manager interface can “failover” to a counterpart controller. Operators’ access to the system will not be interrupted.

Other Concerns

Availability Concern:

For safety reason, it is better to create a reserved space on more than one logical drive.

Whatever data is put into the reserved space, firmware will automatically duplicate and distribute it to the reserved section on every data drive. Even if one hard drive or one logical drive fails, an exact replica still resides on other drives.

Web-Based Management

The controller firmware has embedded http server. Once properly configured, the controller/subsystem’s Ethernet port behaves like an HTTP server.

Requirements

1. Controller/subsystem running Firmware revision 3.21 and above [3.25 onwards has embedded NPC (Notification Processing Center) support]
2. **Management Station:**
Pentium or above compatible (or equivalent PC) running Windows NT 4/Windows 2000; Solaris 7 & 8 (SPARC, x86); AIX 4.3; or Red Hat

Linux 6.1 (kernel v2.2.xx); Red Hat 7/8, SUSE 7, WIN95/98, or Windows Me/XP

3. Standard Web Browser.

4. A management station (computer) accessing RAIDWatch manager must support:

-**TCP/IP**

-**Java Runtime:** a package is bundled with RAIDWatch installer or it can be downloaded from SUN Microsystems' web site.

5. A static or an IP address obtained by DHCP method

3.2.1 Connecting Ethernet Port:

Use a LAN cable to connect the Ethernet port(s) on the subsystem's RAID controller unit(s). Use only shielded cable to avoid radiated emissions that may cause interruptions. Connect the cable between controller's LAN port and a LAN port from your local network.

3.2.2 Configuring the Controller

To prepare the controller for using the RAIDWatch manager, do the following:

1. Use a Terminal Emulator to Begin Configuration

Connect the subsystem's serial port to a PC running a VT-100 terminal emulation program or a VT-100 compatible terminal.

Make sure the included Null Modem is already attached to enclosure serial port or the host computer's COM port. The Null Modem converts the serial signals for connecting to a standard PC serial interface. For more details, please refer to the descriptions above in section 3.1.

2. Create a Reserved Space on Drives

LG	ID	LV	RAID	Size(MB)	Status	1	2	3	0	C	#LN	#SB	#FL	NAME
0			NONE											
Maximum Drive Capacity : 26444MB Assign Spare Drives Disk Reserved Space: 256 MB Write Policy: Default(Write-Back) Initialize Mode: On-Line Stripe Size: Default														
5			NONE											
6			NONE											
7			NONE											

Cache Status: Clean
Write Cache: Enable

Arrow Keys: Move Cursor | Enter: Select | Esc: Confirm | Ctrl+L: Refresh Screen

Create one or more logical drives and the reserved space option will be automatically available. The default size is 256MB, and it is recommended to keep it as is. A reserved disk space will be formatted on every member drives.

If you delete a logical drive later, the reserved space will remain intact. Unless you manually remove the reserved space, data kept in it will be unaffected. These drives can later be used to create a new logical drive without making additional changes.

Quick view view view view view view view view view	Slot	Ch1	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
	1	0		4857	80MB	NONE	FRMT DRV	
		1	1	4857	80MB	NONE	FRMT DRV	
		1	2	4857	80MB	NONE	FRMT DRV	
		1	3	4857	80MB	NONE	NEW DRV	
		1	4	4857	80MB	NONE	NEW DRV	
		1	5	4857	80MB	NONE	NEW DRV	
		1	6	4857	80MB	NONE	NEW DRV	
		1	8	4857	80MB	NONE	NEW DRV	

Cache Status: Clean
e Cache: Enable

Arrow Keys: Move Cursor | Enter: Select | Esc: Exit | Ctrl+L: Refresh Screen

When formatted, a meta-filesystem is created on the 256MB reserved space. A drive configured with a reserved space will be stated as a "formatted drive."

3. Assign an IP Address to Ethernet Port:

Assign an IP address to the controller Ethernet port and specify the Net Mask and gateway values. Power off your system and then power on again for the configuration to take effect.

Select "View and Edit Configuration Parameters" from the main menu. Select "Communication Parameters" -> "Internet Protocol (TCP/IP)" -> press [ENTER] on the chip hardware address -> and then select "Set IP Address."

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
v
s
v
v
Communi
C
View Statistics
Set IP Address
RS-2
Routing Table Configuration
P
M
LAN0(R8192C) HwAddr 00:D0:23:00:00:00 - 192.168.20.19
S
Internet Protocol (TCP/IP)
File System Maintenance

```

Provide the IP address, NetMask, and Gateway values accordingly.

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
v
s
v
v
Communi
C
Address: 192.168.20.00
Set IP Address
RS-2
NetMask: 255.255.255.0
Routing Table Configuration
P
M
LAN0(R8192C) HwAddr 00:D0:23:00:00:00 - 192.168.20.00
S
Internet Protocol (TCP/IP)
File System Maintenance

```

PING the IP address from your management computer to make sure the link is up and running.

4. FTP Manager Programs to the Controller IP Address

There are several RAIDWatch programs that need to be FTP'ed to the controller IP address.

1. Necessary program files can be found in a zip file (GUI.zip) in the CD-ROM that came with your machine. Unzip "grem.htm", "grem.jar", "grm.htm", and "grm.jar" to your PC. Files are available in the following directory: X:\Java where X is the CD-ROM letter.
2. Open a DOS prompt. You may use an FTP program to complete the same process. Move to the folder where the unzipped program files reside. Key in "ftp xx.xx.xx.xx" (controller IP address) and press Enter to proceed.
3. Login as "root" and there is no password for the first login. Press Enter to skip password entry.
4. Use the "put" command to transfer the following files:
 - put grm.htm
 - put grm.jar
 - put grem.htm
 - put grem.jar
5. Proceed to install Java Run-time environment from the CD (If the management station is a P4-based computer, it is required to install Java JRE version1.3.1).

6. Reset the RAID subsystem using the “Reset Controller” command in “System Functions” for the configuration to take effect.

5. Starting the Manager:

Start your web browser and enter the IP address assigned to the controller followed by “grm.htm” as your URL (e.g., <http://xx.xx.xx.xx/grm.htm>).

Enter the IP address followed by “grem.htm” to start Event Monitor.

3.2.3 NPC Onboard

NPC is short for Notification Processing Center, a sub-module for use with system event notification.

To activate the NPC module, do the following:

1. Create an NPC configuration file (in a simple text file format) using a text editor program like Notepad in Win32 systems.
2. Save it in the name of "agent.ini"
3. FTP it to the controller IP address, and then reset the controller for the configuration to take effect.

Listed below is the sample configuration. Specify your configuration using simple defining parameters as shown below.

```
[SNMP_TRAP]
ENABLED=0      (1=on; 0=off)
SEVERITY=1
COMMUNITY=public
RECEIVER1=XXX.XXX.XXX.XXX,2 ("2" specifies the level of
                             events to be received by this receiver)

[EMAIL]
ENABLED=0
SEVERITY=1
SUBJECT=Event Message
SENDER_MAIL_BOX=XXXX@XXXXX.XXX
SMTP_SERVER=XXX.XXX.XXX.XXX
RECEIVER1=XXXX@XXXXX.XXX,3
RECEIVER2=XXXX@XXXXX.XXX,1
RECEIVER3=XXXX@XXXXX.XXX,2
RECEIVER4=XXXX@XXXXX.XXX,1

[BROADCAST]
ENABLED=0
SEVERITY=1
RECEIVER=XXX.XXX.XXX.XXX, 1
RECEIVER=XXX.XXX.XXX.XXX, 1
```

NOTE:

NPC will be automatically activated if any of the notifier settings (email, SNMP, or broadcast) is set to "enabled."

The configuration file is comprised of three major sections: SNMP, Email and Broadcast. Each notifying method can be separately enabled or disabled.

The SNMP_TRAP section

[SNMP_TRAP] – section header

[ENABLED] – 1=enabled, 0=disabled (applies to this section only)

[SEVERITY] - level of severity of the messages to be received:

1. notification, 2. warning, 3. alert. “1” covers events of all levels. “3” sends only the most serious events.)

[COMMUNITY] – SNMP community name of the destination/ receiver

[RECEIVER] – The IP address of the receiver computer. Add additional lines to specify multiple receivers. Up to 4 receivers can be configured.

The EMAIL section

[EMAIL] – section header

[ENABLED] – 1=enabled, 0=disabled (applies to this section only)

[SEVERITY] - level of severity of the messages to be received:

notification, 2. warning, 3. alert. “1” covers events of all levels. “3” sends only the most serious events.)

[SUBJECT] – add a topic to email. This can be used to specify the location of the RAID system, if there are many.

[SENDER_MAIL_BOX] – a valid email address to be used as the “from” part of the email message.

[SMTP_SERVER] – SMTP server used to send email. IP address only, do not enter a host name here.

[RECEIVER#] – receiver’s email address. The receiver’s number followed by an “=” mark, an email address, “comma,” and the number to specify the message severity level.

* * * *

The BROADCAST section

[BROADCAST] – section header

[ENABLED] – 1=enabled, 0=disabled (applies to this section only)


[SEVERITY] – level of severity of the messages to be received:

1. notification, 2. warning, 3. alert. “1” covers events of all levels. “3” only the most serious events will be broadcast.)

[RECEIVER#] – The IP address of the receiver computer. Add additional lines to specify multiple receivers. Up to 4 receivers can be configured.

LCD Screen Messages

4.1 The Initial Screen



Status/Data Transfer Indicator:


- Ready There is at least one logical drive or logical volume mapped to a host ID/LUN.
- No Host No logical drive created or the logical drive has not
- LUN yet been mapped to any host ID/LUN.
- Indicates data transfer. Each block indicates 256Kbytes of data throughput.

4.2 Quick Installation Screen



Press **[ENT]** to create a logical drive, the controller will start initialization of one logical drive with all the connected SCSI drives and automatically map the logical drive to LUN 0 of the first host channel. The “Quick Installation” can only be performed when there is no Logical Drive.

4.3 Logical Drive Status



Logical Drive: The Logical Drive number.
RAID level: The RAID level used in this logical drive
Drive numbers: The number of physical drives included in this configuration.

Logical Drive status:

XxxxMB The capacity of this logical drive.
 SB=x Standby drives available to this logical drive. Except the spares dedicated to other logical configurations, all spare drive(s) will be counted in this field, including Global and Local Spares.

xxxxMB INITING The logical drive is now initializing.

xxxxMB INVALID For firmware version before 3.31:
 The logical drive has been created with "Optimization for Sequential I/O", but the current setting is "Optimization for Random I/O."

-OR-

The logical drive has been created with "Optimization for Random I/O," but the current setting is "Optimization for Sequential I/O."

Firmware version 3.31 has separate settings for array optimization and array stripe size. This message will not appear when the optimization mode is changed.

xxxxMB GD SB=x The logical drive is in good condition.


xxxxMB FL SB=x One drive failed in this logical drive.

xxxxMB RB SB=x Logical Drive is rebuilding.

xxxxMB DRVMISS One of the drives is missing.


INCOMPLETE Two or more drives failed in this logical drive.
 ARRAY

4.4 Logical Volume Status



- Logical Volume:** The Logical Volume number.
- DRV=x:** The number of logical drive(s) contained in this logical volume.
- Logical Volume ID:** The unique ID number of the logical volume (controller random generated).
- Logical Volume Status:**
- xxxMB** The capacity of this logical volume.
- DRV=X:** The number of member logical drive(s) in this logical volume.


4.5 SCSI Drive Status



Drive Status:

LG=x IN	Initializing
LG=x LN	On-line (already a member of a logical configuration)
LG=x RB	Rebuilding
LG=x SB	Local Spare Drive
GlobalSB	Global Spare Drive
NEW DRV	New drive
BAD DRV	Failed drive
ABSENT	Drive does not exist
MISSING	Drive missing (drive was once there)
SB-MISS	Spare drive missing

4.6 SCSI Channel Status



Channel Mode:

Host	Host Channel mode
Drive	Drive Channel mode

Default SCSI Bus Sync Clock:

80.0M	The default setting of this channel is 80.0MHz in Synchronous mode
Async	The default setting of this SCSI channel is in Asynchronous mode

Primary Controller SCSI ID Mapping:

*	Multiple SCSI ID's applied (Host Channel mode only)
<i>(ID number)</i>	Primary Controller is using this SCSI ID for host LUN mapping.
NA	No SCSI ID applied (Drive Channel mode only)

Secondary Controller SCSI ID Mapping:

*	Multiple SCSI ID's applied (Host Channel mode only)
<i>(ID number)</i>	Secondary Controller is using this SCSI ID for host LUN mapping.
NA	No SCSI ID applied (Drive Channel mode only)

4.7 Controller Voltage and Temperature

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Peripheral Dev," then press **ENT**.

Press **▼** or **▲** to select "Ctrl Peripheral Device Config..", press **ENT** and then choose "View Ctrl Periph Device Status..", then press **ENT**.

```
View and Edit  
Peripheral Dev ↓
```

```
Ctrl Peripheral  
Device Config..
```

```
View Ctrl Periph  
Device Status..
```

Press **▼** or **▲** to choose either "Voltage Monitor", or "Temperature Monitor".

```
Voltage Monitor  
..
```

```
Temperature  
Monitor ..
```

Select "Temperature and Voltage Monitor" by pressing **Enter**. Press **▼** or **▲** to browse through the various voltage and temperature statuses.

```
[+12V] 12.077V  
Operation Normal
```

```
[+5v] 4.938v  
Operation Normal
```

```
[+3.3V] 3.384V  
Operation Normal
```

```
[CPU] 43.5°C  
in Safe Range
```

```
[+12v] 12.077v  
Operation Normal
```

```
[CPU] 43.5°C  
in Safe Range
```

```
[Board]46.5°C  
in Safe Range
```


```
[Board1]46.5°C  
in Safe Range
```


4.8 Cache Dirty Percentage

The LCD panel indicates the cache dirty percentage. The amber-colored “busy” light blinking on front panel also indicates that the cache is being accessed.


4.9 View and Edit Event Logs

Press **ENT** for two seconds to enter the Main Menu. Press ▼ or ▲ to select “View and Edit Event Logs,” then press **ENT**.




View and Edit
Event Logs ↑

Press ▼ or ▲ to browse through the existing event log items.



UPS Power
Failure Detected

To delete a specified item and all events prior to this event, press **ENT** for 2 seconds.



Press 2 Seconds
to Clear Events

IMPORTANT!

- *The event log will be cleared after the controller is powered off or reset.*
-

LCD Keypad Operation

5.1 Power on RAID Enclosure

Before you start to configure a RAID system, make sure that hardware installation is completed before any configuration takes place. Power on your RAID enclosure.

5.2 Caching Parameters

Optimization Modes

Mass storage applications can be categorized into two according to its read/write characteristics: database and video/imaging. To optimize the controller for these two categories, the controller has two embedded optimization modes with controller behaviors adjusted to different read/write parameters. They are the Optimization for Random I/O and the Optimization for Sequential I/O.

Limitations: There are limitations on the use of optimization modes.

1. You can select the stripe size of each array (logical drive) during the initial configuration. However, changing stripe size is only recommended for experienced engineers who have tested the effects tuning stripe sizes for different applications.
2. The array stripe size can only be changed during the initial configuration process.
3. Once the controller optimization mode is applied, access to different logical drives in a RAID system will follow the same optimized pattern. You can change the optimization mode later without having to re-organize your array.

Database and Transaction-based Applications:

This kind of applications usually include SQL server, Oracle server, Informix, or other data base services. These applications keep the size of each transaction down to the minimum, so that I/Os can be rapidly processed. Due to its transaction-based nature, these applications do not read or write a bunch of data in a sequential order. Access to data occurs randomly. The transaction size usually ranges from 2K to 4K. Transaction performance is measured in “I/Os per second” or “IOPS.”

Video Recording/Playback and Imaging Applications:

This kind of applications usually includes video playback, video post-production editing, or other similar applications. These applications have the tendency to read or write large files from and into storage in a sequential order. The size of each I/O can be 128K, 256K, 512K, or up to 1MB. The efficiency of these applications is measured in “MB/Sec.”

When an array works with applications such as video or image oriented applications, the application reads/writes from the drive as large-block, sequential threads instead of small and randomly accessed files.

The controller optimization modes have read-ahead buffer and other R/W characteristics tuned to obtain the best performance for these two major application categories.

Optimization Mode and Stripe Size

Each controller optimization mode has preset values for the stripe size of arrays created in different RAID levels. If you want a different value for your array, you may change the controller optimization mode, reset the controller, and then go back to create the array. Once the array is created, stripe size can not be changed.

Using the default value should be sufficient for most applications.

	Opt. For Sequential I/O	Opt. for Random I/O
RAID0	128	32
RAID1	128	32
RAID3	16	4
RAID5	128	32

Optimization for Random or Sequential I/O

Select from main menu “View and Edit Config Params,” “Caching Parameters,” and press **ENT**. Choose “Optimization for Random I/O” or “Optimization for Sequential I/O,” then press **ENT** for two seconds to confirm. Press **ESC** to leave and the setting will take effect after the controller is restarted.

```
Caching  
Parameters ..
```

```
Optimization I/O  
Random ..
```

```
Optimization for  
Sequential I/O?
```

IMPORTANT!

- *The original 512GB threshold on array optimization mode is canceled. If the size of an array is larger than 16TB, only the optimization for sequential I/O can be applied. Logical drives of this size are not practical; therefore, there is actually no limitation on the optimization mode and array capacity.*
-

Write-Back/Write-Through Cache Enable/Disable

As one of the submenus in "Caching Parameters," this option controls the cached write function. Press **ENT** to enable or disable “Write-Back Cache.” Press **ENT** for two seconds to confirm. The current status will be displayed on the LCD.

```
Write-Back Cache  
Enabled ..
```

The Write-through mode is safer if your controller is not configured in a redundant pair and there is no battery backup.

```
Disable Write  
-Back Cache ?
```

Write-back caching can dramatically improve write performance by caching the unfinished writes in memory and let them be committed to drives latter in a more efficient manner. In the event of power failure, a battery module can hold cached data for days. In the event of controller failure, data cached in the failed controller has an exact replica on its counterpart controller and therefore remains intact.

IMPORTANT!

- *Every time you change the Caching Parameters, you must reset the controller for the changes to take effect.*
 - *In the Redundant Controller configuration, write-back will only be applicable when there is a synchronized cache channel between partner controllers.*
-

5.3 View Connected Drives:

A RAID system consists of many physical drives that can be modified and configured as the members of one or several logical drives.

Press the front panel **ENT** button for two seconds to enter the Main Menu. Use ▼ or ▲ to navigate through the menus. Choose "View and Edit SCSI Drives," then press **ENT**.

```
View and Edit
SCSI Drives
```

Use ▼ or ▲ to scroll down the list of connected drives' information screens.

```
C=2 I=0 1010MB
New DRV SEAGATE
```

You may first examine whether there is any drive installed but not shown here. If there is a drive installed but not listed, the drive may be defective or not installed correctly, please check your enclosure installation and contact your system vendor.

Press **ENT** on a drive. Choose "View Drive Information" by pressing **ENT**. Use ▼ or ▲ to navigate through the screens.

```
View Drive
Information ..
```

The Revision Number of the selected SCSI drive will be shown. Press ▼ to see other information.

```
Revision Number:
0274
```

Other information screens include "Serial Number" and "Disk Capacity" (displayed in blocks- each block equals 512K Bytes).

IMPORTANT!

- *Drives of the same brand/model/capacity might not feature the same block number.*
 - *The basic read/write unit of a hard drive is block. If members of a logical drive have different block numbers (capacity), the smallest block number will be taken as the maximum capacity to be used in every drive. Therefore, use drives of the same capacity.*
 - *You may assign a Local/Global Spare Drive to a logical drive whose members has a block number equal or smaller than the Local/Global Spare Drive but you should not do the reverse.*
-

5.4 Creating a Logical Drive

To create a logical drive, press **ENT** for two seconds to enter the Main Menu. Use **▼** or **▲** to navigate through the menus. Choose "View and Edit Logical Drives," and then press **ENT**.

```
View and Edit
Logical Drives
```

Press **▼** or **▲** to select a logical drive entry, then press **ENT** for two seconds to proceed. "LG" is short for Logical Drive.

```
LG=0
Not Defined ?
```

Choosing a RAID Level:

Press **▼** or **▲** to choose the desired RAID level, then press **ENT** for two seconds. "TDRV" (Total Drives) refers to the number of available SCSI drives.

```
TDRV=4 Create
LG Level=RAID5 ?
```

Choosing Member Drives:

Press **ENT** for two seconds, a message, "RAID X selected To Select drives", will prompt. Confirm your selection by pressing **ENT**.

```
RAID X Selected
To Select drives
```

Press **ENT**, then use **▼** or **▲** to browse through the available drives. Press **ENT** again to select/deselect the drives. An asterisk (*) mark will appear on the selected drive(s). To deselect a drive, press **ENT** again on the selected drive. The (*) mark will disappear. "C=1 I=0" refers to "Channel 1, SCSI ID 0".

```
C=1 I=0 1010MB
NEW DRV SEAGATE
```

After all the desired drives have been selected, press **ENT** for two seconds to continue. Press **▼** or **▲** to choose "Create Logical Drive," then press **ENT** for two seconds to start initializing the logical drive.

```
Create Logical
Drive ?
```

Logical Drive Preferences:

You may also choose "Change Logical Drive Parameter," then press **ENT** to

```
Change Logical
Drive Parameter?
```

change related parameters before initializing the logical drive.

Maximum Drive Capacity:

Choose “Maximum Drive Capacity,” then press **ENT**. The maximum drive capacity refers to the maximum capacity that will be used in each member drive.

```
Maximum Drive
Capacity      ..
```

Use **▼** and **▲** to change the maximum size that will be used on each drive.

```
MaxSiz= 1010MB
Set to   1010MB?
```

Spare Drive Assignments:

Local Spare Drive can also be assigned here. Press **▼** or **▲** to choose “Spare Drive Assignments,” then press **ENT**.

```
Spare Drive
Assignments ..
```

Available drives will be listed. Use **▼** or **▲** to browse through the drive list, then press **ENT** to select the drive you wish to use as the Local Spare Drive. Press **ENT** again for two seconds.

```
C=1 I=15 1010MB
*LG=0 SL SEAGATE
```

Disk Reserved Space:

This menu allows you to change the size of disk reserved space. Default is 256MB. We recommended using the default value.

```
Disk Rev. Space
256MB      ..
```

Choices are 256MB and 64KB. With 64KB, logical drives are backward compatible to RAID controllers running earlier firmware versions. Press **ENT** and use the **▼** or **▲** keys to choose the size you prefer.

Write Policy:

This menu allows you to set the caching mode policy for this specific logical drive. “Default” is a neutral value that is coordinated with the controller’s caching mode setting. Other choices are “Write-Back” and “Write-Through.”

```
Write Policy
Default     ..
```


Initialization Mode:

This menu allows you to determine if the logical drive is immediately accessible. If the Online method is used, data can be written onto it before the array's initialization is completed. Users may proceed with array configuration, e.g., including this array in a logical volume.

```
Initialization
Mode      Online..
```

Array initialization can take a long time especially for those comprised of large capacity. Setting to "Online" means the array is immediately accessible and that the controller will complete the initialization when IO demands become less intensive.

Stripe Size:

This menu allows you to change the array stripe size. Setting to an incongruous value can severely drag the performance. This item should only be changed when you can be sure of the performance gains it might bring you.

```
Stripe size
Default      ?
```

Listed below are the default values for an array. The default value for the stripe size is determined by controller Optimization Mode and the RAID level chosen for an array.

Table 5 - 1 RAID Level, Optimization Modes, and Stripe Size

	Opt. for Sequential I/O	Opt. for Random I/O
RAID0	128	32
RAID1	128	32
RAID3	16	4
RAID5	128	32

When you are done with setting logical drive preferences, press **ESC** and use your arrow keys to select "Create Logical Drive?". Press **ENT** for two seconds to proceed.

Beginning Initialization

Press **ESC** to return to the previous menu. Use **▼** or **▲** to choose "Create Logical Drive," then press **ENT** for two seconds to start initializing the logical drive.

```
Create Logical
Drive      ?
```

The On-Line Mode:

```
LG=0 Creation
Completed!
```

If online initialization method is applied, the array will be available for use immediately. The array initialization runs in the background while data can be written onto it and users can continue configuring the RAID system.

The Off-Line Mode:

The controller will start to initialize the array parity if using the “Off-line” mode. Note that if NRAID or RAID 0 is selected, initialization time is short and completes almost immediately.

The logical drive’s information displays when the initialization process is completed. If “On-line” mode is adopted, array information will be displayed immediately.

```
Initializing090%  
Please Wait!
```

```
LG=0 Initializat  
Ion Completed
```

```
LG=0 RAID5 DRV=3  
2012MB GD SB=0
```

5.5 Creating a Logical Volume

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Logical Volume," then press **ENT**.

```
View and Edit
Logical Volume ↓
```

Press **▼** or **▲** to select an undefined entry for logical volume, then press **ENT** for two seconds to proceed. "LV" is short for Logical Volume.

```
LV=0
Not Defined   ?
```

Proceed to select one or more logical drives. Press **ENT** to proceed. "LD" is short for Logical Drive.

```
LV=0 Selected To
Select LD Drives?
```

Use **▼** or **▲** to browse through the logical drives. Press **ENT** again to select/deselect the drives. An asterisk (*) mark will appear when the logical drive is selected. After all the desired logical drive(s) have been selected, press **ENT** for two seconds to continue.

```
LG0 RAID5 DRV=3
2021MB GD SB=0
```

Two submenus will appear.

Initialization Mode

Array initialization can take a long time especially for those comprised of large capacity. Setting to "Online" means the array is immediately accessible and that the controller will complete the initialization when IO demands become less intensive.

```
Initialization
Mode      Online..
```

Write Policy

This menu allows you to set the caching mode policy for this specific logical volume. "Default" is a neutral value that is coordinated with the controller's caching mode setting. Other choices are "Write-Back" and "Write-Through."

```
Write Policy
Default    ..
```

When finished with setting the preferences, press **ENT** for two

seconds to display the confirm box. Press **ENT** for two seconds to start initializing the logical volume.

```
Create
Logical Volume ?
```

The logical volume has been successfully created.

```
Lv=0 Creation
Completed
```

Press **ESC** to clear the message. Another message will prompt, press **ESC** to clear it.

```
Lv=0 ID=07548332
0024488MB DRV=2
```

Logical volume information will be displayed below.

```
Create Logical
Volume Succeeded
```

Logical Volume Assignment

If you have two controllers, you may choose to assign this logical volume to the secondary controller. The assignment can be done during or after the initial configuration.

```
Change Logical
Volume Params ?
```

If the redundant controller function has been enabled, secondary controller IDs assigned to IO channels, the assignment menus should appear as listed on the right.

```
Logical Volume
Assignments ..
```

If settings related to redundant controllers have not been accomplished, you may find the option after the volume is successfully created.

```
Red Ctlr Assign
to Sec. Ctlr ?
```

Press **ENT** on a configured logical volume. Use arrow keys to select “Logical Volume Assignment..”, and press **ENT** to proceed. Press **ENT** for two seconds to confirm.

```
Logical Volume
Assignment ..
```

Press **ESC**, and the LCD will display the logical volume’s information when initialization is finished.

```
Red Ctlr Assign
to Sec. Ctlr ?
```

```
LV=0 ID=685AE502
2021MB DRV=1
```

5.6 Partitioning a Logical Drive/Logical Volume

Partitioning, as well as the creation of logical volume, are not the requirements for creating a RAID system. The configuration processes for partitioning a logical drive are the same as those for partitioning a logical volume.

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Logical Volume," then press **ENT**.

```
View and Edit
Logical Volume ↑
```

Press **▼** or **▲** to select a logical volume, then press **ENT**.

```
LV=0 ID=685AE502
2021MB DRV=1
```

Press **▼** or **▲** to select "Partition Logical Volume," then press **ENT**.

```
Partition
Logical Volume..
```

The total capacity of the logical volume will be displayed as the first partition (partition 0). Press **ENT** for two seconds to change the size of the first partition.

```
LV=0   Part=0:
        2021MB   ?
```

Use **▼** or **▲** to change the number of the flashing digit, (see the arrow mark) then press **ENT** to move to the next digit. After changing all the digits, press **ENT** for two seconds to confirm the capacity of this partition. You may also use arrow keys to move down to the next partition.

```
LV=0   Part=0:
        2021MB
```



```
LV=0 Part=0:
        700MB   ?
```

The rest of the drive space will be automatically allocated as the last partition. You may go on to create up to 32 partitions using the same method as described above.

```
LV=0 Partition=1
        1321MB  ?
```

Press **ESC** for several times to go back to the main menu.

5.7 Mapping a Logical Volume/Logical Drive to Host LUN

The process of mapping a logical drive is identical to that of mapping a logical volume. The process of mapping a logical volume is used as an example.

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Host Luns," then press **ENT**.

```
View and Edit
Host Luns      ↑↓
```

Note some details before proceeding:

1. **Primary/Secondary IDs:** A logical group of drives (logical drive/logical volume) previously assigned to the primary controller can not be mapped to a secondary ID. Neither can those assigned to the secondary controller be mapped to a primary ID.
2. **Reserved IDs:** For a SCSI-based controller, ID 7 is reserved for the controller itself. If there are two controllers, controllers might occupy ID 6 and ID 7. Please check your system Hardware Manual for details on preserved IDs.

Press **▼** \or **▲** to select a configured host ID, and then press **ENT** for two seconds to confirm. IDs are available as Primary or Secondary Controller IDs.

```
CH=0 ID=000
Pri. Ctlr   ..
```

Press **▼** or **▲** to select the type of logical configuration. Available choices are "Map to Logical Volume," "Map to Logical Drive," or "Map to Physical Drive." Confirm your choice by pressing **ENT**.

```
Map to
Logical Volume ?
```

Press **▼** or **▲** to select a LUN number, then press **ENT** to proceed.

```
CH=0 ID=0 LUN=0
Not Mapped
```

Press **ENT** for two seconds to confirm the selected LUN mapping.

```
Map Host LUN  ?
```

Press **▼** or **▲** to select a partition from the logical volume. Press **ENT** for two seconds to map the selected partition to this LUN. If the logical configuration has not been partitioned,

```
LV=0 ID=685AE502
2021MB          DRV=1
```

```
LV=0 PART=0
700MB          ?
```

you can map the whole capacity to a host LUN.

Mapping information will be displayed on the subsequent screen. Press **ENT** for two seconds to confirm the LUN mapping.

```
CH=0 ID0 LUN0
MAP to LV=0 PRT=0?
```

With any of the Host ID/LUN successfully associated with a logical capacity, the “No Host LUN” message in the main menu will change to “Ready.”

If you want to create more host IDs, please move to section 5.12 Viewing and Editing SCSI Channels for more details on channel mode and channel IDs setting.

5.8 Assigning Spare Drive and Rebuild Settings

Adding a Local Spare Drive

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select “View and Edit SCSI Drives,” then press **ENT**.

```
View and Edit
SCSI Drives ↓
```

SCSI drive information will be displayed on the LCD. Press **▼** or **▲** to select a drive that is stated as “NEW DRV” or “USED DRV” that has not been assigned to any logical drive, as spare drive or failed drive, then press **ENT** to select it.

```
C=2 I=4 1010MB
NEW DRV SEAGATE
```

Press **▼** or **▲** to select “Add Local Spare Drive,” then press **ENT**.

```
Add Local Spare
Drive ..
```

Press **▼** or **▲** to select the logical drive where the Local Spare Drive will be assigned, then press **ENT** for two seconds to confirm.

```
LG0 RAID5 DRV=3
2012MB GD SB=0
```

The message “Add Local Spare Drive Successful” will be displayed on the LCD.

```
Add Local Spare
Drive Successful
```

Adding a Global Spare Drive

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Drives," then press **ENT**.

```
View and Edit
SCSI Drives ↑
```

SCSI drive information will be displayed on the LCD. Press **▼** or **▲** to select a SCSI drive that has not been assigned to any logical drive yet, then press **ENT**.

```
C=2 I=4 1010MB
NEW DRV SEAGATE
```

Press **▼** or **▲** to select "Add Global Spare Drive," then press **ENT**.

```
Add Global Spare
Drive ..
```

Press **ENT** again for two seconds to add the spare drive. The message "Add Global Spare Drive Successful" will be displayed on the LCD.

```
Add Global Spare
Drive Successful
```

Rebuild Settings

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Config Params," then press **ENT**.

```
View and Edit
Config Params ↑
```

Press **▼** or **▲** to select "Disk Array Parameters," then press **ENT**.

```
Disk Array
Parameters..
```

Press **▼** or **▲** to select "Rebuild Priority Low," then press **ENT**. "Low" refers to the temporary setting.

```
Rebuild Priority
Low ..
```

Press **ENT** again and the abbreviation mark ".." will change to question mark "?". Press **▼** or **▲** to select priority "Low," "Normal," "Improved," or "High".

```
Rebuild Priority
Low ?
```

Press **ENT** to confirm and the question mark "?" will turn into "..".

```
Rebuild Priority
High ..
```

NOTE:

- *The rebuild priority determines how much of controller resources is conducted when rebuilding a logical drive. The default setting of the rebuild priority is “LOW.” Rebuild will have smaller impact on host I/O access, but rebuild will take a longer time to complete. Changing the rebuild priority to a higher level you will have a faster rebuild, but will certainly increase the Host I/O response time. The default setting “LOW” is recommended.*

5.9 Viewing and Editing Logical Drives and Drive Members

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Logical Drives..," then press **ENT**.

```
View and Edit
Logical Drives ↓
```

Press **▼** or **▲** to select the logical drive, then press **ENT**.

```
LG0 RAID5 DRV=3
2012MB GD SB=1
```

Press **▼** or **▲** to select "View SCSI Drives..", then press **ENT** .

```
View SCSI Drives
..
```

Press **▼** or **▲** to scroll through the list of member drives.

```
C=1 I=0 1010MB
LG=0 LN SEAGATE
```

Deleting a Logical Drive

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Logical Drives," then press **ENT**.

```
View and Edit
Logical Drives ↓
```

Press **▼** or **▲** to select a logical drive, then press **ENT**.

```
LG0 RAID5 DRV=3
2012MB GD SB=1
```

Press **▼** or **▲** to select "Delete Logical Drive," then press **ENT** .

```
Delete Logical
Drive ..
```

Press **ENT** for two seconds to delete. The selected logical drive has now been deleted.

```
LG=0
Not Defined ?
```

Deleting a Partition of a Logical Drive

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Logical Drives..," then press **ENT**.

```
View and Edit
Logical Drives ↓
```

Press **▼** or **▲** to select a logical drive, then press **ENT**.

```
LG0 RAID5 DRV=3
2012MB GD SB=1
```

Press **▼** or **▲** to choose "Partition Logical Drive," then press **ENT**.

```
Partition
Logical Drive ..
```

The first partition's information will be shown on the LCD. Press **▼** or **▲** to browse through the existing partitions in the logical drive. Select a partition by pressing **ENT** for two seconds.

```
LG=0 Partition=1
200MB ?
```


```
LG=0 Partition=1
300MB ?
```

Use **▼** or **▲** to change the number of the flashing digit to "0," then press **ENT** to move to the next digit. After changing all the digits, press **ENT** for two seconds.

```
LG=0 Partition=2
600MB ?
```

The rest of the drive space will be automatically allocated to the last partition as diagrammed below.

Figure 5 - 1 Drive Space Allocated to the Last Partition



WARNING!

- *Whenever there is a partition change, data will be erased, and all host LUN mappings will be removed. Therefore, every time the size of a partition has been changed, it is necessary to re-configure all host LUN mappings of the associated partitions.*

Assigning a Name to a Logical Drive

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Logical Drives..," then press **ENT**.

```
View and Edit
Logical Drives ↓
```

Press **▼** or **▲** to select a logical drive, then press **ENT**.

```
LG0 RAID5 DRV=3
2012MB GD SB=1
```

Press **▼** or **▲** to select "Logical Drive Name," then press **ENT**.

```
Logical Drive
Name ..
```

Press **▼** or **▲** to change the character of the flashing cursor. Press **ENT** to move the cursor to the next space. The maximum number of characters for a logical drive name is 25.

```
Enter LD Name:
_
```

Rebuilding a Logical Drive

If you want the controller to auto-detect a replacement drive, make sure you have the following items set to enabled:

1. Periodic Drive Check Time
2. Periodic Auto-Detect Failure Drive Swap Check Time

These two configuration options can be found under "View and Edit Configuration Parameters" -> "Drive-Side SCSI Parameters".

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Logical Drives..," then press **ENT**.

```
View and Edit
Logical Drives ↓
```

Press **▼** or **▲** to select the logical drive that has a failed member, then press **ENT**.

```
LG0 RAID5 DRV=3
2012MB FL SB=0
```

Press **▼** or **▲** to select "Rebuild Logical Drive," then press **ENT**.

```
Rebuild Logical
Drive ..
```

Press **ENT** for two seconds to start rebuilding the logical drive.

```
Rebuild Logical
Drive ?
```

The rebuilding progress will be displayed (as a percentage) on the LCD.

```
LG0 RAID5 DRV=3
2012MB RB SB=0
```

```
Rebuilding 25%
Please Wait!
```

When rebuilding is already started or the logical drive is being rebuilt by a Local Spare Drive or Global Spare Drive, choose "Rebuild Progress" to see the rebuild progress.

```
Rebuild Progress
..
```

IMPORTANT!

- *The Rebuild function will appear only if a logical drive (with RAID level 1, 3 or 5) has a failed member.*
 - *Use the "Identify Drive" function to check the exact location of a failed drive. Removing the wrong drive may cause a logical drive to fail and data loss is unrecoverable.*
-

Regenerating Logical Drive Parity

If no verifying method is applied to data writes, this function can be manually performed to ensure that parity errors can be mended.

From the Main Menu, press ▼ or ▲ to select "View and Edit Logical Drives."

```
View and Edit
Logical Drives
```

If you have more than one logical drive, use the ▼ or ▲ to select the logical drive you would like to check the parity for; and then **press ENT**.

```
LG0 RAID5 DRV=3
4095MB GD SB=0
```

Press ▼ or ▲ to select "Regenerate Parity" and then press **ENT**.

```
Regenerate
Parity ..
```

To stop the regeneration process, press ESC and enter the submenu to select "Abort Regenerate Parity".

```
Abort Regenerate
Parity ..
```

IMPORTANT!

- *If Parity Regenerating process is stopped by a drive failure, the process cannot restart until the logical drive is rebuilt.*
-

Media Scan

Media Scan is used to examine drives and is able to detect the presence of bad blocks. If any data blocks have not been properly committed, data from those blocks are automatically recalculated, retrieved and stored onto undamaged sectors. If bad blocks are encountered on yet another drive during the rebuild process, the block LBA (Logical Block Address) of those bad blocks will be shown. If rebuild is carried out under this situation, rebuild will continue with the unaffected sectors, salvaging a majority of the stored data.

From the Main Menu, press ▼ or ▲ to select "View and Edit Logical Drives".

```
View and Edit
Logical Drives
```

The first logical drive displays. If you have more than one logical drive, use the ▼ or ▲ keys to select the logical drive you want to scan; and then press **ENT**.

```
LG0 RAID5 DRV=3
4095MB GD SB=0
```

Press ▼ or ▲ to select "Media Scan" and then press **ENT**.

```
Media Scan
..
```

Press **ENT** again to display the first configuration option. Press **ENT** on it and use arrow keys to select an option. Press **ENT** to confirm the change on priority level.

```
Priority
Normal ..
```

```
Priority
To High ?
```

Use arrow keys to move one level down to another option, "Iteration Count". This option determines how many times the scan is performed on the logical drive. If set to the continuous, the scan will run in the background continuously until it is stopped by user.

```
Iteration Count
Single ..
```

```
Iteration Count
to Continuous ?
```

If media scan is continuously run in the background, considerable system resources will be consumed.

Press **ENT** on your option to confirm.

Press **ENT** for two seconds to display the confirm message, press **ENT** to start scanning the array.

```
Execute Media
Scanning ?
```

Write Policy

From the Main Menu, press ▼ or ▲ to select "View and Edit Logical Drives".

```
View and Edit
Logical Drives
```

The first logical drive displays. If you have more than one logical drive, use the ▼ or ▲ keys to select the logical drive you want to change the write policy of; and then press **ENT**.

```
LG0 RAID5 DRV=3
4095MB GD SB=0
```

Use arrow keys to select "Write Policy" and then press **ENT**.

```
Write Policy
```

```
..
```

```
Write Policy
Write-Back ?
```

The Write-Back cache setting is configurable on a per array basis. Setting to the default value means the array setting is coordinated with the controller's general setting. The controller's general setting option can be found in "View and Edit Config Params" -> "Caching Parameters" -> "Write-Back Cache". Note that cached writes are lost if power failure should occur unless cached data has been duplicated to a partner controller and a battery is supporting cache memory.

5.10 Viewing and Editing Host LUNs

Viewing and Deleting LUN Mappings

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Host Luns", then press **ENT**.

```
View and Edit
Host Luns      ↑
```

Press **▼** or **▲** to select a host ID, then press **ENT** to proceed.

```
CH=0 ID=002
Sec. Ctlr    ..
```

Press **▼** or **▲** to browse through the LUN number and its LUN mapping information.

```
CH=0 ID=0 LUN=0
Map to LG0 PRT0
```

Press **ENT** on the LUN you wish to delete.

```
Delete CH0 ID0
LUN=00 Mapping ?
```

Press **ENT** for two seconds to confirm deletion. The deleted LUN has now been unmapped.

```
CH=0 ID=0 LUN=0
Not Mapped
```

For LUN Filtering functions, e.g., Create Host Filter Entry, Edit Host-ID/WWN Name List, please refer to **Chapter 8 "Fibre Operation."**

Pass-through SCSI Commands

Pass-through SCSI commands facilitate functions like downloading firmware for drives or devices (not controller firmware), setting SCSI drive mode parameters, or monitoring a SAF-TE/S.E.S. device directly from the host. To perform such a function, the channel device must be mapped to a host ID.

From the Main Menu, press **▼** or **▲** to select "View and Edit Host LUNs."

```
View and Edit
Host Luns
```

If you have primary and secondary controllers, use the **▼** or **▲** keys to select the controller for the device that you would like to map.

```
Map Channel=0
ID=0 Pri Ctlr ?
```

Press **▼** or **▲** to choose to map an ID to "Physical Drive" or other device and then press **ENT**.

```
Map to
Physical Drive ?
```

WARNING!

- *Pass-through SCSI Commands are only intended to perform maintenance functions for a drive or device on the drive side. Do not perform any destructive commands to a disk drive (i.e., any commands that write data to a drive media). If a disk drive is a spare drive or a member of a logical drive, such a destructive command may cause a data inconsistency.*
 - *When a drive/device is mapped to a host SCSI ID so that Pass-through SCSI Commands can be used, the data on that drive/device will not be protected by the controller. Users who employ Pass-through SCSI Commands to perform any write commands to drive media do so at their own risk.*
-

5.11 Viewing and Editing SCSI Drives

Scanning New SCSI Drive

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Drives," then press **ENT**.

```
View and Edit
SCSI Drives  ↓
```

SCSI drive information will be displayed on the LCD. Press **ENT** on a drive. Use **▼** or **▲** to select "Scan New SCSI Drive," then press **ENT** again.

```
Scan new SCSI
Drive          ..
```

Press **▼** or **▲** to select a SCSI channel, then press **ENT** for two seconds.

```
Scan Channel=1 ?
```

Press **▼** or **▲** to select a SCSI ID, then press **ENT** for two seconds.

```
Scan Channel=1
ID= 01          ?
```

The information of the scanned SCSI drive will be displayed on the LCD. If the drive was not detected on the selected SCSI channel and ID, the LCD will display "Scan Fail!"

```
Scan Channel=1
ID=1 Scan Fail!
```

An empty drive entry is added for this channel/SCSI ID for enclosure

```
C=1 I=1 ABSENT
```


management. The drive status is "ABSENT."

```
Clear Drive
Status      ..
```

To clear the empty drive entry, press **ENT** and use arrow keys to select "Clear Drive Status," then press **ENT** to proceed.

Press **ENT** for two seconds to confirm the drive entry's deletion. Information of other drives will be displayed instead.

```
Clear Drive
Status      ?
```

Identifying a Drive

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Drives," then press **ENT**.

```
View and Edit
SCSI Drives ↓
```

SCSI drive information will be displayed. Press **▼** or **▲** to select a SCSI drive, then press **ENT**.

```
C=1 I=0 1010MB
GlobalSB SEAGATE
```

Press **▼** or **▲** to select "Identify Drive," then press **ENT** to continue.

```
Identify Drive
..
```

Press **▼** or **▲** to select "Flash All Drives", "Flash Selected Drive", or "Flash All But Selected Drive". Press **ENT** for two seconds to flash the read/write LEDs of all the connected drives.

```
Flash All
Drives    ?
```

Or, press **▼** or **▲** to select "Flash Selected SCSI Drives," then press **ENT** for two seconds to flash the read/write LED of the selected drive. The read/write LED will light for a configurable time period from 1 to 999 seconds.

```
Flash Selected
SCSI Drives  ?
```

```
Flash all But
Selected Drives?
```

Deleting Spare Drive (Global / Local Spare Drive)

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Drives," then press **ENT**.

```
View and Edit
SCSI Drives ↓
```

SCSI drive information will be displayed on the LCD. Press **▼** or **▲** to select the spare drive you wish to delete, then press **ENT**.

```
C=1 I=0 1010MB
GlobalSB SEAGATE
```

Press **▼** or **▲** to select "Delete Spare Drive," then press **ENT** to continue.

```
Delete Spare
Drive ..
```

Press **ENT** for two seconds to delete the spare drive.

```
Delete Spare
Drive Successful
```

5.12 Viewing and Editing SCSI Channels

Redefining Channel Mode

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Channels," then press **ENT**.

```
View and Edit
SCSI Channels ↓
```

Channel information will be displayed. Press **▼** or **▲** to browse through the information of all channels. Press **ENT** on the channel you wish the channel mode changed.

```
CH0=Host PID=0
SID=NA SXF=20.0M
```

Press **▼** or **▲** to select "Redefine Channel Mode," then press **ENT**.

```
Redefine Channel
Mode ..
```

Press **ENT** for two seconds to change the channel mode.

```
Redefine? CHL=0
To=Drive Channel
```

The new setting will be displayed.

```
CH0=Drive PID=7
SID=NA SXF=20.8M
```

IMPORTANT!

- *Every time you change channel mode, you must reset the controller for the changes to take effect.*
-

Setting a SCSI Channel's ID - Host Channel

Viewing IDs

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Channels," then press **ENT**.

```
View and Edit
SCSI Channels  ↓
```

Channel information will be displayed. Press **ENT** on the host channel you wish the ID changed.

```
CH0=Host  PID=0
SID=NA  SXF=20.0M
```

Press **▼** or **▲** to select "Set SCSI Channel ID," then press **ENT**.

```
Set SCSI Channel
ID                ..
```

Press **▼** or **▲** to browse through the existing ID settings. Press **ENT** on any to continue.

```
CHL=0  ID=0
Primary Ctrl  ..
```

Adding a Channel ID

Press **ENT** on a host channel, on "Set SCSI Channel ID", and then on an existing ID.

Press **▼** or **▲** to choose "Add Channel SCSI ID", then press **ENT**.

```
Add Channel
SCSI ID      ..
```

Press **▼** or **▲** to choose "Primary Controller" or "Secondary Controller", then press **ENT** for two seconds to confirm.

```
Primary
Controller   ?
```

Press **▼** or **▲** to choose the SCSI ID you wish to add, then press **ENT** for two seconds to complete the process.

```
Add CHL=0  ID=2
Primary Ctlr  ?
```

Deleting a Channel ID

Press **ENT** on an existing host channel ID you want to delete. Press **▼** or **▲** to choose "Delete Channel SCSI ID," then press **ENT**.

```
Delete Channel
SCSI ID      ..
```

Press **ENT** for two seconds to confirm.

```
Delete ID=2
Primary Ctlr  ?
```

IMPORTANT!

- *Every time you make changes to channel IDs, you must reset the controller for the configuration to take effect.*
 - *The reserved IDs for SCSI-based controllers are shown below:
Single controller configuration (SCSI-based controllers):
Drive channels – "7"
Redundant controller configuration:
Drive channels – "8" and "9"*
- For IDs reserved in different controller configurations, please refer to the hardware manual that came with your system. For controllers connected through back-end PCBs, firmware can detect its board type and automatically apply the preset IDs. There is no need to set IDs for these models.*
- *In single controller mode, you should set the Secondary Controller's ID to "NA." If a secondary controller exists, you need to set an ID for it on each of your drive channels.*
 - *Multiple target IDs can be applied to Host channels while each Drive channel has only one or two IDs (in redundant mode).*
 - *At least a controller's ID has to be present on each channel bus.*

Setting a SCSI Channel's Primary ID - Drive Channel

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Channels," then press **ENT**.

```
View and Edit
SCSI Channels  ↓
```

Channel information will be displayed. Press **ENT** on the drive channel you wish the ID changed.

```
CH1=Drive  PID=7
SID=NA SXF=80.0M
```

Press **▼** or **▲** to select “Set SCSI Channel Pri. Ctlr ID..”, then press **ENT**.

```
Set SCSI Channel
Pri. Ctlr ID ..
```

Press **▼** or **▲** to select a new ID, then press **ENT** for two seconds to confirm.

```
Set Pri. Ctlr
ID= 7 to ID: 8 ?
```

Setting a SCSI Channel's Secondary ID - Drive Channel

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Channels," then press **ENT**.

```
View and Edit
SCSI Channels  ↓
```

Channel information will be displayed. Press **ENT** on the drive channel you wish the ID changed.

```
CH1=Drive  PID=7
SID=NA SXF=20.0M
```

Press **▼** or **▲** to select “Set SCSI Channel Sec. Ctlr ID..”, then press **ENT**.

```
Set SCSI Channel
Sec. Ctlr ID ..
```

Press **▼** or **▲** to select a new ID, then press **ENT** for two seconds to confirm.

```
Set Sec. Ctlr
ID=NA to ID: 9 ?
```

Setting Channel Bus Terminator

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Channels," then press **ENT**.

```
View and Edit
SCSI Channels  ↓
```

Channel information will be displayed. Press **▼** or **▲** to select a channel. Press **ENT** on a channel you wish the terminator mode changed.

```
CH0=Host  PID=0
SID=NA SXF=20.0M
```

Press **▼** or **▲** to select “Set SCSI Channel Terminator,” then press **ENT**.

```
Set SCSI Channel
Terminator ..
```

Its current status will be displayed on the LCD. Press **ENT** to continue.

```
SCSI Terminator
Enabled ..
```

Press **ENT** again for two seconds to change the terminator mode to the alternate setting.

```
CHL=0 Disable
Terminator      ?
```

IMPORTANT!

- *You can use terminator jumpers on the controller board to control SCSI bus termination of the SentinelRAID series controllers. When using jumpers to control, firmware termination setting must be disabled. To disable SCSI termination of a SCSI bus, the associated terminator jumpers must be left open, and firmware setting must be disabled.*
-

Setting Transfer Speed

Transfer speed refers to the SCSI bus speed in synchronous mode. Asynchronous mode is also available in this option setting. In Ultra/Ultra Wide SCSI, the maximum synchronous speed is 20.8Mhz.

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Channels," then press **ENT**.

```
View and Edit
SCSI Channels  ↓
```

Channel information will be displayed. Press **▼** or **▲** to select a channel. Press **ENT** on the channel you wish the transfer speed changed.

```
CH0=Host  PID=0
SID=NA  SXF=80.0M
```

Press **▼** or **▲** to select "Set Transfer Speed," then press **ENT**.

```
Set Transfer
Speed      ..
```

The current speed of this SCSI channel will be displayed. Press **▼** or **▲** to select the desired speed, then press **ENT** for two seconds to confirm.

```
CHL=0 Clk=80.0M
Change to=40.0M?
```

IMPORTANT!

- *Every time you change the Transfer Speed, you must reset the controller for the changes to take effect.*
-

Setting Transfer Width

The controller supports 8-bit SCSI and 16-bit SCSI. Enable "Wide Transfer" to use the 16-bit SCSI function. Disabling "Wide Transfer" will limit the channel transfer speed to 8-bit SCSI.

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Channels," then press **ENT**.

```
View and Edit
SCSI Channels  ⬆
```

Channel information will be displayed. Press **▼** or **▲** to browse through the channels. Press **ENT** on the channel you wish the transfer width changed.

```
CH0=Host  PID=0
SID=NA  SXF=20.0M
```

Press **▼** or **▲** to select "Set Transfer Width," then press **ENT**.

```
Set Transfer
Width      ..
```

The current mode will be displayed. Press **ENT** to continue.

```
Wide Transfer
Enabled     ..
```

Press **ENT** again for two seconds.

```
Disable
Wide Transfer  ?
```

IMPORTANT!

- *Every time you change the SCSI Transfer Width, you must reset the controller for the changes to take effect.*
-

Viewing and Editing SCSI Target - Drive Channel

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit SCSI Channels," then press **ENT**.

```
View and Edit
SCSI Channels  ⬆
```

SCSI channel information will be displayed on the LCD. Press **ENT** on the drive channel you wish the SCSI ID changed.

```
CH1=Drive  PID=7
SID=NA  SXF=20.0M
```

```
View and Edit
SCSI Target   ..
```

Press ▼ or ▲ to select “View and Edit SCSI Target,” then press **ENT**.

Press ▼ or ▲ to select a SCSI target, then press **ENT**.

```
SCSI Target
CHL=1 ID=0 ..
```

Slot Number

To set the Slot number of the SCSI target, choose “Slot Assignment,” then press **ENT**. The current slot number will be displayed.

```
Slot Assignment
Default No Set..
```

Press ▼ or ▲ to change the slot number, then press **ENT** for two seconds.

```
Slot Assignment
Set to # 9 ?
```

Maximum Synchronous Transfer Clock

Press ▼ or ▲ to select a SCSI target, then press **ENT**.

```
SCSI Target
CHL=1 ID=0 ..
```

To set the maximum synchronous clock of this SCSI target, choose “Max. Synchronous Xfer Clock,” then press **ENT**. The current clock setting will be displayed on the LCD.

```
Max Synchronous
Xfer Clock# 12..
```

Press ▼ or ▲ to change the clock, then press **ENT** for two seconds.

```
Period Factor
Def= 12 to __?
```

Maximum Transfer Width

Press ▼ or ▲ to select a SCSI target, then press **ENT**.

```
SCSI Target
CHL=1 ID=0 ..
```

To set the maximum transfer width of this SCSI target, choose “Max. Xfer Narrow Only” or “Max. Xfer Wide Supported,” then press **ENT**. The

```
Max Xfer Wide
Supported ..
```


current clock setting will be displayed on the LCD.

Press **ENT** for two seconds to change the setting.

```
Max Xfer Narrow
Only ?
```

Parity Check

Press ▼ or ▲ to select a SCSI target, then press **ENT**.

```
SCSI Target
CHL=1 ID=0 ..
```

Choose "Parity Check," then press **ENT**. The current clock setting will be displayed on the LCD.

```
Parity Check
Enabled ..
```

Press **ENT** for two seconds to change the setting.

```
Disable
Parity Checking?
```

Disconnecting Support

Press ▼ or ▲ to select a SCSI target, then press **ENT**.

```
SCSI Target
CHL=1 ID=0 ..
```

Choose "Disconnect Support," then press **ENT**. The current clock setting will be displayed on the LCD.

```
Disconnect
Support Enabled
```

Press **ENT** for two seconds to change the setting.

```
Disable Support
Disconnect ?
```

Maximum Tag Count

Press ▼ or ▲ to select a SCSI target, then press **ENT**.

```
SCSI Target
CHL=1 ID=0 ..
```

Choose "Max Tag Count," then press **ENT**. The current clock setting will be displayed on the LCD.

```
Max Tag Count:
Default( 32) ..
```

Press ▼ or ▲ to change the setting, then press **ENT** for two seconds to change the setting.

```
Tag Cur=32
Set to:Default ?
```

IMPORTANT!

- *Disabling the Maximum Tag Count will disable the internal cache of this SCSI drive..*
-

Restore to Default Setting

Press ▼ or ▲ to select a SCSI target, then press **ENT**.

```
SCSI Target
CHL=1 ID=0 ..
```

Choose "Restore to Default Setting," then press **ENT**.

```
Restore to
Default Setting.
```

Press **ENT** again for two seconds to restore the SCSI target's default settings.

```
Restore to
Default Setting?
```

5.13 System Functions

Choose “System Functions” in the main menu, then press ENT. Press ▼ or ▲ to select a submenu, then press ENT.

Mute Beeper

When the controller’s beeper has been activated, choose “Mute beeper,” then press ENT to turn the beeper off temporarily for the current event. The beeper will still activate on the next event.

A screenshot of a menu item labeled "Mute Beeper" with two dots to its right, indicating a submenu. The text is displayed in a monospaced font within a rectangular box.

Change Password

Use the controller’s password to protect the system from unauthorized entry. Once the controller’s password is set, regardless of whether the front panel, the RS-232C terminal interface or the RAIDWatch Manager is used, the user can only configure and monitor the RAID controller by providing the correct password.

IMPORTANT!

- *The controller requests a password whenever user is entering the main menu from the initial screen or a configuration change is made. If the controller is going to be left unattended, the “Password Validation Timeout” should be set to “Always Check.”*
 - *Controller password and controller name share a 16-character space. The maximum number of characters for controller password is 15. If 15 characters are used for a controller name, there will be only one character left for controller password and vice versa..*
-

Changing Password

To set or change the controller password, press ▼ or ▲ to select “Change Password,” then press ENT.

```
Change Password ..
```

If a password has previously been set, the controller will ask for the old password first. If password has not yet been set, the controller will directly ask for the new password. The password can not be replaced unless a correct old password is provided.

```
Old Password ..
```

Press ▼ or ▲ to select a character, then press ENT to move to the next space. After entering all the characters (alphabetic or numeric), press ENT for two seconds to confirm. If the password is correct, or there is no preset password, it will ask for the new password. Enter the password again to confirm.

```
Re-Ent Password ..
```

```
Change Password  
Successful
```

Disabling Password

To disable or delete the password, press ENT on the fist flashing digit for two seconds when requested to enter a new password. The existing password will be deleted. No password checking will occur when entering the Main Menu from the Initial screen or making configuration.

Reset Controller

To reset the controller without powering off the system, Press ▼ or ▲ to “Reset Controller,” then press ENT. Press ENT again for two seconds to confirm. The controller will now reset.

```
Reset This  
Controller ..
```

```
Reset This  
Controller ?
```

Shutdown Controller

Before powering off the controller, unwritten data may still reside in cache memory. Use the “Shutdown Controller” function to flush the cache content. Press ▼ or ▲ to “Shutdown Controller,” then press **ENT**. Press **ENT** again for two seconds to confirm.

```
Shutdown This  
Controller  ..
```

```
Shutdown This  
Controller  ?
```

The controller will now flush the cache memory. Press **ENT** for two seconds to confirm and reset the controller or power off the controller.

```
ShutdownComplete  
Reset Ctlr?
```

Controller Maintenance

For Controller Maintenance functions, please refer to Appendix C.

Saving NVRAM to Disks

You can choose to backup your controller-dependent configuration information to disk. We strongly recommend using this function to save configuration profile whenever a configuration change is made. The information will be distributed to every logical drive in the RAID system. If using the RAIDWatch manager, you can save your configuration data as a file to a computer system drive.

A RAID configuration of drives must exist for the controller to write NVRAM content onto it.

From the main menu, choose “System Functions.” Use arrow keys to scroll down and select “Controller Maintenance,” “Save NVRAM to Disks,” then press **ENT**. Press **ENT** for two seconds on the message prompt, “Save NVRAM to Disks?”.

```
Controller  
Maintenance  ..
```

```
Save NVRAM  
To Disks    ?
```

A prompt will inform you that NVRAM information has been successfully saved.

Restore NVRAM from Disks

Once you want to restore your NVRAM information from what you previously saved onto disk, use this function to restore the configuration setting.

From the main menu, choose “System Functions.” Use arrow keys to scroll down and select “Controller Maintenance,” “Restore NVRAM from Disks..” and then press **ENT**. Press **ENT** for two seconds to confirm.

```
Restore NVRAM
from Disks    ?
```

A prompt will inform you the controller NVRAM data has been successfully restored from disks.

Adjust LCD Contrast

The controller LCD contrast is set at the factory to a level that should be generally acceptable. The controller comes equipped with a LCD contrast adjustment circuit just in case the factory-preset level is not optimal allowing the contrast to be adjusted either via the RS-232 Terminal Emulation Menus or by the LCD User Interface.

From the main menu, choose “View and Edit Peripheral Dev.” Press **ENT** on it and use arrow keys to scroll down and select “Adjust LCD Contrast,” press **ENT** to proceed, and then use arrow keys to find an optimal setting. Press **ESC** to return to the previous menu.

```
View and Edit
Peripheral Dev ↑
```

```
Adjust LCD
Contrast    ..
```

```
LCD Contrast :
■■■■■|-----
```

5.14 Controller Parameters

Controller Name

Select “View and Edit Config Parm” from the main menu. Choose “View and Edit Configuration parameters,” “Controller Parameters,” then press **ENT**. The current name will be displayed. Press **ENT** for two seconds and enter the new controller name by using **▼** or **▲**. Press **ENT** to move to another character and then press **ENT** for two seconds on the last digit of controller name to complete the process.

```
Controller Name:  
- - - -
```

```
Enter Ctlr Name:
```

LCD Title Display Controller Name

Choose “View and Edit Configuration parameters,” “Controller Parameters,” then press **ENT**. Use **▼** or **▲** to choose to display the embedded controller logo or any given name on the LCD initial screen.

```
LCD Title Disp -  
Controller Logo?
```

```
LCD Title Disp -  
Controller Name?
```

Password Validation Timeout

Choose “View and Edit Configuration parameters,” “Controller Parameters,” then press **ENT**. Select “Password Validation Timeout,” and press **ENT**. Press **▼** or **▲** to choose to enable a validation timeout from one to five minutes to always check. The always check timeout will disable any configuration change without entering the correct password.

```
PasswdValidation  
Timeout-5 mins..
```

Controller Unique Identifier

Choose “View and Edit Configuration parameters,” “Controller Parameters,” then press **ENT**. Press **▼** or **▲** to select “Ctlr Unique ID-,” then press **ENT**. Enter any hex number between “0” and “FFFFF” and press **ENT** to proceed.

```
Ctlr Unique  
ID-
```

Enter a unique ID for any RAID controller no matter it is configured in a single or dual-controller configuration. The unique ID is recognized by the controller as the following:


1. A controller-specific identifier that helps controllers to identify its counterpart in a dual-active configuration.
2. The unique ID is combined to generate a unique WWN node name for controllers or RAID systems using Fibre channel host ports. The unique node name helps to prevent host computers from mis-addressing the storage system during the controller failback/failover processes.
3. MAC addresses for the controller's Ethernet port that should be taken over by a surviving controller in the event of controller failure.

Controller Date and Time


This submenu is only available for controllers or subsystems that come with a real-time clock on board.

Time Zone


Choose "View and Edit Configuration parameters," "Controller Parameters," then press **ENT**. Press **▼** or **▲** to scroll down and select "Set Controller Date and Time", then press **ENT**.



View and Edit
Config Parm's



Controller
Parameters ..



Set Controller
Date and Time ..


The controller uses GMT (Greenwich Mean Time), a 24-hours clock. To change the clock to your local time zone, enter the hours later than the Greenwich mean time following a plus (+) sign. For example, enter "+9" for Japanese time zone.

Choose "Time Zone" by pressing **ENT**.

Use the **▲** key to enter the plus sign and the **▼** key to enter numeric representatives.




Time Zone ..



GMT +08:00
-

Date and Time

Use your arrow keys to scroll down and select "Date and Time" by pressing **ENT**.



Date and Time ..

Use your arrow keys to select and enter the numeric representatives in the following order: month, day, hour, minute, and the year.

[MMDDh:mm[YYYY]]

5.15 SCSI Drive Utilities

From the “View and Edit SCSI Drives” menu, select the drive that the utility is to be performed on; then press **ENT**. Select “SCSI Drive Utilities; then press **ENT**. Choose either “SCSI Drive Low-level Format” or “Read/Write Test”.

These options are not available for drives already configured in a logical configuration, and can only be performed before a reserved space is created on drive.

```
View and Edit
SCSI Drives
```

```
C=1 I=1 8683MB
NEW DRV SEAGATE
```

```
SCSI Drives
Utilities ..
```

```
Drive Read/Write
Test ..
```

SCSI Drive Low-level Format

Choose “SCSI Drive Low-level Format” and confirm by selecting **Yes**.

```
Drive Low-Level
Format ..
```

IMPORTANT!

- *Do not switch the controller's and/or disk drive's power off during the Drive Low-level Format. If any power failure occurs during a drive low-level format, the formatting must be started over again when power resumes.*
 - *All of the data stored in the disk drive will be destroyed during a low-level format.*
 - *The disk drive on which a low-level disk format will be performed cannot be a spare drive (local or global) nor a member drive of a logical drive. The "SCSI Drive Low-level Format" option will not appear if the drive's status is not stated as a "New Drive" or a "Used Drive".*
-

SCSI Drive Read/Write Test

From the "View and Edit SCSI Drives" menu, select a new or used drive that the utility is to be performed on; then press **ENT**. Select "SCSI Drive Utilities;" then press **ENT**. Choose "Read/Write Test" and press **ENT**.

Press ▼ or ▲ to select and choose to enable/disable the following options:

1. "Auto Reassign Bad Block;
2. Abort When Error Occurs;
3. Drive Test for - Read Only/Read and Write.

When finished with configuration, select "Execute Drive Testing" and press **ENT** to proceed.

The Read/Write test progress will be indicated as a percentage.

You may press **ESC** and select "Read/Write Test" later and press ▼ or ▲ to select to "View Read/Write Testing Progress" or to "List Current Bad Block Table." If you want to stop testing the drive, select "Abort Drive Testing" and press **ENT** to proceed.

```
Drive Read/Write
Test                ..
```

```
Auto Reassign
Disabled           ..
```

```
Abort When Error
Occur-Enabled
```

```
Drive Test for
Read and Write..
```

```
Execute Drive
Testing           ..
```

```
Drv Testing  23%
Please Wait !
```


```
View Read/Write
Test Progress ..
```

```
List Current
Bad Block Table.
```

```
Abort Read/Write
Testing         ..
```

Terminal Screen Messages

6.1 The Initial Screen



Cursor Bar:	Move the cursor bar to a desired item, then press [ENTER] to select
Controller Name:	Identifies type of controller or a preset name
Transfer Rate Indicator	Indicates the current data transfer rate
Gauge Range:	Use + or - keys to change the gauge range in order to view the transfer rate indicator
Cache Status:	Indicates current cache status
Write Policy	Indicates current write-caching policy
Date & Time:	Current system date and time, generated by controller real time clock
PC Graphic (ANSI Mode):	Enters the Main Menu and operates in ANSI mode
Terminal (VT-100 Mode):	Enters the Main Menu and operates in VT-100 mode
PC Graphic (ANSI+Color Mode):	Enters the Main Menu and operates in ANSI color mode
Show Transfer Rate+Show Cache Status:	Press [ENTER] on this item to show the cache status and transfer rate

6.2 Main Menu

```
i0:47% i1:0%                               Cache Status: Clean
                                                Write Cache: Enable
                                                BAT:BAD
< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
view and edit Peripheral devices
system Functions
view system Information
view and edit Event logs

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen
```

Use the arrow keys to move the cursor bar through the menu items, then press **[ENTER]** to choose a menu, or **[ESC]** to return to the previous menu/screen.

In a subsystem or controller head where battery status can be detected, battery status will be displayed at the top center. Status will be stated as Good, Bad, or several “+” (plus) signs will be used to indicate battery charge. A battery fully-charged will be indicated by five plus signs.

When initializing or scanning an array, the controller displays progress percentage on the upper left corner of the configuration screen. “i” indicates array initialization. “s” stands for scanning process. The following number indicates logical drive number.

6.3 Quick Installation

```
< Main Menu >
Quick installation
v
v Create Logical Drive ? s
v es
v Yes No
v
v view and edit Configuration parameters
v view and edit Peripheral devices
v system Functions
v view system Information
v view and edit Event logs
```

Type **Q** or use the **↑ ↓** keys to select "Quick installation", then press **[ENTER]**. Choose **Yes** to create a logical drive.

All possible RAID levels will be displayed. Use the **↑ ↓** keys to select a RAID level, then press **[ENTER]**. The assigned spare drive will be a Local Spare Drive, not a Global Spare Drive.

The controller will start initialization and automatically map the logical drive to LUN 0 of the first host channel.

6.4 Logical Drive Status

LG	ID	LV	RAID	Size(MB)	Status	1	2	3	O	C	#LN	#SB	#FL	NAME
00	00000000	00000000	0000	0000	GOOD						0	0	0	
1			NONE											
2			NONE											
3			NONE											
4			NONE											
5			NONE											
6			NONE											
7			NONE											

LG	Logical Drive number
	P0: Logical Drive 0 managed by the Primary Controller
	S0: Logical Drive 0 managed by the Secondary Controller
LV	The Logical volume to which this logical drive belongs
ID	Controller-generated unique ID
RAID	RAID level
SIZE (MB)	Capacity of the Logical Drive
Size(MB)	Capacity of the Logical Drive
Status 1	Logical Drive Status – Column 1
	GOOD The logical drive is in good condition
	DRV FAILED A drive member failed in the logical drive
	CREATING Logical drive is being initiated
	DRV ABSENT One of its member drives cannot be detected
	INCOMPLETE Two or more drives failed in the logical drive
Status 2	Logical Drive Status – Column 2
	I Initializing drives
	A Adding drive(s)
	E Expanding logical drive
Status 3	Logical Drive Status – Column 3
	R Rebuilding the logical drive
	P Regenerating array parity
Column O	Logical Drive Status – Stripe size
	N/A Default
	2 4KB 6 64KB
	3 8KB 7 128KB
	4 16KB 8 256KB
	5 32KB
Column C	Logical Drive Status – Write Policy setting
	B Write-back

T	Write-through
#LN	Total drive members in the logical drive
#SB	Standby drives available for the logical drive. This includes all the spare drives (local spare, global spare) available for the specific logical drive
#FL	Number of Failed member(s) in the logical drive
Name	Logical drive name (user configurable)

6.5 Logical Volume Status

Q	LV	ID	Size(MB)	#LD	s
v	0	46665C8D	60000	1	es
v	1				
v	2				
v	3				
s	4				
v	5				
v	6				
v	7				

parameters
vices

Cache Status: Clean

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

LV	Logical Volume number. P0: Logical Volume 0 managed by the Primary Controller S0: Logical Volume 0 managed by the Secondary Controller
ID	Logical Volume ID number (controller randomly generated)
Size(MB)	Capacity of the Logical Volume
#LD	The number of Logical Drive(s) included in this Logical Volume

6.6 SCSI Drive Status

```

Sun Jan 6 03:03:40 2002 Cache Status: Clean

```

< Main Menu >

quick installation
 view and edit logical drives
 view and edit logical volumes
 view and edit host luns
view and edit scsi Drives

view	Slot	Chl	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
view	S	2<3>	18	17560	200MB	0	ON-LINE	SEAGATE ST318304FC
view		2<3>	19	17560	200MB	0	ON-LINE	SEAGATE ST318304FC

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Slot	Slot number of the drive; “S” indicates this is the drive used for passing through SES signals
Chl	The drive channel where the drive is connected “X<Y>” indicates two channels are configured in a dual-loop
ID	The channel ID assigned to this drive
Size (MB)	Drive capacity
Speed	XxMB Maximum transfer rate of drive channel interface Async The drive is using asynchronous mode.
LG_DRV	X The drive is a drive member of logical drive “X.” If the Status column shows “STAND-BY”, the drive is a Local Spare of logical drive x.
Status	Global The SCSI drive is a Global Spare Drive
INITING	Processing array initialization
ON-LINE	The drive is in good condition
REBUILD	Processing Rebuild
STAND-BY	Local Spare Drive or Global Spare Drive. The Local Spare Drive’s LG_DRV column will show the logical drive number. The Global Spare Drive’s LG_DRV column will show “Global”.
NEW DRV	A new drive has not been configured to any logical drive or as a spare drive
USED DRV	An used drive that is not a member of any logical drive or configured as spare
BAD	Failed drive
ABSENT	Drive does not exist
MISSING	Drive once existed, but is missing now
SB-MISS	Spare drive missing
Vendor and Product ID	The vendor and product model information of the drive

6.7 SCSI Channel's Status

Cache Status: Clean									
Chl	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
0	RCCom								
1	Host	*	NA	20.0MHz	Wide	S	On	Async	Narrow
2	Drive	7	NA	20.0MHz	Wide	S	On	Async	Wide
3	Drive	7	NA	20.0MHz	Wide	S	On	Async	Narrow
4	Drive	7	NA	20.0MHz	Wide	S	On	Async	Narrow
5	Drive	7	NA	20.0MHz	Wide	S	On	Async	Narrow
6	Drive	119	NA	1 GHz	Serial	F	NA		
7	Drive	119	NA	1 GHz	Serial	F	NA		

Arrow Keys: Move Cursor | Enter: Select | Esc: Exit | Ctrl+L: Refresh Screen

Chl	SCSI channel number
Mode	Channel mode
	RCCom Redundant controller communication channel
	Host Host Channel mode
	Drive Drive Channel mode
PID	IDs managed by the Primary Controller
	* Multiple IDs were applied (Host Channel mode only)
	(ID number) Host channel:
	Specific IDs managed by the Primary Controller for host LUN mapping
	Drive channel:
	Specific ID reserved for the channel processor on the Primary controller
SID	IDs managed by the Secondary Controller
	* Multiple IDs were applied (Host Channel mode only)
	(ID number) Host channel:
	Specific IDs managed by the Secondary Controller for host LUN mapping
	Drive channel:
	Specific ID reserved for the channel processor on the Secondary controller; used in redundant controller mode
	NA No SCSI ID applied
DefSynClk	Default SCSI bus synchronous clock:
	??M The default setting of the channel is ??? MHz in Synchronous mode.
	Async. The default setting of the channel is Asynchronous mode.
DefWid	Default SCSI Bus Width:
	Wide 16-bit SCSI
	Narrow 8-bit SCSI
S	Signal:
	S Single-ended
	L LVD
	F Fibre

Term	Terminator Status:	
	On	Terminator is enabled.
	Off	Terminator is disabled.
	Diff	The channel is a Differential channel. The terminator can only be installed/removed physically.
CurSynClk	Current SCSI bus synchronous clock:	
	??M	The default setting of the SCSI channel is ??? MHz in Synchronous mode.
	Async.	The default setting of the SCSI channel is Asynchronous mode.
	<i>(empty)</i>	The default SCSI bus synchronous clock has changed. Reset the controller for the changes to take effect.
CurWid	Current SCSI Bus Width:	
	Wide	16-bit SCSI
	Narrow	8-bit SCSI
	<i>(empty)</i>	The default SCSI bus width has changed. Reset the controller for the changes to take effect.

6.8 Controller Voltage and Temperature

Controller voltage and temperature monitoring

```
Cache Status: Clean
e Cache: Enable

< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
view and edit Peripheral devices
View Peripheral Device Status
Set Peripheral Device Entry
Define Peripheral Device Active Signal
Adjust LCD Contrast
Controller Peripheral Device Configuration
View Peripheral Device Status
Voltage and Temperature Parameters

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen
```

Choose from main menu “View and Edit Peripheral Devices,” and press [ENTER]. From the submenu, choose “Controller Peripheral Device Configuration,” “View Peripheral Device Status”, then press [ENTER].

```
Cache Status: Clean
e Cache: Enable

< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
view and edit Peripheral devices
View Peripheral Device Status
Set Peripheral Device Entry
Define Peripheral Device Active Signal
Adjust LCD Contrast
Controller Peripheral Device Configuration
View Peripheral Device Status
Voltage and Temperature Parameters

ITEM VALUE STATUS
+3.3V 3.384V Operation Normally
+5V 5.260V Operation Normally
+12V 12.868V Operation Normally
CPU Temperature 32.0 (C) Temperature within Safe Range
Board1 Temperature 45.5 (C) Temperature within Safe Range
Board2 Temperature 43.0 (C) Temperature within Safe Range

View Peripheral Device Status
Voltage and Temperature Parameters

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen
```

The current specimens of voltage and temperature detected by the controller will be displayed on screen and will be stated as normal or out of order.

6.9 Viewing Event Logs on the Screen

There may be a chance when errors occur and you may want to trace down the record to see what has happened to your system. The controller's event log management will record all the events from power on, it can record up to 1,000 events. Powering off or resetting the controller will cause an automatic deletion of all the recorded event logs. To view the events logs on screen, choose from main menu "view and edit Event logs" by pressing [ENTER].

```
Cache Status: Clean
< Main Menu >
view installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
view and edit Peripheral devices
system functions
view system Information
view and edit Event logs
Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen
```

The controller can store up to 1000 event logs for use in modifying the configuration with reference to the present time shown on the upper left of the configuration screen and the time when the events occurred.

```
Thu Jun 19 15:11:32 2003 Cache Status: Clean
Event Logs
[2186] Parity Regeneration of Logical Drive 0 Completed
<Thu Jun 19 15:08:48 2003>
[2544]LG:0 NOTICE:Media Error During Check Parity Block 00000520 Recovered
<Thu Jun 19 15:08:38 2003>
[2344]LG:0 NOTICE:Media Error Encountered During Check Parity Block 0000052
<Thu Jun 19 15:08:38 2003>
[1113] Slot9 Drive ALERT: Bad Block Encountered - 0x220
<Thu Jun 19 15:08:30 2003>
[2344]LG:0 NOTICE:Media Error Encountered During Check Parity Block 00000022
<Thu Jun 19 15:08:22 2003>
[1113] Slot9 Drive ALERT: Bad Block Encountered - 0x120
<Thu Jun 19 15:08:14 2003>
[2185] LG:0 Logical Drive NOTICE: Starting Parity Regeneration
<Thu Jun 19 15:08:07 2003>
[2182] On-Line Initialization of Logical Drive 0 Completed
<Thu Jun 19 15:07:37 2003>
Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen
```

The "P" or "S" icon on the right indicates which one of the controllers (Primary or Secondary) issued an event in a dual-controller configuration.

To clear the saved event logs, scroll the cursor down to the last event and press [ENTER].

```
Clear Above 8 Event Logs ?
  Yes  no
```

Choose **Yes** to clear the recorded event logs.


Terminal Operation

7.1 Power on RAID Enclosure

Hardware installation should be completed before powering on your RAID enclosure. Drives must be configured and the controller properly initialized before host computer can access the storage capacity. The configuration and administration utility resides in controller's firmware.

Open the initial terminal screen: use arrow keys to move cursor bar through menu items, then press **[ENTER]** to choose the terminal emulation mode, and **[ESC]** to return to the previous menu/screen.

```
Wed Jun 26 17:11:34 2002                               Cache Status: Clean
                                                         Write Cache: Enable
```



The screenshot shows a terminal window with a progress bar at the top. The progress bar is labeled '0' on the left and '10MB/S' on the right. Below the bar is a scale from 0 to 100 in increments of 10. The progress bar is filled with a black bar that extends to approximately the 25 mark on the scale.

```

PC Graphic(ANSI Mode)
Terminal(V100 Mode)
PC Graphic(ANSI+Color Mode)
Show Transfer Rate+Show Cache Status
```

```
Arrow Keys:Move Cursor|+ & -:Rate Range|Enter:Main Menu|Ctrl+L:Refresh Screen
```

7.2 Caching Parameters

Optimization Modes

Mass storage applications can be roughly categorized into two as database and video/imaging, according to its read/write characteristics. To optimize the controller for these two categories, the controller has two embedded optimization modes with controller behaviors adjusted to different read/write parameters. They are the “Optimization for Random I/O” and the “Optimization for Sequential I/O.”

Limitations:

There are limitations on the use of optimization modes.

1. You can select the stripe size of each array (logical drive) during the initial configuration. However, changing stripe size is only recommended for experienced engineers who have tested the effects tuning stripe sizes for different applications.
2. The array stripe size can only be changed during the initial configuration process.
3. Once the controller optimization mode is applied, access to different logical drives in a RAID system will follow the same optimized pattern. You can change the optimization mode later without having to re-organize your array.

Database and Transaction-based Applications:

This kind of applications usually include SQL server, Oracle server, Informix, or other data base services. These applications keep the size of each transaction down to the minimum, so that I/Os can be rapidly processed. Due to its transaction-based nature, these applications do not read or write a bunch of data in a sequential order. Access to data occurs randomly. The transaction size usually ranges from 2K to 4K. Transaction performance is measured in “I/Os per second” or “IOPS.”

Video Recording/Playback and Imaging Applications:

This kind of applications usually includes video playback, video post-production editing, or other applications of the similar nature. These applications have the tendency to read or write large files from and into storage in a sequential order. The size of each I/O can be 128K, 256K, 512K, or up to 1MB. The efficiency of these applications is measured in “MB/Sec.”

When an array works with applications such as video or image oriented applications, the application reads/writes from the drive as large-block, sequential threads instead of small and randomly accessed files.

The controller optimization modes have read-ahead buffer and other R/W characteristics tuned to obtain the best performance for these two major application categories.

Optimization Mode and Stripe Size


Each controller optimization mode has preset values for the stripe size of arrays created in different RAID levels. If you want a different value for your array, you may change the controller optimization mode, reset the controller, and then go back to create the array. Once the array is created, stripe size can not be changed.

Using the default value should be sufficient for most applications.

Table 7 - 1 RAID Levels, Optimization Modes, and Stripe Sizes


	Opt. for Sequential I/O	Opt. for Random I/O
RAID0	128	32
RAID1	128	32
RAID3	16	4
RAID5	128	32

Optimization for Random or Sequential I/O



Choose “Optimization for Random I/O” or “Optimization for Sequential I/O,” then press **[ENTER]**. The “Random” or “Sequential” dialog box will appear, depending on the option you have selected. Choose **Yes** in the dialog box that follows to confirm the setting.

Write-Back/Write-Through Cache Enable/Disable



Choose “Caching Parameters”, then press **[ENTER]**. Select “Write-Back Cache,” then press **[ENTER]**. “Enabled” or “Disabled” will display the current setting with the Write-Back caching. Choose **Yes** in the dialog box that follows to confirm the setting.

The Write-through mode is safer if your controller is not configured in a redundant pair and there is no battery backup.

Write-back caching can dramatically improve write performance by caching the unfinished writes in memory and let them be committed to drives in a more efficient manner. In the event of power failure, a battery module can hold cached data for days. In the event of controller failure, data cached in the failed controller has an exact replica on its counterpart controller and therefore remains intact.

IMPORTANT!

- *The original 512GB threshold on array optimization mode is canceled. If the size of an array is larger than 16TB, only the optimization for sequential I/O can be applied. Logical drives of this size are not practical; therefore, there is actually no limitation on the optimization mode and array capacity.*
- *Every time you change the Caching Parameters, you must reset the controller for the changes to take effect.*
- *In the redundant controller configuration, write-back will only be applicable when there is a synchronized cache channel between partner controllers.*

7.3 Viewing the Connected Drives

Prior to configuring disk drives into a logical drive, it is necessary to understand the status of physical drives in your enclosure.

Cache Status: Clean								
	Slot	Ch1	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
Quick view		2	0	2010	20MB	NONE	NEW DRV	
view		2	1	2010	20MB	NONE	NEW DRV	
view		2	2	2010	20MB	NONE	NEW DRV	
view		2	3	2010	20MB	NONE	NEW DRV	
view		2	4	2010	20MB	NONE	NEW DRV	
view		2	5	2010	20MB	NONE	NEW DRV	
view		2	6	2010	20MB	NONE	NEW DRV	
view		2	8	2010	20MB	NONE	NEW DRV	

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Use arrow keys to scroll down to “View and Edit SCSI Drives.” This will display information of all the physical drives installed.

Drives will be listed in the table of “View and Edit SCSI Drives.” Use arrow keys to scroll the table. You may first examine whether there is any drive installed but not listed here. If there is a drive installed but not listed, the drive may be defective or not installed correctly, please contact your RAID supplier.

IMPORTANT!

- *Drives of the same brand/model/capacity might not have the same block number.*
- *The basic read/write unit of a hard drive is block. If members of a logical drive have different block numbers (capacity), the smallest block number will be taken as the maximum capacity to be used in every drive. Therefore, use drives of the same capacity.*
- *You may assign a Local/Global Spare Drive to a logical drive whose members has a block number equal or smaller than the Local/Global Spare Drive but you should not do the reverse.*

7.4 Creating a Logical Drive

Browse through the main menu and select “View and Edit Logical Drive.”

LG	ID	LV	RAID	Size(MB)	Status	1	2	3	0	C	#LN	#SB	#FL	NAME
0			NONE											
1			NONE											
2			NONE											
3			NONE											
4			NONE											
5			NONE											
6			NONE											
7			NONE											

Cache Status: Clean
Write Cache: Enable

Arrow Keys: Move Cursor | Enter: Select | Esc: Exit | Ctrl+L: Refresh Screen

For the first logical drive on RAID, simply choose LG 0 and press **[ENTER]** to proceed. You may create as many as 128 logical drives from drives on any drive channel.

When prompted to “Create Logical Drive?,” select **Yes** and press **[ENTER]** to proceed.

Create Logical Drive ?	
Yes	No

Choosing a RAID Level:

A pull-down list of supported RAID levels will appear. In this chapter, RAID 5 will be used to demonstrate the configuration process. Choose a RAID level for this logical drive.



Choosing Member Drives:


Choose your member drive(s) from the list of available physical drives. The drives can be tagged for inclusion by positioning the cursor bar on the drive and then pressing [ENTER]. An asterisk (*) mark will appear on the selected physical drive(s). To deselect the drive, press [ENTER] again on the selected drive. The "*" mark will disappear. Use ↑↓ keys to select more drives.

Cache Status: Clean
Write Cache: Enable
3 of 8 Selected

LG	Slot	Chl	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
0	*	1	0	9999	80MB	NONE	NEW DRV	
1	*	1	1	9999	80MB	NONE	NEW DRV	
2	*	1	2	9999	80MB	NONE	NEW DRV	
3		1	3	9999	80MB	NONE	NEW DRV	
4		1	4	9999	80MB	NONE	NEW DRV	
5		1	5	9999	80MB	NONE	NEW DRV	
6		1	6	9999	80MB	NONE	NEW DRV	
7		1	8	9999	80MB	NONE	NEW DRV	


Arrow Keys: Move Cursor | Enter: Select | Esc: Confirm | Ctrl+L: Refresh Screen

Logical Drive Preferences:



After all member drives have been selected, press ESC to continue with the next option. A list of array options is displayed.

Maximum Drive Capacity:



As a rule, a logical drive should be composed of drives of the same capacity. A logical drive can only use the capacity of each drive up to the maximum capacity of the smallest drive.

Assign Spare Drives:

```
Maximum Drive Capacity : 9999MB
Assign Spare Drives
Slot Chl ID Size(MB) Speed LG_DRV Status Vendor and Product ID
1 4 9999 40MB NONE NEW DRV
1 5 9999 40MB NONE NEW DRV
1 6 9999 40MB NONE NEW DRV
1 8 9999 40MB NONE NEW DRV
```

You can add a spare drive from the list of the unused drives. The spare chosen here is a Local spare and will automatically replace any failed drive in the event of drive failure. The controller will then rebuild data onto the replacement drive.

A logical drive composed in a none-redundancy RAID level (NRAID or RAID 0) does not support spare drive rebuild.

Disk Reserved Space

```
Maximum Drive Capacity : 244MB
Assign Spare Drives
Disk Reserved Space: 256 MB
256MB
Backward Compatible(64KB) ck)
```

The reserved space is a small section of disk space formatted for storing array configuration and RAIDWatch program. Do not change the size of reserved space unless you want your array to be accessed by controllers using older firmware.

Logical Drive Assignments:

```
Maximum Drive Capacity : 9999MB
Assign Spare Drives
Disk Reserved Space: 256 MB
Logical Drive Assignments
Redundant Controller Logical Drive Assign to Secondary Controller ?
Yes No
```


If you use two controllers for a dual-active configuration, a logical drive can be assigned to either of the controllers to balance workload. The default is primary controller, press **[ESC]** if change is not preferred. Logical drive assignment can be changed any time later.

Write Policy

```
Maximum Drive Capacity : 9999MB
Assign Spare Drives
Disk Reserved Space: 256 MB
Logical Drive Assignments
Write Policy: Default(Write-Back)
Change Write Policy ?
Default Write-Back Write-Through
```


This sub-menu allows you to set the caching mode for this specific logical drive. "Default" is a neutral value that is coordinated with the controller's current caching mode setting, that you can see bracketed in the write policy status.

Initialization Mode



This sub-menu allows you to set if the logical drive is immediately available. If the online (default) mode is used, data can be written onto it and you may continue with array configuration, e.g., including the array into a logical volume, before the array's initialization is completed.


Stripe Size



This option should only be changed by experienced engineers. Setting to an incongruous value can severely drag the performance. This option should only be changed when you can be sure of the performance gains it might bring you.

The default value is determined by controller Optimization Mode setting and the RAID level used for the array.


Press **[ESC]** to continue when all the preferences have been set.




A confirm box will appear on the screen. Verify all information in the box before choosing **"Yes"** to confirm and proceed.





If online initialization mode is applied, logical drive will first be created and the controller will find appropriate time to initialize the array.




7.5 Creating a Logical Volume



A logical volume consists of one or several logical drives. Choose “View and Edit logical volumes” in the main menu. The current logical volume configuration and status will be displayed on the screen. Choose a logical volume number (0-7) that has not yet been defined, then press **[ENTER]** to proceed. A prompt “Create Logical Volume?” will appear. Select “**Yes**” and press **[ENTER]**.



Select one or more logical drive(s) available on the list. The same as creating a logical drive, the logical drive(s) can be tagged for inclusion by positioning the cursor bar on the desired drive and then press **[ENTER]** to select. An asterisk (*) mark will appear on the selected drive. Press **[ENTER]** again will deselect a logical drive.



Use arrow keys to select a sub-menu and make change to the initialization mode, write policy, or the managing controller.

Logical volumes can be assigned to different controllers (primary or secondary). Default is primary.

```

Logical Drive Count      : 2
Logical Volume Assignment : Primary Controller
Write Policy            : Write-Through
Initial Mode            : On-Line

                Create Logical Volume ?
                Yes                No
  
```

Note that if a logical volume is manually assigned to a specific controller, all its members' assignment will also be shifted to that controller.

As all the member logical drives are selected, press **[ESC]** to continue. The confirm box displays. Choose **Yes** to create the logical volume.

Q	LV	ID	Size(MB)	#LD	
v	P0	2D99C36B	59956	2	
v	1				
v	2				
v	3				
s	4				
v	5				
	6				
	7				

1	View logical drive	
2	Delete logical volume	
3	Partition logical volume	ters
4	Logical volume Assignments	
5	Expand logical volume	
6	Write Policy	
7	add Logical drive	

Press **[ENTER]** and the information of the created logical volume displays.

- LV:** Logical Volume ID
- P0:** Logical Volume 0 managed by the primary controller
- S0:** Logical Volume 0 managed by the secondary controller
- ID:** Unique ID for the logical volume, randomly generated by the controller
- Size:** Capacity of this volume
- #LD:** Number of the included members

7.6 Partitioning a Logical Drive/Logical Volume

The process of partitioning a logical drive is the same as that of partitioning a logical volume. We take the partitioning of a logical volume for an example in the preceding discussion.

Please note that partitioning can be very useful when dealing with a very large capacity but partitioning a logical drive or logical volume is not a must for RAID configuration.

Q	LV	ID	Size(MB)	#LD
v	P0	20990363	59956	2
v	1			
v	2			
v	3			
s	4			
v	5			
v	6			
v	7			

- 1 View logical drive
- 2 Delete logical volume
- 3 Partition logical volume
- 4 Logical volume Assignments
- 5 Expand logical volume
- 6 Write Policy
- 7 add Logical drive

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Choose the logical volume you wish to partition, then press [ENTER]. Choose "Partition logical volume", then press [ENTER]. Select from the list of undefined partitions and Press [ENTER].

A list of partitions displays. If the logical volume has not yet been partitioned, all volume capacity will list as "partition 0."

Q	LV	ID	Size(MB)	#LD	Partition	Offset(MB)	Size(MB)
v	P0	20990363	59956	2	0	0	59956
v	1						
v	2						
v	3						
v	4						
v	5						
v	6						
v	7						

Partition Size (MB): 59956 _

3		
4		
5		
6		
7		

Press [ENTER] and type the desired size for the selected partition, and then press [ENTER] to proceed. The remaining size will be automatically allotted to the next partition.

Choose **Yes** to confirm when prompted to the "Partition Logical Volume?" message. Press [ENTER] to confirm. Follow the same procedure to partition the remaining capacity of your logical volume.


Q	LV	ID	Size(MB)	#LD	Partition	Offset(MB)	Size(MB)
v	P0	20990363	59956	2	0	0	59956
v	1						
v	2						
v	3						
v	4						
v	5						
v	6						
v	7						

This operation will result in the LOSS OF ALL DATA on the Partition !
Partition Logical Volume ?
Yes No

When a partition of a logical drive/logical volume is deleted, the capacity of the deleted partition will be added to the last partition.

WARNING!

- As long as a partition has been changed, it is necessary to re-configure all host LUN mappings. All data in it will be lost and all the host LUN mappings will be removed with any change to partition capacity.



1. A list of LUN entries and their respective mappings will be displayed. To map a host LUN to a logical volume's partition, select an available LUN entry (one not mapped yet) by moving the cursor bar to the LUN, then press **[ENTER]**.
2. A list of available logical volumes displays. Move the cursor bar to the desired logical unit, then press **[ENTER]**.
3. A list of available partitions will prompt. Move cursor bar to the desired partition, then press **[ENTER]**. If you have not partitioned the logical volume, the whole capacity will be displayed as one logical partition.
4. When prompted to "Map Host LUN," press **[ENTER]** to proceed. For access control over Fibre network, find in Chapter 8 details about "Create Host Filter Entry."
5. When prompted to "Map Logical Volume?," select **Yes** to continue.

A prompt will display the mapping you wish to create. Choose **Yes** to confirm the LUN mapping you selected.

LUN	LV/LD	DRV	Partition	Size(MB)	RAID
0					
	Map	Logical Volume:	0		
	To	Partition	: 0		
		Channel	: 0		
		ID	: 0		
		Lun	: 0 ?		
		Yes	No		
5					
6					
7					

The detail in the confirm box reads: partition 0 of logical volume 0 will map to LUN 0 of SCSI ID 0 on host channel 0.

Continue to map other partitions to host LUNs.

With any of the Host ID/LUN successfully associated with a logical capacity, the "No Host LUN" message in the LCD screen will change to "Ready."

If your controller has not been configured with a host channel and assigned with SCSI ID, please move on to section 7.12 Viewing and Editing SCSI Channels."

7.8 Assigning Spare Drive, Rebuild Settings

Adding Local Spare Drive

A spare drive is a standby drive automatically initiated by controller firmware to replace a failed drive. A spare drive must have an equal or larger capacity than the array members. A local spare should have a capacity equal or larger than the members of the logical drive it is assigned to. A global spare should have a capacity equal or larger than all physical drives in a RAID system.



1. Choose “View and Edit SCSI Drives” on the main menu, press **[ENTER]**. Move the cursor bar to a SCSI drive that is not assigned to a logical drive or as a spare drive (usually indicated as a “New Drive”), and then press **[ENTER]**.
2. Choose “Add Local Spare Drive” and press **[ENTER]**. A list of logical drives displays.
3. Move the cursor bar to a logical drive, then press **[ENTER]**. The unassigned SCSI drive will be associated with to this logical drive as a Local Spare.
4. When prompted to “Add Local Spare Drive?”, choose **Yes** to confirm.

Adding a Global Spare Drive


A global spare replaces the failed drive in any logical drive of a RAID system.



Move cursor bar to the SCSI drive that is not a member drive or a spare (usually indicated as a "New Drive"), and then press **[ENTER]**. Choose "Add Global Spare Drive." When prompted to "Add Global Spare Drive?", choose **Yes**.

7.9 Viewing and Editing Logical Drive and Drive Members

Choose "View and Edit Logical Drives" in the main menu. The array status will be displayed. Refer to the previous chapter for more details on the legends used in Logical Drive's Status. To see the drive member information, choose the logical drive by pressing **[ENTER]**.



Choose "View SCSI Drives." Drive member information will be displayed on the screen.

Deleting a Logical Drive

Choose the logical drive you wish to delete, then press **[ENTER]**. Choose “Delete logical drive.” Choose **Yes** when prompted to confirm.


Deleting a Partition of a Logical Drive

Q	LG	ID	LV	RAID	Size(MB)	Partition	Offset(MB)	Size(MB)	NAME
V	P0	4149A729	NA	RAID5	35	0	0	3999	
V	P1	76CD4DF6	NA	RAID0	119	1	3999	3999	
V	2			NONE					
V	3			NONE					
V	4			NONE		4	15999	3999	
V	5			NONE		5			
V	6			NONE		6			
V	7			NONE		7			

Partition Size (MB): 0

Choose the logical drive which has a partition you wish to delete, then press **[ENTER]**. Choose “Partition logical drive.” Partitions of the logical drive will be displayed in tabulated form. Move the cursor bar to the partition you wish to delete, then press **[ENTER]**. Enter “0” on the partition size to delete the partition.

Figure 7 - 1 Drive Space Allocated to the Last Partition



As illustrated above, the capacity of the deleted partition will be added to the last partition.

WARNING!

- *As long as a partition has been changed, it is necessary to reconfigure all host LUN mappings. All data kept in the partition and the host LUN mappings will be removed with any partition change.*

Assigning a Name to a Logical Drive

Naming can help with identifying different arrays in a multi-array configuration. This function is also useful in special situations. For

example, when one or more logical drives have been deleted, the array indexing is changed after system reboot. The second logical drive might become the first on the list.

LG	ID	LV	RAID	Size(MB)	Status	1	2	3	0	C	#LN	#SB	#FL	NAME
P0	477F9A88	0	RAID5	9999	GOOD					5	3	0	0	
P	View scsi drives													
P	Delete logical drive													
P	Partition logical drive													
	Logical drive Name													
	Current Logical Drive Name:													
	New Logical Drive Name: _													
	7													
			NONE											

Choose the logical drive you wish to assign a name, then press **[ENTER]**. Choose “logical drive name,” then press **[ENTER]** again. The current name will be displayed. You may now enter a new name in this field. Enter a name, then press **[ENTER]** to save the configuration.

Rebuilding a Logical Drive

If there is no spare drive in the system, a failed drive should be immediately replaced by a drive known to be good. Once the failed drive is replaced, the rebuild process can be manually initiated.


If you want the controller to auto-detect a replacement drive, make sure you have the following items set to enabled:

1. Periodic Drive Check Time
2. Periodic Auto-Detect Failure Drive Swap Check Time

These two configuration options can be found under “View and Edit Configuration Parameters” -> “ Drive-Side SCSI Parameters”.

Q	LG	ID	LV	RAID	Size(MB)	Status	0	#LN	#SB	#FL	NAME
P0	4149A729	INA	RAID5	19998	DRU FAILED	R	2	0	0		
P	View scsi drives										
P	Delete logical drive										
P	Partition logical drive										
P	Logical drive Name										
P	Rebuild logical drive										
	Rebuild Logical Drive ?										
	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No										
			NONE								
			NONE								

Choose the logical drive that has a failed member drive, then press **[ENTER]**. Choose “Rebuild logical drive”, then press **[ENTER]**. When prompted to “Rebuild Logical Drive?,” select **Yes**.



The rebuild progress will be displayed.

When rebuild has already started, choose “Rebuild progress” to see the rebuilding progress.

IMPORTANT!

- *The Rebuild function is only available when a logical drive (with RAID level 1, 3 or 5) has a failed member. NRAID and RAID 0 configurations provide no data redundancy.*
-

Regenerating Logical Drive Parity

(Applies to RAID1, 3, and 5)

If no verifying method is applied to data writes, this function can be often performed to verify parity blocks of a selected array. This function compares and recalculates parity data to correct parity errors.

LG	ID	LV	RAID	Size(MB)	Status	1	2	3	0	C	#LN	#SB	#FL	NAME
P0	477F9A88	0	NRAID5	9999	GOOD					S	3	0	0	
P				999	GOOD					S	2	-	0	
P				999	GOOD					S	2	-	0	
7			NONE											

Choose the logical drive that you want to regenerate the parity for, and then press **[ENTER]**. Choose “Regenerate Parity,” then press **[ENTER]**. When prompted to “Regenerate Parity?”, select **Yes**.

IMPORTANT!

- *If a regenerating process is stopped by a drive failure, the process cannot restart until the logical drive is successfully rebuilt by having its failed member replaced.*
-

Media Scan

Media Scan is used to examine drives and is able to detect the presence of bad blocks. If any data blocks have not been properly committed and are found during the scanning process, data from

those blocks are automatically recalculated, retrieved and stored onto undamaged sectors. If bad blocks are encountered on yet another drive during the rebuild process, the block LBA (Logical Block Address) of those bad blocks will be shown. If rebuild is carried out under this situation, rebuild will continue with the unaffected sectors, salvaging the majority of the stored data.

Wed Jun 26 16:37:56 2002 Cache Status: Clean
Write Cache: Enable

BAT:BAD

LG	ID	LV	RAID	Size(MB)	Status	1	2	3	0	C	#LN	#SB	#FL	NAME
P0	20F7C6C5	NA	RAID0	277976	GOOD				7		8	-	0	
P1	6620CBA0	NA	RAID5	694	GOOD				7		3	0	0	
Media Scan Priority - Normal Iteration Count - Single Time														
4			NONE											
5			NONE											
6			NONE											
7			NONE											

Arrow Keys: Move Cursor | Enter: Select | Esc: Exit | Ctrl+L: Refresh Screen

There are two options with performing the media scan:

1. **Media Scan Priority:** determines how much system resources will be used for drive scanning and recalculating process.
2. **Iteration Count:**

Media Scan Priority - Normal
Iteration Count - Single Time

Set Media Scan Iteration Count to Continuous Scan ?

Yes No

The iteration setting determines how many times the scan is performed. If set to the continuous, the scan will run in the background continuously until it is stopped by user.

Write Policy

View scsi drives
Delete logical drive
Partition logical drive
logical drive Name
logical drive Assignments
Expand logical drive
add Scsi drives
copy and replace drive
Write policy

Change Write Policy ?

Default Write-Back Write-Through

The Write-Back cache setting is configurable on the per array basis. Setting to the default value means the array setting is coordinated with the controller's general setting. The controller's general setting option can be found in "View and Edit Configuration Parameters" -> "Caching Parameters" -> "Write-Back Cache". Note that cached writes are lost if power failure should occur.

7.10 Viewing and Editing Host LUNs

Viewing or Deleting LUN Mappings

Choose the host channel and host ID combination you wish to view or delete.

Cache Status: Clean
Write Cache: Enable

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit Logical Volumes
view and edit Host Luns
v
v CHL 0 ID 0 (Primary Controller)
v CHL 0 ID 1 (Secondary Controller)
v CHL 1 ID 0 (Primary Controller)
v CHL 1 ID 1 (Secondary Controller)
v Edit Host-ID/WWN Name List
v

```

LUN	LV/LD	DRV	Partition	Size(MB)	RAID
0	LD	2	0	9999	RAID5
3					
4					
5					
6					
7					

Unmap Host Lun ?
Yes No

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

A list of the current LUN mapping will be displayed on the screen. Move the cursor bar to the LUN mapping you wish to delete, then press [ENTER]. Select **Yes** to delete the LUN mapping, or **No** to cancel.

Edit Host-ID/WWN Name List

This is a specific item used for systems communicating over Fibre host loops. Please refer to Chapter 8 Fibre Operation for more details.

Pass-through SCSI Commands

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit Logical Volumes
view and edit Host Luns
v
v Host Channel
v CHL 0 ID 0 (Primary Controller)
v CHL 0 ID 1 (Secondary Controller)
v CHL 1 ID 0 (Primary Controller)
v CHL 1 ID 1 (Secondary Controller)
v Edit Host-ID/WWN Name List
v

```

Slot	Ch1	ID	Size(MB)	Speed	LG_DRU	Status	Vendor and Product ID
2	0	0	1010	40MB	0	ON-LINE	SEAGATE ST31055W

Map Physical Drive Ch1: 2
To Host Channel : 0
Host ID : 0 ?
Yes No

If you have primary and secondary controllers, move the cursor to the controller for the device that you wish to map; then press [ENTER]. You will be prompted to map a SCSI ID to a physical drive.

WARNING!

- *Pass-through SCSI Commands are only intended to perform maintenance functions for a drive or device on the drive side. **Do not** perform any destructive commands to a disk drive (i.e., any commands that write data to a drive media). This will result in inconsistent parity among drives included in a logical configuration of drives. If a disk drive is a spare drive or a member of a logical drive, such a destructive command may cause a data inconsistency.*
- *When a drive/device is mapped to a host SCSI ID so that Pass-through SCSI Commands can be used, the data on that drive/device will not be protected by the controller. Users who employ Pass-through SCSI Commands to perform any write commands to drive media do so at their own risk.*

7.11 Viewing and Editing SCSI Drives

Cache Status: Clean

< Main Menu >

Quick installation

Slot	Chl	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
2	0	9999	40MB	0	ON-LINE	SEAGATE ST31055W	
2	1	9999	40MB	0	ON-LINE	SEAGATE ST31055W	
2	3	9999	40MB	0	ON-LINE	SEAGATE ST31055W	
2	4	9999	40MB	1	ON-LINE	SEAGATE ST31055W	
2	5	9999	40MB	1	ON-LINE	SEAGATE ST31055W	
2	6	9999	40MB	1	ON-LINE	SEAGATE ST31055W	
2	8	9999	40MB	NONE	NEW DRV	SEAGATE ST31055W	

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Choose “View and Edit SCSI Drives” in the main menu. All drives attached to the drive channels will be displayed on the screen.

Scanning New Drive

Cache Status: Clean
Write Cache: Enable

Slot	Chl	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
2	8	9999	40MB	0	ON-LINE		
2	5	9999	40MB	0	ON-LINE		
2	6	9999	40MB	0	ON-LINE		
2	8	9999	40MB	0	FRMT DRV		

View drive information

scan scsi drive

set slot Number

add drive Entry

Identify scsi drive

clone Failing drive

disk Reserved space - 256 mb

SCSI Channel 0

SCSI Channel 1

SCSI Channel 2

SCSI Channel 3

SCSI Channel 4

SCSI Channel 5

SCSI Channel 6

SCSI Channel 7

ID 0

ID 1

ID 2

ID 3

ID 4

ID 5

ID 6

ID 7

ID 8

ID 9

Scan SCSI Drive ?

Yes No

If there is a drive connected after the array is started, choose a drive and press [ENTER]. Choose “Scan SCSI drive”, then press [ENTER]. The menu may vary according to the drive status. Choose the drive channel and ID of the drive you wish to scan, then press [ENTER].

Slot Number

Drive Entry

These two functions are reserved for Fault Bus configuration.

Identifying Drive

Quick view	Slot	Ch1	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
view	2	0	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view	View drive information							
view	Scan scsi drive							
view	set slot Number							
view	add drive Entry							
view	Identify scsi drive							
view	clone failing drive							
view	flash All drives							
view	flash Selected drive							
view	flash all But selected drive							
view	2	0	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view	2	8	9999	40MB	NONE	NEW DRV	IBM	DDRS-34560D

Move the cursor bar to the drive you wish to identify, then press [ENTER]. Choose “Identify SCSI drive,” then choose “flash all drives” to flash the read/write LEDs of all the drives in the drive channel. Choose **Yes**.

Slot	Ch1	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
2	0	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
View drive information							
Scan scsi drive							
set slot Number							
add drive Entry							
Identify scsi drive							
clone failing drive							
Flash Drive Time(Second) : 15							
2	0	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
2	8	9999	40MB	NONE	NEW DRV	IBM	DDRS-34560D
Flash All But Channel:2 ID:1 SCSI Drive ?							
Yes No							

You may also choose “**flash selected drive**” or “**flash all But Selected drives**” to flash the read/write LED of the selected drive only, or all the drives except the selected drive. Choose **Yes** and choose an extent of time from 1 to 999 seconds.

Deleting Spare Drive (Global / Local Spare Drive)

Move the cursor to a Local Spare Drive or Global Spare Drive, then press **[ENTER]**. Choose "Delete Global/Local Spare Drive," then press **[ENTER]** again. Choose **Yes** to confirm.

	Slot	Chl	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID	
Quick view		2	0	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	1	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	2	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	3	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	4	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	5	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	6	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	7	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	8	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	9	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	10	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	11	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	12	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	13	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	14	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	15	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	16	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	17	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	18	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	19	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	20	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	21	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	22	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	23	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	24	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	25	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	26	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	27	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	28	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	29	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	30	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	31	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	32	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	33	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	34	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	35	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	36	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	37	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	38	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	39	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	40	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	41	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	42	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	43	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	44	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	45	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	46	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	47	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	48	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	49	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	50	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	51	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	52	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	53	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	54	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	55	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	56	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	57	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	58	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	59	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	60	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	61	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	62	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	63	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	64	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	65	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	66	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	67	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	68	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	69	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	70	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	71	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	72	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	73	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	74	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	75	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	76	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	77	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	78	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	79	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	80	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	81	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	82	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	83	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	84	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	85	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	86	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	87	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	88	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	89	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	90	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	91	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	92	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	93	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	94	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	95	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	96	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	97	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	98	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	99	9999	40MB	0	ON-LINE	IBM	DDRS-34560D
view		2	100	9999	40MB	0	ON-LINE	IBM	DDRS-34560D

NOTE:

- *The spare drive you deleted or any drive you replaced from a logical unit will be indicated as a "used drive."*

7.12 Viewing and Editing SCSI Channels

Except for those shipped in dual-redundant chassis, SCSI-based controllers use channel 0 as the host channel and also as the communications path between controllers. If redundant controller configuration is preferred, you may need to assign other channels as host. Flexibility is added for all channels can be configured as host or drive.

Cache Status: Clean

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit Logical Volumes
view and edit Host Luns
view and edit scsi Drives
view and edit Scsi channels
  
```

Ch1	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
0	Host	0	1	40.0MHz	Wide	L	0n	Async	Narrow
1	Host	0	NA	40.0MHz	Wide	L	0n	Async	Narrow
2	Drive	7	NA	40.0MHz	Wide	S	0n	20.0MHz	Wide
3	Drive	7	NA	40.0MHz	Wide	L	0n	Async	Narrow

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Choose “View and Edit SCSI Channels” in the main menu. Channel status displays.

Redefining Channel Mode

Ch	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
0	Host	0	1	40.0MHz	Wide	L	0n	Async	Narrow
1	Host	0	NA	40.0MHz	Wide	L	0n	Async	Narrow
2	Drive	7	NA	40.0MHz	Wide	S	0n	20.0MHz	Wide
3	Drive	7	NA	40.0MHz	Wide	L	0n	Async	Narrow

channel Mode		Change Mode to Host Channel ?	
Primary controller scsi	Secondary controller scs	<input checked="" type="radio"/> Yes	<input type="radio"/> No
scsi Terminator	sync transfer Clock		
Wide transfer	View and edit scsi target		
parity check - Enabled	view chip information		

For Fibre and SCSI-based controllers, all channels can be operated in host or drive mode. Choose the channel you wish to change, then press [ENTER]. Choose “Channel Mode,” then press [ENTER]. A dialog box will appear asking you to confirm the change.

IMPORTANT!

- *Every time you change the channel mode, you must reset the controller for the change to take effect.*

Deleting an ID

Chl	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
0	Host	0	1	40.0MHz	Wide	L	On	Async	Narrow
1	Host	0	1	40.0MHz	Wide	L	On	Async	Narrow
2	Drive	7	NA	40.0MHz	Wide	L	On	Async	Narrow
3	Drive	7	NA	40.0MHz	Wide	L	On	Async	Narrow

Choose the SCSI ID you wish to delete. Choose “Delete Channel SCSI ID.” The dialog box “Delete Primary/Secondary Controller SCSI ID?” will appear. Select **Yes**, then press **[ENTER]** to confirm.

IMPORTANT!

- Every time you change a channel ID, you must reset the controller for the changes to take effect.
- The default SCSI ID of the primary controller (single controller configuration) on a host channel is 0, on a Drive channel is 7.
- If only one controller exists, you must set the Secondary Controller’s ID to “NA.” If a secondary controller exists, you need to set a secondary ID on host and drive channels.
- Multiple target IDs can be applied to the Host channels while each Drive channel has only one or two IDs (in redundant mode).
- At least a controller’s ID has to present on each channel bus.


Setting a Primary Controller’s SCSI ID - Drive Channel

Chl	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
0	Host	0	1	40.0MHz	Wide	L	On	Async	Narrow
1	Host	0	1	40.0MHz	Wide	L	On	Async	Narrow
2	Drive	7	NA	40.0MHz	Wide	L	On	Async	Narrow
3	Drive	7	NA	40.0MHz	Wide	L	On	Async	Narrow

Choose a drive channel, then press **[ENTER]**. Choose “Primary Controller SCSI ID.” A list of channel IDs displays. Choose an ID. The dialog box “Change Primary Controller SCSI ID?” displays. Select **Yes**, then press **[ENTER]**.


For more details on ID settings in redundant mode, please refer to Chapter 10.

Setting a Secondary Controller's SCSI ID - Drive Channel



Choose a Drive channel, then press **[ENTER]**. Choose “Secondary Controller SCSI ID.” A list of channel IDs displays. Assign an ID to the chip processor of the secondary controller’s drive channel. Choose an ID. The dialog box “Change Secondary Controller SCSI ID?” will appear. Select **Yes**, then press **[ENTER]**.


Setting Channel Terminator



Choose the channel you wish the terminator enabled or disabled, then press **[ENTER]**. Choose “SCSI Terminator”, then press **[ENTER]**. A dialog box will appear. Choose **Yes**, then press **[ENTER]**. Terminator can also be enabled by switch jumpers, please refer to the controller hardware manual for more details.

Setting a Transfer Speed

Drive Channel



Host Channel

Quick installation
view and edit Logical drives
view channel Mode
view Primary controller scsi id
view Secondary controller scsi id
view scsi terminator
view sync transfer Clock

Ch	efWid	S	Term	CurSynClk	Cur
0	Wide	L	0n	Async	Nar
1	Wide	L	0n	Async	Nar
2	Drive	7	NA	80.0MHz	Wide
3	Drive	7	NA	80.0MHz	Wide

80.0MHz
40.0MHz
33.0MHz
20.0MHz
16.6MHz
13.8MHz
10.0MHz
8.0MHz
6.7MHz
5.8MHz
5.0MHz
4.0MHz
3.3MHz
2.8MHz
2.5MHz
Async

Move the cursor bar to a channel, then press **[ENTER]**. Choose “Sync Transfer Clock”, then press **[ENTER]**. A list of the clock speed will appear. Move the cursor bar to the desired speed and press **[ENTER]**. A dialog box “Change Sync Transfer Clock?” will appear. Choose **Yes** to confirm.

IMPORTANT!

- *Every time you change the SCSI Transfer Speed, you must reset the controller for the changes to take effect.*

Setting the Transfer Width

Quick installation
view and edit Logical drives
view channel Mode
view view and edit scsi Id
view scsi Terminator
view sync transfer Clock
view Wide transfer

Ch	Clk	DefWid	S	Term	CurSynClk	CurWid
0						
1						
2	Drive	7	6	40.0MHz	Wide	S
3	Drive	7	NA	40.0MHz	Wide	L

Enable Wide Transfer ?
Yes No
Narrow L 0n Async Narrow

Move the cursor bar to a channel, then press **[ENTER]**. Select “Wide Transfer,” then press **[ENTER]**. A dialog box “Disable Wide Transfer?” or “Enable Wide Transfer?” will appear. Choose **Yes** to confirm.

IMPORTANT!

- *Every time you change the SCSI Transfer Width, you must reset the controller for the changes to take effect.*

Maximum Synchronous Transfer Clock

Quick view	Slot	Chl	ID	SyncClk	XfrWid	ParityChk	Disconnect	TagCount	
view	1	0		9	Wide	Enabled	Enabled	Def(32)	
view	Slot number maximum sync. xfer Clock						bled	Enabled	Def(32)
view	Synchronous Transfer Period Factor Maximum Sync. Xfer Clock: 9								
view	1	5		9	Wide	Enabled	Enabled	Def(32)	
view	1	6		9	Wide	Enabled	Enabled	Def(32)	
view	1	8		9	Wide	Enabled	Enabled	Def(32)	

Choose “Maximum Sync. Xfer Clock,” then press **[ENTER]**. A dialog box will appear on the screen. Enter the clock, then press **[ENTER]**.

Maximum Transfer Width

Quick view	Slot	Chl	ID	SyncClk	XfrWid	ParityChk	Disconnect	TagCount	
view	1	1	0	9	Wide	Enabled	Enabled	Def(32)	
view	2	1	1	9	Narrow	Enabled	Enabled	Def(32)	
view	Slot number maximum sync. xfer Clock maximum xfer Width						bled	Enabled	Def(32)
view	Set SCSI Target Maximum Xfer Wide Supported ?								
view	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No								
view	1	6		9	Wide	Enabled	Enabled	Def(32)	
view	1	8		9	Wide	Enabled	Enabled	Def(32)	

Choose “Maximum Xfer Width”, then press **[ENTER]**. Choose **Yes** in the dialog box to confirm the setting.

Parity Check

Quick view	Slot	Chl	ID	SyncClk	XfrWid	ParityChk	Disconnect	TagCount	
view	1	1	0	9	Wide	Enabled	Enabled	Def(32)	
view	2	1	1	9	Wide	Disabled	Enabled	Def(32)	
view	Slot number maximum sync. xfer Clock maximum xfer Width Parity check						bled	Enabled	Def(32)
view	Enable Parity Checking ?								
view	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No								
view	1	8		9	Wide	Enabled	Enabled	Def(32)	

Choose “Parity Check.” Choose **Yes** in the dialog box that follows to confirm the setting.

Disconnecting Support

Slot	Ch1	ID	SyncClk	XfrWid	ParityChk	Disconnect	TagCount
1	2	0	9	Wide	Enabled	Enabled	Def(32)
2	2	1	9	Wide	Enabled	Enabled	Def(32)
3	6	6	9	Wide	Enabled	Enabled	Def(32)
7	2	8	9	Wide	Enabled	Enabled	Def(32)

Slot number	bled	Enabled	Def(32)
maximum sync. xfer Clock	bled	Enabled	Def(32)
maximum xfer Width	bled	Enabled	Def(32)
Parity check	bled	Enabled	Def(32)
Disconnect support	bled	Enabled	Def(32)
Disallow target disconnect ?		Enabled	Def(32)
<input checked="" type="checkbox"/> Yes		Enabled	Def(32)
<input type="checkbox"/> No		Enabled	Def(32)

Choose “Disconnect Support.” Choose **Yes** in the dialog box that follows to confirm the setting.

Maximum Tag Count

Slot	Ch1	ID	SyncClk	XfrWid	ParityChk	Disconnect	TagCount
1	2	0	9	Wide	Enabled	Enabled	Def(32)
2	2	1	9	Wide	Enabled	Enabled	Def(32)
3	6	6	9	Wide	Enabled	Enabled	Def(32)
7	2	8	9	Wide	Enabled	Enabled	Def(128)

Slot number	bled	Enabled	Def(32)
maximum sync. xfer Clock	bled	Enabled	Def(32)
maximum xfer Width	bled	Enabled	Def(32)
Parity check	bled	Enabled	Def(32)
Disconnect support	bled	Enabled	Def(32)
maximum tag count	bled	Enabled	Def(32)
Restore to default setting	bled	Enabled	Def(32)
Set Maximum Tag Count ?		Enabled	Def(32)
<input checked="" type="checkbox"/> Yes		Enabled	Def(32)
<input type="checkbox"/> No		Enabled	Def(32)

Choose “Maximum Tag Count,” then press **[ENTER]**. A list of available tag count numbers will appear. Move the cursor bar to a number, then press **[ENTER]**. Choose **Yes** in the dialog box that follows to confirm the setting.

IMPORTANT!

- Disabling the Maximum Tag Count will disable the internal cache of a SCSI drive.

Data Rate

Ch1	Mode	ID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
0	Host	*	80.0MHz	Wide	L	Off	Async	Narrow
1	Host	0	80.0MHz	Wide	L	Off	Async	Narrow
2	Drive		AUTO	PATA				
3	view chip inFormation			PATA				
4	Data rate			PATA				
5	AUTO		AUTO	PATA				
6	33MB		AUTO	PATA				
7	44MB		AUTO	PATA				
	66MB		AUTO	PATA				
	100MB		AUTO	PATA				


This option is available in the drive channel configuration menus of Fibre, ATA, or SATA-based subsystems. Default is “AUTO” and

should work fine with most drives. Changing this setting is not recommended unless some particular bus signal issues occur.

All SATA/ATA-based system connects only one drive per SATA/ATA channel. This helps to avoid single drive failure from affecting other drives. The maximum mechanical performance of today's drives can reach around 30MB/sec (sustained read). This is still far below the bandwidth of a drive channel bus. Setting the SATA/ATA bus speed to a lower value can get around some problems, but will not become a bottleneck to system performance.


Mind that the SATA/ATA speed is the maximum transfer rate of SATA/ATA bus in that mode. It does not mean the drive can actually carry out that amount of sustained read/write performance. For the performance of each drive model, please refer to the documentation provided by drive manufacturer.

7.13 System Functions




Choose “System Functions” in the main menu, then press **[ENTER]**. The System Functions menu displays. Move the cursor bar to an item, then press **[ENTER]**.

Mute Beeper



When the controller’s beeper has been activated, choose “Mute beeper,” then press **[ENTER]**. Choose “Yes” and press **[ENTER]** in the next dialog box to turn the beeper off temporarily for the current event. The beeper will still be activated on the next event.

Change Password



Use the controller’s password to protect the array from unauthorized entry. Once the controller’s password has been set, regardless of whether the front panel, the RS-232C terminal interface

or RAIDWatch Manager is used, you can only access the RAID controller by providing the correct password.

IMPORTANT!

- *The controller verifies password when entering the main menu from the initial screen or making configuration change. If the controller is going to be left unattended, the “Password Validation Timeout” can be set to “Always Check.” Setting validation timeout to “always check” will protect the controller configuration from any unauthorized access.*
 - *The controller password and controller name share a 16-character space. The maximum characters for the controller password is 15. When the controller name occupies 15 characters, there is only one character left for the controller password, and vice versa.*
-

Changing the Password


To set or change the controller password, move the cursor bar to “Change Password,” then press **[ENTER]**.

If a password has previously been set, the controller will ask for the old password first. If the password has not yet been set, the controller will directly ask for the new password. The password can not be replaced unless a correct old password is provided.

Key-in the old password, then press **[ENTER]**. If the password is incorrect, it will not allow you to change the password. Instead, it will display the message “Password incorrect!,” then go back to the previous menu.

If the password is correct, or there is no preset password, it will ask for the new password.

Setting a New Password




Enter the desired password in the column, then press **[ENTER]**. The next dialog box will display “Re-Enter Password”. Enter the password again to confirm and press **[ENTER]**.

The new password will now become the controller's password. Providing the correct password is necessary when entering the main menu from the initial screen.

Disabling the Password

To disable or delete the password, press **[ENTER]** in the empty column that is used for entering a new password. The existing password will be deleted. No password checking will occur when entering the main menu or when making configuration change.


Reset Controller



To reset the controller without powering off the system, move the cursor bar to "Reset Controller," then press **[ENTER]**. Choose **Yes** in the dialog box that follows, then press **[ENTER]**. The controller will now reset as well as power-off or re-power-on.


Shutdown Controller

Before powering off the controller, unwritten data may still reside in cache memory. Use the "Shutdown Controller" function to flush the cache content. Move the cursor bar to "Shutdown Controller," then press **[ENTER]**. Choose **Yes** in the dialog box that follows, then press **[ENTER]**. The controller will now flush the cache memory.



For "Controller Maintenance" functions, such as "Download Firmware," please refer to Appendix C.


Adjust LCD Contrast



The controller LCD contrast is set at the factory to a level that should be generally acceptable. The controller comes equipped with a LCD contrast adjustment circuit just in case the factory-preset level is not optimal allowing the contrast to be adjusted either via the RS-232 Terminal Emulation Menus or by the LCD User Interface.


7.14 Controller Parameters

Controller Name



Choose "View and Edit Configuration Parameters," "Controller Parameters," then press [ENTER]. The current name displays. Press [ENTER]. Enter a name in the dialog box that prompts, then press [ENTER].

LCD Title Display Controller Name




Choose “View and Edit Configuration Parameters,” “Controller Parameters,” then press [ENTER]. Choose to display the embedded controller logo or any given name on the LCD. Giving a specific name to controller can give you the ease of identification if you have multiple RAID systems remotely monitored.

Saving NVRAM to Disks

You can choose to backup your controller-dependent configuration information to disks. We recommend using this function to save configuration information whenever a configuration change is made. The information will be duplicated and distributed to all logical configurations of drives.

At least a RAID configuration must exist for the controller to write your configuration data onto it.

From the main menu, choose “system functions.” Use arrow keys to scroll down and select “controller maintenance,” “save NVRAM to disks,” then press [ENTER].




Choose **Yes** to confirm.

A prompt will inform you that NVRAM information has been successfully saved.

Restore NVRAM from Disks

When you want to restore your NVRAM information from what you previously saved onto disk, use this function to restore the configuration information.


From the main menu, choose “system functions.” Use arrow keys to scroll down and select “controller maintenance,” “restore NVRAM from disks,” and then press **[ENTER]**.



Press **Yes** to confirm.


A prompt will notify you that the controller NVRAM data has been successfully restored from disks.

Password Validation Timeout



Choose “View and Edit Configuration parameters,” “Controller Parameters,” then press **[ENTER]**. Select “Password Validation Timeout,” and press **[ENTER]**. Choose to enable a validation timeout from one minute to always check. The always check timeout will disable any configuration change made without entering the correct password.

Controller Unique Identifier



Enter any hex number between “0” and “FFFFF” for the unique identifier. The value you enter **MUST** be different for each controller.

The Controller Unique Identifier is **required** for configuring every RAID controller. The controller automatically notifies users to enter a unique identifier when the first logical drive is created in a dual-controller system.

Enter a unique ID for any RAID controller no matter it is configured in a single or dual-controller configuration. The unique ID is necessary for the following:

1. A controller-specific identifier that helps controllers to identify its counterpart in a dual-active configuration.
2. The unique ID is generated into a Fibre channel WWN node name for controllers or RAID systems using Fibre channel host ports. The node name is used to prevent host computers from mis-addressing the storage system during the controller failover/failback processes.
3. MAC addresses for the controller’s Ethernet port that should be taken over by a surviving controller in the event of controller failure.

In redundant mode, configuration data is synchronized between controllers. Host ports on both controllers appear with the same node name but each with a different port name (WWPN).


When a controller fails and a replacement is combined as the Secondary controller, the node name will be passed down to the Secondary controller. The host will not acknowledge any differences so that controller failback is totally transparent.

The unique identifier setting can be accessed from "View and Edit Configuration Parameters" → "Controller Parameters" → "Controller Unique ID."

Set Controller Date and Time

This sub-menu only appears when the controller is equipped with a real-time clock.

Time Zone



The controller uses GMT (Greenwich Mean Time), a 24-hours clock. To change the clock to your local time zone, enter the hours later than the Greenwich mean time following a plus (+) sign. For example, enter “+9” for Japanese time zone.


Date and Time



Enter time and date in its numeric representatives in the following order: month, day, hour, minute, and the year.

7.15 Drive Information


View Drive Information



From the “View and Edit SCSI Drives” menu, select the drive that the utility is to performed on, then press **[ENTER]**. Select “View drive information,” then press **[ENTER]**.

SCSI Drive Utilities

From the “View and Edit SCSI Drives” menu, select the drive that the utility is to performed on, then press **[ENTER]**. Select “SCSI Drive Utilities, then press **[ENTER]**. Choose either “SCSI Drive Low-level Format” or “Read/Write Test.”



8.1 Overview

This chapter describes the Fibre-specific functions available since firmware release 3.21 and above. Optional functions have been implemented for operations using Fibre channel and access control under multiple-host environments such as Storage Area Network. Users familiar with Fibre channel configurations, please jump to section 8.5.

Summary:

8.2 Major Concerns:

Things you should know before proceeding with configuration

8.3 Supported Features:

List of functionality supported by controller FC chips

8.4 Configuration: Host and Drive Parameters

Configuration options for data bus setting and system drive mapping

8.5 Configuration Sample

The configuration procedures for changing parameters on FC host and drive channels

8.6 Multi-Host Access Control:

Learning how to setup the LUN Filtering function, a useful tool for access control in multi-host environments

8.2 Major Concerns

Most of the configuration options in this chapter are directly related to controller redundancy. Joining two controllers into a dual-active pair can eliminate most possible points of failure. Configuring a controller pair requires careful planning and proper setup and the requirements can be summarized as follows:

<p>▪ Redundant Cache Coherency Channels (RCC):</p>	
1. RCC	FC channels can be manually assigned as the dedicated communications loops. Two are recommended for path redundancy and sufficient bandwidth.
2. Drive + RCC	Communications traffic distributed over drive loops
<p>▪ Connection between Controllers:</p>	
	Cabling between controllers, hardware link through a common backplane, Fibre hub or switch (for SAN applications and for those models that do not have by-pass chips)
<p>▪ Channel Mode Assignment</p>	
	<p>According to the topological plan, your I/O channels can be designated as:</p> <ul style="list-style-type: none"> • Host • RCC paths • Drive • Drive + RCC
<p>▪ Host Channel Connection Type:</p>	
	<p>This depends on the way your RAID system is connected to the host computer(s). The host connection type can be:</p> <ul style="list-style-type: none"> • FC-AL • Fabric (point-to-point)
<p>▪ Controller Unique ID:</p>	
	This ID will be used to generate Fibre ports' node names, and is necessary for addressing the controller during the controller failover/failback operation.
<p>▪ Dual-Loop:</p>	
1.	Drive-side dual loop provides data path redundancy. Firmware is capable of executing a load-sharing algorithm to optimize dual-loop

performance.

2. **Host-side** dual loop is passively supported and requires the support of multi-path software on the host computer.

8.3 Supported Features

Fibre Chip

1Gbit Fibre Channel:

Fibre loops (1 Gbit FC-AL) comply with the following standards:

1. (FC-PH) X2.230:1994,
2. (SCSI-FCP) X3.269:1996,
3. (FC-AL-2) Project 1133-D rev.6.5,
4. (SCSI-2) X3.131-1994,
5. Supporting sustained 1 Gigabit/sec (100MB/sec) transfer rates.
6. Each Fibre loop can be independently configured for the connection to host or drive.

2Gbit Fibre Channel:

1. Fibre Channel Arbitrated Loop (FC-AL-2) working draft, rev 6.4
2. Fibre Channel Fabric Loop Attach (FC-FLA) working draft, rev 2.7
3. Fibre Channel Private Loop SCSI Direct Attach (FC-PLDA) working draft, rev 2.1
4. Fibre Channel Tape (FC-TAPE) profile, T11/98-124vD, rev 1.13
5. Support Fibre Channel protocol-SCSI (FCP-SCSI)
6. Support Fibre Channel Internet protocol (IP)

Multiple Target IDs:

Each 2Gbit channel configured as a host loop supports multiple target IDs in the range of 0 to 125.

Drive IDs:

Supported ways to address a Fibre port include Hard assigned and Soft assigned. The controller supports automatic loop ID assignment on drive channels. A hard loop address ID can be assigned to disk drives by enclosure jumper setting. If the AL_PA configuration on drive enclosure has been set to a neutral status, physical IDs will be automatically assigned to drives.

In-band Fibre and S.E.S. Support:

"SCSI Pass-through" commands are supported over host and drive loops just as they are over SCSI channels. The "in-band Fibre" protocol for packaging "External Interface" protocol commands/responses is supported over host Fibre loops (such as the RAIDWatch Manager). Drive-side S.E.S. device identification, monitoring and control are likewise supported over drive loops.

8.4 Configuration: Host and Drive Parameters

Channel Mode:

Q	Ch1	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
v	0	Host	112	NA	1 GHz	Serial	F	NA		
v	1	Host	NA	113	1 GHz	Serial	F	NA	1 GHz	Serial
v	2(C)	DRV+RCC	119	118	1 GHz	Serial	F	NA	1 GHz	Serial
v	3	Drive	119	118	1 GHz	Serial	F	NA		
v	4	channel Mode				erial	F	NA	1 GHz	Serial
v	5	Host			er scsi id	erial	F	NA		
v		Drive			iller scsi id					
v		RCCOM			ation					
v		Drive+RCCOM								

All Fibre channels can be changed to operate as “Host,” “Drive,” “RCCOM,” or “Drive + RCCOM”. Choose the channel you wish to change its mode, then press **[ENTER]**. Choose “Channel Mode,” then press **[ENTER]**. A dialog box will appear asking you to confirm the change.

Primary and Secondary Controller IDs:

Select a channel by highlighting its status bar and press **[ENTER]**.

Drive Channel In redundant controller mode, each drive channel should be assigned with both a "Primary Controller ID" and a "Secondary Controller ID." The factory defaults for the primary and secondary IDs on drive loops are “119” and “120”.

Host Channel Create host IDs on each specific host channel. Host IDs are designated as the “Primary controller” or “Secondary controller” IDs.

< Main Menu >											
Quick installation											
view and edit Logical drives											
view and edit logical Volumes											
v	Ch1	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	Cur	
v	0	Host	NA	NA	1 GHz	Serial	F	NA	1 GHz	Serial	
v	1	No SCSI ID Assignment - Add Channel SCSI ID ?							GHz	Ser	
v	2<	Yes		No				GHz	Ser		
v	3<2>	Drive	11	Primary Controller				NA	1 GHz	Ser	
v	6<D>	RCCOM		Secondary Controller							
v	7<C>	RCCOM									
<To Range 5>											
ID 96											
ID 97											
ID 98											
ID 99											
ID 100											
ID 101											
ID 102											
ID 103											
ID 104											
ID 105											
ID 106											
ID 107											
ID 108											
ID 109											
ID 110											
ID 111											
<To Range 7>											

View Device Port Name List (WWPN)

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes

```

Chl	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
0	Host	0	NA	1 GHz	Serial	F	NA	1 GHz	Serial
1	channel Mode						NA	1 GHz	Serial
2	view and edit scsi Id						NA	1 GHz	Serial
3	view chip inFormation						NA	1 GHz	Serial
3	view channel Wwn						NA	1 GHz	Serial
3	View device: port name list <wwpn>						NA	1 GHz	Serial
6<D>	20 00 00 E0 8B 00 9F 6C								
7<D>	RCCom								

This function displays the device port names (host adapter ID) detected on a host loop.

The HBA port names detected can be added to the "**Host-ID WWN name list**" in "View and Edit Host LUN" menu. Adding port names to list can speed the mapping process that follows.

Each port name should then be assigned a nickname for ease of identification. This is especially the case when multiple filtering entries must be defined for granting or denying access to a specific storage unit. See the following sections for more details.

View and Edit Fibre Drives

Cache Status: 24% Dirty

Slot	Chl	ID	Size(MB)	Speed	LG_DRU	Status	Vendor and Product ID	
2	0		8683	100MB	0	ON-LINE	SEAGATE ST39103FC	
View drive information							0	ON-LINE SEAGATE ST39103FC
Scan scsi drive							0	ON-LINE SEAGATE ST39103FC
set slot Number							0	ON-LINE SEAGATE ST39103FC
add drive Entry							0	ON-LINE SEAGATE ST39103FC
Identify scsi drive							0	ON-LINE SEAGATE ST39103FC
clone Failing drive							0	ON-LINE SEAGATE ST39103FC
disk Reserved space - 32 mb							0	ON-LINE SEAGATE ST39103FC
2	5		8683	100MB	1	ON-LINE	SEAGATE ST39103FC	
2	6		8683	100MB	1	ON-LINE	SEAGATE ST39103FC	
2	7		8683	100MB	1	ON-LINE	SEAGATE ST39103FC	

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Choose "View and Edit SCSI Drives" on the main menu and use the arrow keys to move the cursor bar through connected drives. Press **[ENTER]** to choose a drive, or **[ESC]** to return to the previous menu/screen.

User-Assigned ID (Scan SCSI Drive)

Select "Scan SCSI drive" to assign an ID to drive.

Slot	Chl	ID	Size(MB)	Speed	LG_DRU	Status	Vendor and Product ID
	2	0	17560	100MB	0	ON-LINE	SEAGATE ST318304FC
	2	1	17560	100MB	1	ON-LINE	SEAGATE ST318304FC
	2	2	17560	100MB	NONE	FRMT DRU	SEAGATE ST318304FC
	2	3	17560	100MB	NONE	FRMT DRU	SEAGATE ST318304FC
	2	6	17366	100MB	NONE	FRMT DRU	SEAGATE ST318275FC
	2	6	17366	100MB	NONE	FRMT DRU	SEAGATE ST318275FC
	2	7	17366	100MB	NONE	FRMT DRU	SEAGATE ST318275FC

A drive enclosure usually has drive slots pre-assigned with specific IDs. There are occasions when an ID needs to be assigned manually to a device other than an ID provided otherwise. The "set slot number" and the "add drive entry" functions are reserved for Infortrend's Fault-bus operation.

View Drive Information

Slot	Chl	ID	Size(MB)	Speed	LG_DRU	Status	Vendor and Product ID
	2	0	17560	100MB	0	ON-LINE	SEAGATE ST318304FC
	2	1	17560	100MB	1	ON-LINE	SEAGATE ST318304FC
	2	5	17366	100MB	NONE	FRMT DRU	SEAGATE ST318275FC
	2	6	17366	100MB	NONE	FRMT DRU	SEAGATE ST318275FC
	2	7	17366	100MB	NONE	FRMT DRU	SEAGATE ST318275FC

Property	Value	Product ID
Revision Number	0002	8304FC
Serial Number	3EL00FUN0007049	8304FC
Disk Capacity (blocks)	35964300	8304FC
Node Name(WVNN)	20 00 00 20 37 65 7B DA	8275FC
Redundant Loop ID	0	8275FC

If the selected drive belongs to a drive group that is configured in a dual-loop, the "Redundant Loop ID" will be displayed here.

View and Edit Host-Side Parameters

```

Cache Status: Clean
< Main Menu >
Quick installation
view
view Maximum Queued I/O Count - 256
view LUNs per Host SCSI ID - 8
view Max Number of Concurrent Host-LUN Connection - 32
view Number of Tags Reserved for each Host-LUN Connection - Def(32)
view Peripheral Device Type Parameters
view Host Cylinder/Head/Sector Mapping Configuration
v s C Fibre Connection Option - Loop only
v v C Host Loop only
v v C Driv Point to point only
v v C Disk Loop preferred, otherwise point to point
v v C Redu Point to point preferred, otherwise Loop
v v C Cont
Arrow Keys: Move Cursor | Enter: Select | Esc: Exit | Ctrl+L: Refresh Screen

```

1. Fibre Channel Connection Option:

Use the ↑ ↓ keys to scroll down to “View and Edit Configuration Parameters,” “Host-side SCSI Parameters,” and then “Fibre Connection Option.” A prompt will display all the options. Select one appropriate for your Fibre channel topology. If connection to host is through a Fibre hub, choose “Loop only.”


If connection to host is through a Fibre switch F_Port or directly to a server, choose “Point to point only.” Proper selection is necessary and will decrease overhead on data transmission.

A redundant controller configuration should always have its host connection configured in FC-AL mode. For a switched fabric configuration, a redundant controller system can be connected to the FL_ports on an FC switch and then the host computers connect to its F_ports.

IMPORTANT!

- *Note that the host ports between redundant controllers can be connected via switched fabric. However, switch ports connecting the controllers should be operating as FL_Ports. If they are configured as F_Ports, the controller host ports will not support multiple target IDs, especially when IDs on a failed controller's host ports need to be taken over by the surviving controller.*
-

View and Edit Drive-Side Parameters



2. Drive-Side Dual Loop:

Fibre drives are usually configured in a JBOD enclosure. Through the enclosure backplane, these drives form one or two circuit loops. You may choose to assemble certain number of disk drives into a dual-loop configuration using two of the controller channels.

To configure a dual-loop, connect two of the drive channels each to an FC-AL port on the drive enclosure (JBOD). Please refer to the related documents that came with your drive enclosure for the connection details.

The dual-loop configuration not only doubles traffic bandwidth by separating the transmitting and receiving paths but also provides path redundancy. I/O traffic will be continued if one data path fails.

Controller firmware automatically examines the node names and port names of all the connected drives once initiated. If devices on two different drive channels appear with the same loop ID and port name, controller will consider these two drive channels as a "dual loop."

< Main Menu >

Quick installation
view and edit Logical drives
view and edit Logical Volumes

Ch1	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
0	Host	0	NA	1 GHz	Serial	F	NA	1 GHz	Serial
1	Host	NA	1	1 GHz	Serial	F	NA	1 GHz	Serial
2<3>	Drive	119	120	1 GHz	Serial	F	NA	1 GHz	Serial
3<2>	Drive	119	120	1 GHz	Serial	F	NA	1 GHz	Serial
6<C>	RCCom								
7<C>	RCCom								

The dual loop configuration will be displayed as "channel <pair channel>." For example, channel numbers are displayed as 2<3> and 3<2> if channel 2 and channel 3 are configured as a dual loop. The data bus will be operating at the bandwidth of up to 400MB/sec (2Gbps Fibre).

Controller Unique Identifier




A Controller Unique Identifier is **required** for operation with the **Redundant Controller Configuration**. The controller will automatically notify users to enter a unique identifier when the first logical drive is being created in a dual-controller system.

The unique identifier will be used to generate a Fibre channel "node name" (WWNN). The node name is device-unique and comprised of information such as the IEEE company ID and this user-configurable identifier in the last two bytes.

In redundant mode, the controller configuration data is continuously synchronized between controllers. Host ports on both controllers appear with the identical node names and each with a different port name (WWPN). When a controller fails and a replacement is combined, the node name will be passed down to the replacement, making the host unaware of controller replacement so that controller failback is totally transparent.

Choose "View and Edit Peripheral Devices," "Set Peripheral Device Entry," then enable the "Redundant Controller" configuration. You will be requested to enter a value for the "Controller Unique Identifier." For firmware release 3.25 and above, enter a hex number between **0** and **FFFF**. The identifier selection box will prompt automatically. The value you enter **MUST** be different for each controller.



The unique identifier can also be accessed from "View and Edit Configuration Parameters" → "Controller Parameters" → "Controller Unique ID."

Controller Communications over Fibre Loops

Q	Ch1	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
v	0	Host	112	NA	1 GHz	Serial	F	NA		
v	1	Host	NA	113	1 GHz	Serial	F	NA	1 GHz	Serial
v	2(C)	DRV+RCC	119	118	1 GHz	Serial	F	NA	1 GHz	Serial
s	3	Drive	119	118	1 GHz	Serial	F	NA		
v	4	channel Mode				erial	F	NA	1 GHz	Serial
P	5	Host			er scsi id	erial	F	NA		
S		Drive			ller scsi id					
v		RCCOM			ation					
		Drive+RCCOM								

Controllers running firmware version 3.14 and above supports controller communications over Fibre loops.

There are two options with the controller communications over Fibre loops. Hardware configuration should be completed before firmware setting.

1. Select from the main menu "View and Edit SCSI channels," and configure the selected FC channels into "RCCOM (Redundant Controller Communication)" mode. To ensure the connection with data path redundancy, you may use two channels as the dedicated RCC loops. The dedicated channels should not be attached with any other device.
2. **Communications Traffic Distributed over All Drive Loops:** Select all drive loops and configure them as "Drive + RCCOM (Drive Loops plus Redundant Controller Communications)." The communications traffic between the two controllers will be automatically distributed over all drive loops.

Q	Ch1	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
v	0	Host	112	NA	1 GHz	Serial	F	NA	1 GHz	Serial
v	1	Host	NA	113	1 GHz	Serial	F	NA	1 GHz	Serial
v	2(3;C)	DRV+RCC	119	118	1 GHz	Serial	F	NA	1 GHz	Serial
v	3(2;C)	DRV+RCC	119	118	1 GHz	Serial	F	NA	1 GHz	Serial
v	4(5;C)	DRV+RCC	119	118	1 GHz	Serial	F	NA	1 GHz	Serial
v	5(4;C)	DRV+RCC	119	118	1 GHz	Serial	F	NA	1 GHz	Serial


- As displayed above, channel(s) selected as the communications paths will be displayed as "channel number (C: connected)" or "channel number (D: disconnected)." If channels configured in a dual-loop are selected, channel status will be displayed as "channel number (pair loop; C or D)."
- If any of the communications loops should fail, the inter-controller traffic will be automatically shifted to the remaining Drive/RCC loop(s).

8.5 Multi-Host Access Control: LUN Filtering

RAID-based mapping provides access control over a Storage Area Network where:


1. Servers may share common storage;
2. File integrity becomes a problem and access contentions might occur;
3. File access must be coordinated among multiple servers.

Figure 8 - 1 Storage Pool



RAID-based mapping provides the centralized management for host-storage access. It is derived from the concept that storage can be divided into manageable pieces by mapping storage units to different Logical Unit Numbers (LUNs). The storage can then be managed in the context of a LUN map. We then append filtering mask(s) to the LUNs making specific storage unit accessible or inaccessible to one or multiple host adapters (HBAs).

Figure 8 - 2 Host-LUN Mapping




Creating LUN Masks

User can configure the storage subsystem to appear as 32 LUNs per Fibre target ID. Each LUN can be mapped with a storage unit -a partition or the entire logical drive. The configuration of logical units depends on host applications and how many drives and drive channels have been employed in the storage system.

The diagram below shows the idea of the virtual connection and the physical connection from host computers to drives. There can be many host computers connected across a storage network and a system administrator may want to make each storage unit available for certain host systems while forbidden for some others.

Figure 8 - 3 LUN Mask



The access control can also be implemented by filter drivers. However, comparing to the control by software, access control based on controller LUN mapping can avoid overheads on server and the additional I/O latency.

The LUN map combines **Host ID** (in the Fibre case, a 64-bit "**port name**;" in the SCSI case, the **initiator ID**) with the list of attributes of a LUN map that originally only consisted of the channel, target ID, and the LUN number.

To create LUN masks, select "View and Edit Host LUNs" from the Main Menu, then select a host data path (channel-ID combination). In active-to-active mode, selecting a host channel means selecting either the Primary or the Secondary controller I/O path.

WWN Name List

Before mapping host LUNs, you may add host adapter port names to a WWN name list to combine with a nickname given to each adapter. Names will be recorded in controller NVRAM.



A named adapter (by location or the nature of host applications) can be easily identified and later combined with filtering masks.

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host Luns
v
v CHL 7 ID 113 (Secondary Controller)
v Edit Host-ID/WWN Name List
v
v Host-ID/WWN Name List
v
v Host-ID/WWN Name List
v
v 200000E08B011A49 finance
v 210000E08B011A49 support
v
v Add Host-ID/WWN Name List
v Delete Host-ID/WWN Name List

```

Logical Unit to Host LUN Mapping

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host Luns
v Host Channel
v CHL 0 ID 0 (Primary Controller)
v CHL 1 ID 1 (Secondary Controller)
v
v system Functions
v view system Information
v view and edit Event logs

```

Assign Logical Unit Numbers (LUNs) to logical units (logical drives/logical volumes/logical partitions). Select a host channel/ID and then select a LUN number. Select a Host LUN and associate a logical unit with it.

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host Luns
v Host Channel
v CHL 0 ID 0 (Primary Controller)
v CHL 1 ID 1 (Secondary Controller)
v
v system Functions
v view system Information
v view and edit Event logs

```

LUN	LU/LD	DRU	Partition	Size(MB)	RAID
0	LD	1	0	3000	RAID5
1	LD	1	1	3000	RAID5
2	LD	3	0	3000	RAID5
3	LD	3	1	3000	RAID5

L	Partition	Offset(MB)	Size(MB)	LD	atus	#LN	#SB	#FL	NAME
0	0	0	3000						
1	1	3000	3000						
S1	526D21EF	NA	RAID5	6000	GOOD	S	4	0	0
S3	1B6F245E	NA	RAID5	6000	GOOD	S	4	0	0

When a logical unit is selected, you may choose to "Map Host LUN" or "Create Host Filter Entry." If you select to map the logical unit directly to a host LUN without LUN masking, the particular logical unit will be accessible for all host computers connected through the network.

LUN	LU/LD	DRU	Partition	Size(MB)	RAID
0	LD	1	0	3000	RAID5
1	LD	1	1	3000	RAID5
2	LD	3	0	3000	RAID5
3	LD	3	1	3000	RAID5
4					

```

Map Host LUN
Create Host Filter Entry
Add from current device lists
Manual add host filter entry
7

```

If you want the logical unit to be accessible for some host computers while inaccessible for some others, choose "Create Host Filter Entry."

More than one filter entry can be appended to a host LUN to compose a more complex mapping scheme. LUN map is port name-oriented. You can choose to "Add from current device list" or "Manual(ly) add host filter entry."

LUN	LV/LD	DRV	Partition	Size(MB)	RAID
0	LD	1	0	3000	RAID5
1	LD	1	1	3000	RAID5
2	LD	3	0	3000	RAID5
3	LD	3	1	3000	RAID5
4					
Map Host LUN					
Create Host Filter Entry					
Port Name List					
10 00 00 00 C9 20 C7 38					
7					

Pressing [ENTER] on "Add from current device list" will bring forth a list of port names detected on host loops. If you have a name list pre-configured, port names will appear with its nicknames. Select a port name by pressing [ENTER].

LUN	LV/LD	DRV	Partition	Size(MB)	RAID
0					
Map Host LUN					
Create Host Filter Entry					
Host-ID/WWN					
Host-ID/WWN: 0x200000E08B011A49 (finance)					
Host-ID/WWN: 0x210000E08B011A49 (support)					
Host-ID/WWN: 0x220000E08B011A50 (R&D)					
5					
6					
7					

Host-ID/WWN: 0x210000E08B011A49 (support)
<input checked="" type="radio"/> Yes <input type="radio"/> No

Choose Yes to proceed.

LUN	LV/LD	DRV	Partition	Size(MB)	RAID
M 0	LV	1	0	2020	-----
M 1					
Logical Volume 1 Partition 4					
Host-ID/WWN - 0x210000E08B011A49					
Host-ID/WWN Mask - 0xFFFFFFFFFFFFFFFF					
Filter Type - Include					
Access Mode - Read/Write					
Name - Not Set					
Create Host Filter Entry					
6					
7					

The next step is to edit Host ID/WWN Mask. Move cursor bar through the menu items and press ENTER on the "Host ID/WWN Mask."

LUN Mask (ID Range) Configuration:

Ranges can be established by combining a basis ID with a mask similar to the way routing table entries are set up on a LAN/WAN. If the port name ID "AND'ed" with the mask equals the basis ID AND'ed with the mask, then the port name ID is considered to fall within the range. If a default value "0xFFFFFFFFFFFFFFF" is selected, then the port name ID must match the basis ID for the port name to be considered to fall within the range. "0x" means that all values are presented in hexadecimal. If, for instance, a value "0xFFFFFFFFFFFFFFC" is selected, and the basic ID is "0x1111111111111111," port name IDs ranging from "0x....1110" to "0x....1113" will fall in the ID range.

As the general rule, a host HBA's port name can be used as the basic ID. If a host adapter's port name is used as the basic ID and the default mask value, "0xFFFFFFFFFFFFFFF," is applied, the host will fall exactly within the ID range for the port name ID AND'ed with mask equals the basic ID AND'ed with mask.

Filter Type: Include or Exclude

Filter entry can serve both ends: to include or exclude certain adapters from data access.

Include: If a node's (a workstation or a server) WWN falls in an ID range specified as "Include," the node will be allowed to access the storage capacity mapped to the associated LUN. The access mode can be "read only" or "read/write."

Exclude: If a node's WWN falls in an ID range specified as "Exclude," the node will not be allowed to access the storage capacity mapped with this entry.

Multiple ranges, or filter entries, can be established for a single channel, target-ID, and LUN combination. Each range can have its own Exclude/Include attributes. The rules for determining whether a particular ID is considered as "included" or "excluded" are listed below:

1. If an ID falls within one or more Include ranges and does not fall in any Exclude range, then it is included.
2. If an ID falls within ANY Exclude range no matter if it also falls in another Include range, then it is excluded.
3. If the ID falls in none of the ranges and there is at least one Include range specified, then the ID should be considered as excluded.
4. If the ID falls in none of the ranges and only Exclude ranges are specified, then the ID is considered as included.

Access Mode: Read Only or Read/Write

A particular extended LUN map can be setup with an attribute of "Read Only" in the event that certain hosts may need to read the data on the media but must not be allowed to change it. In the degenerate case (range only includes a single ID), different hosts can be mapped with completely different logical drives/logical volumes/logical partitions even when they address the same channel, target-ID, and LUN.

When completed with configuring LUN mask, press [ESC] to map a logical unit to LUN.

LUN	LU/LD	DRU	Partition	Size(MB)	RAID
	Map		Logical Drive: 1	00	RAID5
	To		Partition : 1	00	RAID5
			Channel : 1	00	RAID5
			ID : 1	00	RAID5
			Lun : 4 ?		
	Yes		No	00	RAID5
4					
5					
6					
7					

Multiple filter entries can be created for a Host ID/LUN combination, select the Host LUN again to enter the editing menu.


LUN	LU/LD	DRU	Partition	Size(MB)	RAID
0	LD	1	0	3000	RAID5
1	LD	1	1	3000	RAID5
2	LD	3	0	3000	RAID5
3	LD	3	1	3000	RAID5
4					
	Map		View Host Filter Information		
	Cre		Add Host Filter Entry		
			Delete Host Filter Entry		
			Host ID - 0x10000000C920C738		
7					

You may continue to add more entries, to delete or edit the existing entries.

Sample Configuration:

Figure 8 - 4 LUN Filtering - Configuration Sample

LUN Filtering



1. Host HBA port name (WWPN) list:
 Host A = 0x...F111
 Host B = 0x...F112
 Host C = 0x...F222
2. Controller Configuration:
 - Logical drives are LD0 and LD1. LD0 is partitioned into two: P0 and P1.
 - Filter Entry (LUN map) list

Configuration Procedure:

1. Create an entry list for the specific logical unit from "View and Edit Host LUN"\Host Channel\Create Host Filter Entry."
2. Select Host Channel ID, and then select a configured logical unit (a logical drive, logical volume, or one of its logical partitions) to create the entry. The entry submenu will appear.
3. Enter and modify the **Host ID**, **Host ID Mask**, **Filter Type**, and **Access Mode**.

The exemplary entry list is shown below. Please refer to the diagram above:

Entry 1: "LD0-P0, ID=0x...F111, Mask=0x...FFFE, Filter Type = Include, Access Mode = Read/Write." It means Host A and B can read/write P0 of LD0.

Entry 2: "LD0-P1, ID=0x...F222, Mask=0x...FFFF, Filter Type = Exclude, Access Mode = Read/Write." It means Host A

and B can read/write P1 of LD0, but this partition is inaccessible for Host C.

Entry 3: "LD1-P0, ID=0x...F111, Mask=0x...FFFE, Filter Type = Include, Access Mode = Read Only." It means P0 of LD1 is 'Read Only' for Host A and B.

Entry 4: "LD1-P0, ID=0x...F222, Mask=0x...FFFF, Filter Type = Include, Access Mode = Read/Write." It means Host C can read/write P0 of LD1.

Advanced Configurations

This chapter aims to discuss the advanced options for configuring and maintaining a RAID system. Each function will be given a brief explanation as well as a configuration sample. Terminal screens will be used in the configuration samples. Some of the operations require basic knowledge of RAID technology and the practice of them is only recommended for an experienced user.

9.1 Fault Prevention

S.M.A.R.T.

With the maturity of technologies like S.M.A.R.T., drive failures can be predictable to a certain degree. Before S.M.A.R.T., being recurrently notified of drive bad block reassignments may be the most common omen for a drive about to fail. In addition to the S.M.A.R.T.-related functions as will be discussed later, a system administrator can also choose to manually perform “Clone Failing Drive” to a drive which is about to fail.

You can decide when to replace a drive showing symptoms of defects by a healthy drive. You may also replace any drive at will even when the source drive is healthy.

The “Clone Failing Drive” can be performed under the following conditions:

1. Replacing a failing drive either detected by S.M.A.R.T. or notified by the controller.
2. Manually replacing and cloning any drive with a new drive.

9.1.1 Clone Failing Drive:


Unlike the similar functions combined with S.M.A.R.T., the “Clone Failing Drive” is a manual function. There are two options for cloning a failing drive: “Replace after Clone” and “Perpetual Clone.”

Replace after Clone:


Data on the source drive, the drive with predicted errors (or any selected member drive), will be cloned to a standby spare and replaced later by the spare. The status of the replaced drive, the original member drive with predicted errors, will be redefined as an “used drive.” System administrators may replace the used drive with a new one, and then configure the new drive as a spare drive.

Locate the logical drive to which the specific member drive with predictable errors belongs. Select the “clone failing drive” function.

Select “Replace After Clone.” The controller will automatically start the cloning process using the existing “stand-by” (dedicated/global spare drive) to clone the source drive (the target member drive with predicted errors). If there is no standby drive (local/global spare drive), you need to add a new drive and configure it as a standby drive.



The cloning process will begin with a notification message. Press [ESC] to proceed.



The cloning process will be indicated by a status bar.

You may also quit the status bar by pressing [ESC] to return to the table of the connected drives. Select the drive indicated as “CLONING” by pressing [ENTER].

Slot	Chl	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
	2	0	319	20MB	0	ON-LINE	
	2	1	319	20MB	0	ON-LINE	
	2	2	319	20MB	0	ON-LINE	
	2	3	319	20MB	0	CLONING	
						EW DRV	
						EW DRV	
						EW DRV	
					NONE	NEW DRV	

V
S
a
I

Source Drive: Channel 2 ID 0
View clone progress
Abort clone
clone failing drive

Select “clone Failing drive” again to view the current status. You may identify the source drive and choose to “view clone progress,” or “abort clone” if you happen to have selected the wrong drive.

When the process is completed, users will be notified by the following message.

Drive Cloning
Notification

[21A2] LG:0 Logical Drive NOTICE:CHL:2 ID:3 Copy and Replace Completed

Perpetual Clone:

The standby spare will clone the source drive, member drive with predicted errors or any selected drive, without substituting it. The status of the spare drive will be displayed as “clone drive” after the cloning process. The source drive will remain a member of the logical drive.

In “View and Edit SCSI drives,” locate the member drive that shows predicted errors. Select “clone Failing drive,” and choose “Perpetual Clone.”

Cache Status: Clean

Slot	Chl	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
	2	0	319	20MB	0	ON-LINE	
						ON-LINE	
						ON-LINE	
					NONE	NEW DRV	
					NONE	NEW DRV	
					NONE	NEW DRV	
	2					NEW DRV	
	2					NEW DRV	

View drive information
Scan scsi drive
set slot Number
add drive Entry
Identify scsi drive
clone failing drive

Replace After Clone
Perpetual Clone

Perpetual Clone Drive ?
Yes No

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

The controller will automatically start the cloning process using the existing “stand-by” (local/global spare drive) to clone the source drive (the target member drive).

The cloning process will begin with a notification message:

```

Drive Cloning
Notification
[21A1] LG:0 Logical Drive NOTICE:CHL:2 ID:0 Starting Clone
  
```

Press **[ESC]** to view the current progress:

Quick view	Slot	Ch1	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
view	2	0	319	20MB	0	ON-LINE		
view	<div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%;"> Drive Copying <div style="border: 1px solid black; width: 100%; height: 10px; background-color: #ccc; margin-bottom: 5px;"> <div style="width: 35%; background-color: #333; height: 10px;"></div> </div> 35% Completed_ </div>							
view	2	4	319	20MB	NONE	NEW DRV		
view	2	5	319	20MB	NONE	NEW DRV		
view	2	6	319	20MB	NONE	NEW DRV		
view	2	8	319	20MB	NONE	NEW DRV		

You may also quit viewing the status bar by pressing **[ESC]** to return to the previous menu. Select the drive indicated as “CLONING” by pressing **[ENTER]**. Select “Clone Failing Drive” again to view the progress. You may identify the source drive and choose to “View clone progress” or “Abort clone” if you happen to have selected the wrong drive.

Quick view	Slot	Ch1	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
view	2	0	319	20MB	0	ON-LINE		
view	2	1	319	20MB	0	ON-LINE		
view	2	2	319	20MB	0	ON-LINE		
view	2	3	319	20MB	0	CLONE		
view	<div style="border: 1px solid black; padding: 5px; margin: 5px auto; width: 80%;"> Source Drive: Channel 2 ID 0 Replace original with clone Delete clone clone failing drive </div>							
view							EW DRV	
view							EW DRV	
view							EW DRV	
view							NONE	NEW DRV

The cloning progress will be completed by a notification message as displayed below:

```

Notification
[21A2] LG:0 Logical Drive NOTICE:CHL:2 ID:0 Clone Completed
  
```

You may press **[ESC]** to clear the notification message to see the SCSI drives’ status after the cloning process. The source drive (Channel 1 ID 5) remains as a member of logical drive “0,” and the “stand-by” drive (Channel 1 ID 2, the dedicated/global spare drive) has become a “CLONE” drive.

Quick view	Slot	Ch1	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
view	2	0	319	20MB	0	ON-LINE		
view	2	1	319	20MB	0	ON-LINE		
view	2	2	319	20MB	0	ON-LINE		
view	2	3	319	20MB	0	CLONE		
view	2	4	319	20MB	NONE	NEW DRV		
view	2	5	319	20MB	NONE	NEW DRV		
view	2	6	319	20MB	NONE	NEW DRV		
view	2	8	319	20MB	NONE	NEW DRV		

9.1.2 S.M.A.R.T. (Self-Monitoring, Analysis and Reporting Technology)

This section provides a brief introduction to S.M.A.R.T. as one way to predict drive failure and Infortrend's implementations with S.M.A.R.T. for preventing data loss caused by drive failure.

A. Introduction

Self-Monitoring, Analysis and Reporting Technology (S.M.A.R.T.) is an emerging technology that provides near-term failure prediction for disk drives. When S.M.A.R.T. is enabled, the drive monitors predetermined drive attributes that are susceptible to degradation over time.

If a failure is likely to occur, S.M.A.R.T. makes a status report available so that the host can prompt the user to back up data on the failing drive. However, not all failures can be predicted. S.M.A.R.T. predictability is limited to the attributes the drive can monitor which are selected by the device manufacturer based on the attribute's ability to contribute to the prediction of degrading or fault conditions.

Although attributes are drive specific, a variety of typical characteristics can be identified:

- head flying height
- data throughput performance
- spin-up time
- re-allocated sector count
- seek error rate
- seek time performance
- spin try recount
- drive calibration retry count

Drives with reliability prediction capability only communicate a reliability condition as either good or failing. In a SCSI environment, the failure decision occurs at the disk drive, and the host notifies the user for action. The SCSI specification provides a sense bit to be flagged if the disk drive determines that a reliability issue exists. The system then alerts the user/system administrator.

B. Infortrend's Implementations with S.M.A.R.T.

Infortrend is using ANSI-SCSI Informational Exception Control (IEC) document X3T10/94-190 standard.

There are four selections related to the S.M.A.R.T. functions in firmware:

Disable:

Disable S.M.A.R.T.-related functions

Detect Only:

S.M.A.R.T. function enabled, controller will send a command to enable all drives' S.M.A.R.T. function, if a drive predicts a problem, controller will report the problem in the form of an event log.

Perpetual Clone:

S.M.A.R.T. function enabled, controller will send a command to enable all drives' S.M.A.R.T. function. If a drive predicts a problem, controller will report in the form of an event log. Controller will clone the drive if there is a Dedicated/Global spare available. The drive with predicted errors will not be taken off-line, and the clone drive will still behave as a standby drive.

If the drive with predicted errors fails, the clone drive will take over immediately. Under the circumstance that the problematic drive is still working and another drive in the same logical drive should fail, the clone drive will resume the role of a standby spare and start to rebuild the failed drive immediately. This is to prevent a fatal drive error if yet another drive should fail.

Clone + Replace:

Controller will enable all drives' S.M.A.R.T. function. If a drive predicts a problem, controller will report in the form of event log. Controller will then clone the problematic drive to a standby spare and take the problematic drive off-line as soon as the cloning process is completed.

NOTE:


- *If you are using drives of different brands in your RAID system, as long as they are ANSI-SCSI Informational Exception Control (IEC) document X3T10/94-190 compatible, it should not be an issue working with the controller.*
-

Configuration Procedure


Enabling the S.M.A.R.T. Feature

Follow the procedure below to enable S.M.A.R.T. on all drives.

1. First, enable the “Periodic Drive Check Time” function. In \View and Edit Configuration Parameters\Drive-side SCSI Parameters\Periodic Drive Check Time, choose a time interval.



2. In \View and Edit Configuration Parameters\Drive-side SCSI Parameters\Drive Predictable Failure Mode <SMART>, choose one from “Detect Only,” “Detect, Perpetual Clone” and “Detect, Clone+Replace.”



Examining Whether Your Drives Support S.M.A.R.T.

To see if your drive supports S.M.A.R.T., follow the steps below:

1. Enable “S.M.A.R.T.” for your drives in the RAID system.
2. In “View and Edit SCSI Drives,” choose one drive to test to. Press **[ENTER]** on the drive, a sub-menu will appear.
3. Note that a new item “Predictable Failure Test” appears in the sub-menu. If the SMART” feature is not properly enabled, this item will not appear in the sub-menu.

Cache Status: Clean

Slot	Chl	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
2	0	319	20MB	0	ON-LINE		
2	5	319	20MB	NONE	NEW DRV		
2	6	319	20MB	NONE	NEW DRV		
2	8	319	20MB	NONE	NEW DRV		

View drive information
 Scan scsi drive
 set slot Number
 add drive Entry
 Identify scsi drive
Predictable failure test

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

4. Choose “Predictable Failure Test,” the controller will force the drive to simulate predictable drive errors.

Slot	Chl	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID
2	0	319	20MB	0	ON-LINE		
2	8	319	20MB	NONE	NEW DRV		

View drive information
 Scan scsi drive
 set slot Number
 add drive Entry
 Identify scsi drive
Predictable failure test

Test Drive Predictable Failure(SMART) ?
 Yes No

5. Press **[ENTER]**, and after a while (the next time the controller performs “Periodic Drive Check”), the controller will detect the errors simulated by the drive. An error message displays like this: “[1142] SMART-CH:? ID:? Predictable Failure Detected (TEST).” If this error message appears, it means your drive supports S.M.A.R.T. features.

Warning

[1115] CHL:2 ID:0 SCSI Drive ALERT: Unexpected Sense Received (526)

6. Otherwise, you may simply refer to related documentation or contact drive manufacturer for information about whether the drive model and drive firmware version support S.M.A.R.T..

Using S.M.A.R.T. Functions

1. Enable “SMART” on the RAID controller.

2. Make sure your drives do support S.M.A.R.T. so that your system will work fitly.

3. The “Detect Only” Setting:

3a. In \View and Edit Configuration Parameters\Drive-side SCSI Parameters\Drive Predictable Failure Mode <SMART>, choose “Detect Only.”




3b. Whenever a drive predicts symptoms of predictable drive failure, controller will issue an error message.

4. The “Detect, Perpetual Clone” Setting:

4a. In \View and Edit Configuration Parameters\Drive-side SCSI Parameters\Drive Predictable Failure Mode <SMART>, choose “Detect, Perpetual Clone.”

4b. You should have at least one spare drive for the logical drive (either Local Spare or Global Spare Drive).

4c. When a drive (logical drive member) detects the predictable drive errors, the controller will “clone” the drive with a spare drive. You may enter the "View and Edit SCSI Drive" menu and click on the spare drive (either a local or a global one). Choose from the menu items if you want to know about the status of the source drive, the cloning progress, or to abort cloning.



NOTE:

- *With the precaution of untimely drive failure of yet another drive, when configured as “perpetual clone,” the spare drive will only stay mirrored to the source drive (the drive with signs of failure), but not replacing it until the source drive actually fails.*
-

4d. When the spare drive is mirroring the source drive, any occurrence of drive failure (when there is no other spare drives) will force the spare drive to give up the mirrored data and resume its original role – it will become a spare drive again and start rebuilding the failed drive.

5. The “Detect, Clone+Replace” Function:

- 5a.** In \View and Edit Configuration Parameters\Drive-side SCSI Parameters\Drive Predictable Failure Mode <SMART>, choose “Detect, Clone+Replace.”
- 5b.** Make sure you have at least one spare drive to the logical drive. (Either Local Spare Drive or Global Spare Drive)
- 5c.** When a drive (a logical drive member) detects the predictable drive failure, the controller will “clone” the drive with a spare drive. After the “clone” process is completed, it will replace the source drive immediately. The source drive will be stated as a used drive.


If you want to see the progress of cloning, press **[ESC]** to clear the notification message and see the status bar.

The source drive’s status will be defined as an “Used drive” and will be immediately replaced and pulled off-line. This drive should be replaced with a new one as soon as possible.

9.2 Host-side and Drive-side SCSI Parameters

Foreword: SCSI Channel, SCSI ID and LUN

Figure 9 - 1 SCSI ID/LUNs A SCSI channel (SCSI bus) can connect up to 15 devices (not including the SCSI controller itself) when the Wide function is enabled (16-bit SCSI). It can connect up to 7 devices (not including the controller itself) when the Wide function is disabled (8-bit SCSI). Each device has one unique SCSI ID. Two devices contending for the same SCSI ID are not allowed.




The figure on the left is a good example. If you are to file document into a cabinet, you must put the document into one of the drawers. From a SCSI's point of view, a SCSI ID is like a cabinet, and the drawers are the LUNs. Each SCSI ID can have up to 32 LUNs (Logical Unit). Data can be stored into one of the LUNs of the SCSI ID. Most SCSI host adapters treat an LUN like another SCSI device.

The same holds true for a Fibre channel host interface. 32 LUN's are supported with each host ID and up to 1024 LUN's configurable per controller.

9.2.1 Host-side SCSI Parameters

Maximum Concurrent Host LUN Connection ("Nexus" in SCSI):


The configuration option adjusts the internal resources for use with a number of current host nexus. If there are four host computers (A, B, C, and D) accessing the array through four host IDs/LUNs (ID 0, 1, 2 and 3), host A through ID 0 (one nexus), host B through ID 1 (one nexus), host C through ID 2 (one nexus) and host D through ID 3 (one nexus) - all queued in the cache - that is called 4 nexus. If there are I/Os in the cache through 4 different nexus, and another host I/O comes down with a nexus different than the four in the cache (for example, host A access ID 3), controller will return "busy." Mind that it is "concurrent" nexus, if the cache is cleared up, it will accept four different nexus again. Many I/Os can be accessed via the same nexus.



From the main menu, select “View and Edit Configuration Parameters,” “Host-side SCSI Parameters,” then press [ENTER]. Choose “Max Number of Concurrent Host-LUN Connection,” then press [ENTER]. A list of available selections will appear. Move cursor bar to an item, then press [ENTER]. Choose **Yes** in the dialog box that follows to confirm your setting. The default is “4.”

Number of Tags Reserved for each Host-LUN Connection:


Each "nexus" has "32" (the default setting) tags reserved. When the host computer sends 8 of I/O tags to the controller, and the controller is too busy to process all, the host might start to send less than 8 tags during every certain period of time since then. This setting ensures that the controller will accept at least 32 tags per nexus. The controller will be able to accept more than that as long as the controller internal resources allow - if the controller does not have enough resources, at least 32 tags can be accepted per nexus.



Choose “Host-side SCSI Parameters,” then press [ENTER]. Choose “Number of Tags Reserved for each Host-LUN Connection,” then press [ENTER]. A list of available selections will appear. Move cursor bar to an item, then press [ENTER]. Choose **Yes** in the dialog box that follows to confirm the setting.

Maximum Queued I/O Count:

This function allows you to configure the maximum number of I/O queue the controller can accept from the host computer.



Choose “Host-side SCSI Parameters,” then press **[ENTER]**. Choose “Maximum Queued I/O Count,” then press **[ENTER]**. A list of available selections will appear. Move cursor bar to an item, then press **[ENTER]**. Choose **Yes** in the dialog box that follows to confirm the setting.

The controller supports the following Host-side SCSI configurations: “Maximum Queued I/O Count,” “LUNs per Host SCSI ID,” “Num of Host-LUN Connect,” “Tag per Host-LUN Connect,” “Peripheral Dev Type Parameters,” and “Cyl/Head/Sector Mapping Config.”

LUNs per Host SCSI ID



Choose “LUNs per Host SCSI ID,” then press **[ENTER]**. A list of selections will appear. Move cursor bar to an item, then press **[ENTER]**. Choose **Yes** in the dialog box that follows to confirm the setting.

LUN Applicability:


If no logical drive has been created and mapped to a host LUN, and the RAID controller is the only device connecting to the host SCSI card, usually the operating system will not load the driver for the

host adapter. If the driver is not loaded, the host computer will not be able to use the in-band utility to communicate with the RAID controller. This is often the case when users want to start configuring a RAID using management software from the host. It will be necessary to configure the "Peripheral Device Type" setting for the host to communicate with the controller. If the "LUN-0's only" is selected, only LUN-0 of the host ID will appear as a device with the user-defined peripheral device type. If "all undefined LUNs" is selected, each LUN in that host ID will appear as a device with the user-defined peripheral device type.

Different "LUN applicability" selections are available: "Device Type" selection, "Device Qualifier Support," "Support Removable media," "LUN-0's only," and "All undefined LUNs." Please refer to the table of peripheral device setting for details concerning various operating systems.

Peripheral Device Type:

For connection without a preset logical unit to a host, the in-band SCSI protocol can be used for the host to "see" the RAID controller. Please refer to the reference table below. You will need to make adjustments in the following submenu: Peripheral Device Type, Peripheral Device Qualifier, Device Support for Removable Media, and LUN Application.



In-band (SCSI or Fibre):

What is In-band?

External devices require communication with the host computer for device monitoring and administration. In addition to the regular RS-232, in-band SCSI can serve as an alternative means of management communications. In-band SCSI translates the original configuration commands into standard SCSI commands. These SCSI commands are then sent to and received by the controller over the existing host link, be it SCSI or Fibre.

Peripheral Device Type Parameters for Various Operating Systems:

A host can not “see” a RAID controller **UNLESS** the following is configured:

- (1) a logical unit has been created
 - (2) at least a logical unit is mapped to a host ID or LUN via the RS-232/front panel interface
- (1) the "in-band SCSI" connection with the host is established.
 - (2) the RAID controller is configured to appear as a peripheral device on the channel bus connected to host

If users want to start configuring a RAID system from the host before any RAID configuration is made, the host will not be able to “see” the RAID controller. In order for a host to “see” the controller, it will be necessary to define the controller as a peripheral device.

Different host operating systems require different adjustments. See the tables below to find the proper settings for your host operating system. References to “Peripheral Device Qualifier” and “Device Support for Removable Media” are also included.




Table 9 - 1 Peripheral Device Type Parameters

Operating System	Peripheral Device Type	Peripheral Device Qualifier	Device Support for Removable Media	LUN Applicability
Windows NT® 4.0	0x1f	connected	disabled	All Undefined LUNs
NetWare® 4.x/Windows 2000	0x03	connected	disabled	All Undefined LUNs
SCO OpenServer 5.0x	0x7f	connected	either is okay	All Undefined LUNs
SCO UnixWare 2.1x, UnixWare 7	0x03	connected	either is okay	All Undefined LUNs
Solaris™ 2.5.x/2.6 (x86 and SPARC)	0x7f	connected	either is okay	All Undefined LUNs
Linux	0x03	connected	enabled	All Undefined LUNs

Table 9 - 2 Peripheral Device Type Settings:

Device Type	Setting
No Device Present	0x7f
Direct-access Device	0
Sequential-access Device	1
Processor Type	3
CD-ROM Device	5
Scanner Device	6
MO Device	7
Storage Array Controller Device	0xC
Unknown Device	0x1f

Cylinder/Head/Sector Mapping:

Drive capacity is decided by the number of blocks. For some operating systems (Sun Solaris...etc.) the capacity of a drive is determined by the cylinder/head/sector count. For Sun Solaris, the cylinder cannot exceed 65535, users can choose "cylinder<65535," then the controller will automatically adjust the head/sector count for your OS to read the correct drive capacity. Please refer to the related documents provided with your operating system for more information.

Cylinder, Head, and Sector counts are selectable from the configuration menus shown below. To avoid the difficulties with Sun Solaris configuration, the values listed below can be applied.

Table 9 - 3 Cylinder/Head/Sector Mapping under Sun Solaris

< 64 GB	?	64	32
64 - 128 GB	?	64	64
128 - 256 GB	?	127	64
256 - 512 GB	?	127	127
512 GB - 1 TB	?	255	127


Older Solaris versions do not support drive capacity larger than 1 terabyte.

Configuring Sector Ranges/Head Ranges/Cylinder Ranges:


Selecting Sector Ranges



Selecting Head Ranges



Selecting Cylinder Ranges




9.2.2 Drive-side Parameters:



Choose “Drive-side SCSI Parameters,” then press **[ENTER]**. The Drive-side SCSI parameters menu displays.

SCSI Motor Spin-Up



When power supply is unable to provide sufficient current to start all the hard drives at once, you may have the drives spinning-up in a sequence to solve the problem with low power-up current.


By default, all hard drives will start spinning up when powered-on. These hard drives can be configured so that drives will not spin-up all at the same time. There are 3 methods for spinning-up the hard drive’s motor: “Spin-up at power-on,” “Spin-up serially at random sequence” or “Spin-up by SCSI command.” Please refer to the hard drive’s documentation for instructions on configuring the hard drive using the “Spin-up by SCSI Command.” The procedure for each brand/model of hard drive may vary.

Configure all hard drives (usually by switching jumpers on hard disks). Choose “SCSI Motor Spin-Up,” then press **[ENTER]**. Choose **Yes** in the dialog box that follows to confirm the setting.

Power off all hard drives and controller, and power them on again. Hard drives will not spin-up all at once. The controller will spin-up the hard drives one at a time at the interval of four seconds.

Disk Access Delay Time

Sets the delay time before the controller tries to access the hard drives after power-on. Default is 15 seconds.



Choose “Disk Access Delay Time,” then press **[ENTER]**. A list of selections displays. Move cursor bar to a selection, then press **[ENTER]**. Choose **Yes** in the dialog box that follows to confirm the setting.

SCSI I/O Timeout


The “SCSI I/O Timeout” is the time interval for the controller to wait for a drive to respond. If the controller attempts to read data from or write data to a drive but the drive does not respond within the SCSI I/O timeout value, the drive will be considered as a failed drive.

When the drive itself detects a media error while reading from the drive platter, it usually retries the previous reading or re-calibrates the head. When the drive encounters a bad block on the media, it reassigns the bad block onto a spare block. However, it takes time to perform the above actions. The time to perform these operations can vary between different brands and models of drives.

During SCSI bus arbitration, a device with higher priority can utilize the bus first. A device with lower priority will sometimes receive a SCSI I/O timeout when devices of higher priority keep utilizing the bus.


The default setting for “SCSI I/O Timeout” is 7 seconds. It is highly recommended not to change this setting. Setting the timeout to a lower value will cause the controller to judge a drive as failed while a drive is still retrying, or while a drive is unable to arbitrate the SCSI bus. Setting the timeout to a greater value will cause the

controller to keep waiting for a drive, and it may sometimes cause a host timeout.



Choose “SCSI I/O Timeout –Default (7 seconds),” then press **[ENTER]**. A list of selections will appear. Move cursor bar to a selection, then press **[ENTER]**. Choose **Yes** in the dialog box that follows to confirm the setting.

Maximum Tag Count (Tag Command Queuing)



The controller supports tag command queuing with an adjustable maximum tag count from 1 to 128. The default setting is “Enabled” with a maximum tag count of 32. Choose “Maximum Tag Count”, then press **[ENTER]**. A list of available tag count numbers displays. Move cursor bar to a number, then press **[ENTER]**. Choose **Yes** in the dialog box that follows to confirm the setting.

IMPORTANT!

- *Every time you change this setting, you must reset the controller for the changes to take effect.*
 - *Disabling Tag Command Queuing will disable hard drives’ built-in cache for Write-Back operation.*
-

Detection of Drive Hot Swap Followed by Auto Rebuild

```

QuickView
view SCSI Motor Spin-Up Disabled
view SCSI Reset at Power-Up Disabled
view Disk Access Delay Time - 60 seconds
view SCSI I/O Timeout - 10 seconds
view Maximum Tag Count - 32
view Periodic Drive Check Time - 10 seconds
view Periodic SAF-TE and SES Device Check Time - 5 seconds
view Periodic Auto-Detect Failure Drive Swap Check Time - Disabled
view Drive Predictable Failure Mode(SMART) -Detect Only
view Fibre Channel Dual Loop - Enabled
view Drive-side SCSI Parameters
view Disk Array Parameters
view Redundant Controller Parameters
view Controller Parameters

```

Choose “Periodic Auto-Detect Failure Drive Swap Check Time”; then press **[ENTER]**. Move the cursor to the desired interval; then press **[ENTER]**. Choose **Yes** in the dialog box that follows to confirm the setting.

The controller scans drive buses at this interval to check if a failed drive has been replaced. If a failed drive is replaced, the controller will proceed with the rebuild process.

SAF-TE and S.E.S. Enclosure Monitoring

```

QuickView
view SCSI Motor Spin-Up Disabled
view SCSI Reset at Power-Up Disabled
view Disk Access Delay Time - 60 seconds
view SCSI I/O Timeout - 10 seconds
view Maximum Tag Count - 32
view Periodic Drive Check Time - 10 seconds
view Periodic SAF-TE and SES Device Check Time - 5 seconds
view Periodic Auto-Detect Failure Drive Swap Check Time
view Drive Predictable Failure Mode(SMART) -Detect Only
view Fibre Channel Dual Loop - Enabled
view Drive-side SCSI Parameters
view Disk Array Parameters
view Redundant Controller Parameters
view Controller Parameters


```

If there are remote devices in your RAID enclosure being monitored via SAF-TE/S.E.S., use this function to decide at what interval the controller will check the status of these devices. Choose “Periodic SAF-TE and SES Device Check Time”; then press **[ENTER]**. Move the cursor to the desired interval; then press **[ENTER]**. Choose **Yes** in the dialog box that follows to confirm the setting.

Periodic Drive Check Time

The “Periodic Drive Check Time” is the time interval for the controller to check all disk drives that were on the SCSI bus at controller startup (a list of all the drives that were detected can be seen under “View and Edit SCSI Drives”).

The default value is “Disabled.” “Disabled” means that if a drive is removed from the bus, the controller will not be able to know – so long as no host accesses that drive. Changing the check time to any other value allows the controller to check – at the selected time interval – all of the drives that are listed under “View and Edit SCSI Drives.” If any drive is then removed, the controller will be able to know – even if no host accesses that drive.



Idle Drive Failure Detection

Periodic Auto-Detect Failure Drive Swap Check Time

The “Drive-Swap Check Time” is the interval at which the controller checks to see whether a failed drive has been swapped. When a logical drive’s member drive fails, the controller will detect the failed drive (at the selected time interval). Once the failed drive has been swapped with a drive that has adequate capacity to rebuild the logical drive, the rebuild will begin automatically.

The default setting is “Disabled,” meaning that the controller will not Auto-Detect the swap of a failed drive. To enable this feature, select a time interval.



Choose “Periodic Drive Check Time;” then press [ENTER]. Move cursor to the desired interval; then press [ENTER]. Choose **Yes** in the dialog box that follows to confirm the setting.

IMPORTANT!

- *The "Periodic Drive Check Time" is enabled by choosing a time value. The RAID controller will poll all connected drives through the controller's drive channels at the assigned interval. Drive removal will be detected even if a host does not attempt to access data on that specific drive.*
 - *If the "Periodic Drive Check Time" is set to "Disabled" (the default setting is "Disabled"), the controller will not be able to detect any drive removal that occurs after the controller has been powered on. The controller will only be able to detect drive removal when a host attempts to access data on that drive.*
-

Auto-Assign Global Spare Drive

```
< Main Menu >
Quick installation
view and edit Logical drives
view and edit Logical Volumes
view and edit Host luns
view and edit scsi Drives
view
view SCSI Motor Spin-Up - Disabled
v SCSI Reset at Power-Up - Enabled
s Disk Access Delay Time - 15 seconds
C SCSI I/O Timeout - 10 seconds
v Maximum Tag Count - 32
H Periodic Drive Check Time - 1/2 seconds
D Periodic SAF-TE and SES Device Check Time - 200 ms
R Periodic Auto-Detect failure Drive Swap Check Time - 5 seconds
C Drive Predictable Failure Mode(SMART) -Disabled
Auto-Assign Global Spare Drive - Enabled
Auto-Assign Global Spare Drive - Disabled
```


The "Auto-Assign" function automatically use "New" or "Used" drives that are not included in any logical configurations as global spares. In the event of multiple drive failure, having more hot-spares can reduce the chance of failing more than one drive in an array.

Note that if a drive has a capacity smaller or apparently larger than the members of configured arrays, the controller may avoid using it as a global spare.

Select “View and edit Peripheral Devices” on the main menu and press [ENTER]. Choose “Set Peripheral Device Entry” and “Event Trigger Option” by pressing [ENTER]. The auto-shutdown option displays.


Select a configurable time span between the detection of exceeded temperature and the controller’s commencing an automatic shutdown.

9.4 Disk Array Parameters



Select “View and edit Configuration parameters” on the main menu and press [ENTER]. Choose “Disk Array Parameters,” then press [ENTER] again. The Disk Array Parameters menu will appear.

Rebuild Priority




Choose “Rebuild Priority,” then press [ENTER]. A list of the priority selections (Low, Normal, Improved, or High) displays. Move cursor bar to a selection, then press [ENTER].

Verification on Writes


Errors may occur when a hard drive writes data. To avoid the write error, the controller can force hard drives to verify written data. There are three selectable methods:

- Verification on LD Initialization Writes
Performs Verify-after-Write when initializing a logical drive
- Verification on LD Rebuild Writes
Performs Verify-after-Write during rebuild process
- Verification on LD Normal Drive Writes
Performs Verify-after-Write during normal I/Os

Each method can be enabled or disabled individually. Hard drives will perform Verify-after-Write according to the selected method.



Move cursor bar to the desired item, then press [ENTER].



Choose **Yes** in the confirm box to enable or disable the function. Follow the same procedure to enable or disable each method.

IMPORTANT!

- *The “verification on Normal Drive Writes” method will affect the “write” performance of your RAID system during normal use.*
-

9.5 Controller Self-Monitoring

Open your PC Terminal Emulation screen. Enter the main menu and select “View and Edit Peripheral Devices.” Use the arrow keys to scroll down and select “Controller Peripheral Device Configuration,” “View Peripheral Device Status,” and then press **[ENTER]**.

ITEM	VALUE	STATUS
+3.3V	3.384V	Operation Normally
+5V	5.153V	Operation Normally
+12V	12.199V	Operation Normally
CPU Temperature	35.0 (C)	Temperature within Safe Range
Board1 Temperature	56.0 (C)	Temperature within Safe Range
Board2 Temperature	38.0 (C)	Temperature within Safe Range
Cooling FAN 0	6750 RPM	Operation Normally
Cooling FAN 1	7031 RPM	Operation Normally


The controller operation status displays. Note the fan status here refers to the 3cm fans in the front panel of RAID controllers that come standard in 5.25” canister.

9.5.1 Changing Monitoring Thresholds


Open your PC Terminal Emulation utility. Enter the main menu and select “View and edit Peripheral devices.” Use the arrow keys to scroll down and select “Controller Peripheral Device Configuration,” “Voltage and Temperature Parameters,” and confirm by pressing **[ENTER]**.

Note that it is not recommended to change the threshold values unless you need to coordinate the RAID controller’s values with that of your RAID enclosure. If a value exceeding the safety range is entered, an error message will prompt and the new parameter will be ignored.


Under specific circumstances, for example, the controller operates in a system enclosure where the upper limit on ambient temperature is relatively high or low, adjusting the default thresholds can coordinate the controller status monitoring with that of the system enclosure.




Scroll down and select an item to configure.



Select an item, for instance, “Trigger Thresholds for CPU Temperature Events.” Press **[ENTER]** and a list of selections will appear. You can change the upper or lower threshold values. Press **[ENTER]** to confirm.



A configuration window will prompt. Enter any value within the safety range. Value exceeding the safety range will be rejected by controller firmware.



Follow the same method to modify other threshold parameters.

10.1 Operation Theory

Sample topologies using redundant controllers can be found in the *Hardware Manual* that came with your controller or subsystem. The proceeding discussions will focus on the theories behind and the configuration procedure for readying a redundant controller system.

Today's I/O interfaces have increasing demands on signal quality. We assume that reliable inter-connections have already been made with combining controllers' channels either through a common backplane or cabling connection. Depending on enclosure design, signal paths for communications may have been strung between controllers over a common backplane. Your controllers or subsystems, such as Infortrend's EonStor series, may come with preset IDs and channel mode setting, and require no further configuration.

Users who are familiar with the practice of redundant controller configuration, please jump to section "*10.3 Configuration.*"

This chapter includes the following topics:

Operation Theory

- 10.1.1 Considerations Related to Physical Connection
- 10.1.2 Grouping Hard Drives and LUN Mapping
- 10.1.3 Fault-Tolerance

Preparing controllers

- 10.2.1 Requirements:
- 10.2.3 Configurable Parameters


Configuration Procedure

- 10.3 Configuration
- 10.3.1 Setup Flowchart
- Redundant Configuration Using Automatic Setting
- Controller Unique ID
- Creating Primary and Secondary ID
- Assigning a Logical Drive/Logical Volume to the Secondary Controller
- Mapping a Logical Drive/Logical Volume to the Host LUNs
- Terminal Interface View of Controller Failure
- Forcing Controller Failover for Testing

10.1.1 Considerations Related to Physical Connection

Using SCSI-Based Controllers

Figure 10 - 1 Dual-Controller Setting Using SCSI-Based Controllers



The physical connection between redundant controllers should be similar to the one shown above. The basic configuration rules are:

1. All channels should be connected to both controllers as diagrammed above or strung across via a common backplane. Disk drives or drive enclosure are connected to both controllers.

2. Cached writes are constantly duplicated in both controllers' memory over a dedicated SCSI channel. The default path for controller communications (SCSI-based controllers) is channel 0.


Channel 0 is also the default for host interface; therefore, avail other channel(s) for host connection by changing its channel mode. See Chapter 5 or Chapter 7 for details about channel mode configuration.

3. SCSI channels should be terminated on both ends. It is recommended to use the termination jumpers on the controllers to configure bus termination setting. SCSI Terminators are provided on controllers' back-end PCBs. This design allows a controller to be removed during the controller failover process.

Using Fibre-Based Controllers

Connection between controllers is more flexible with the Fibre-based controllers.

Figure 10 - 2 Dual-Controller Setting Using Fibre-Based Controllers



The basic configuration rules are:

1. All channels should be connected to both controllers as diagrammed above.
2. To reduce chance of downtime, more than one hub or switch can be used to connect to host computer(s) for path redundancy. Drive-side dual loop is supported. Host-side dual loop requires the support of host management software.

3. For the Fibre-to-Fibre controllers or RAID systems, there are two options with the communications loops between controllers:

1). Dedicated Communications Loops – “Dedicated RCC”

The first option is choosing one or two Fibre loops as the dedicated communications paths. Two for communications is recommended for the path redundancy it provides.

Using two channels for the communications offers a greater throughput and hence a better performance.

2). Communications over Drive Loops – “Drive + RCC”

Configure all drive loops into the “Drive + RCC” mode to let them share the communications traffic. The controllers can automatically distribute the communications traffic across all drive loops.

Workflow is balanced among loops. Using the drive + RCC mode allows more channels to be used for drive connection. With a 6-channel controller, for instance, there can be as many as two channels for host and four channels for drives (drive + RCC). All channels can be used for IO traffic while the system is still benefited from controller communications.

10.1.2 Grouping Hard Drives and LUN Mapping

Listed below are the array setting options that need to be considered when planning a dual-controller system:


1. **H**ow many logical drives, logical volumes, or logical partitions, and of what sizes?
2. **S**ystem drive mapping (primary/secondary ID): how many storage volumes will appear to which host port? and managed by which controller?
3. **W**ill those storage volumes be accessed in a multi-host or multi-path configuration? as shared storage volumes?
4. **F**ault Tolerance: Configure the controllers so that they can failover and failback in a way transparent to host. See 10.1.3 Fault-Tolerance for more details.

Logical Drive, Logical Volume, and Logical Partitions

Listed below are the basics about configuring a logical drive for a redundant controller system:


- All configuration options are accessed through the Primary controller. In redundant mode, two controllers behave as one, and there is no need to repeat the configuration on another controller.
- Disk drive and array configuration processes are the same no matter using single or redundant controllers.
- Using logical configurations of drives as base units, system workload can be distributed to different controllers. Logical units can be manually assigned to different controllers to facilitate the active-active configuration.
- There is no limitation on drive allocations. The members of a logical drive do not have to come from the same drive channel. Grouping drives from different drive channels helps reduce the chance of downtime by channel bus failure.
- Each logical drive can be configured in a different RAID level and several logical drives can be striped across to compose a larger logical volume.
- Each of the logical units (logical drives, logical volumes, or one of their partitions) can be made available on host ports through host LUN mapping. Each of these associated host ID/LUNs appears as a virtual hard drive.

Figure 10 - 3 Grouping Hard Drives



- As diagrammed above, choosing members to compose an array can be flexible. You may divide a logical drive or logical volume into several partitions as diagrammed below, or use the entire logical drive as a single partition, with or without the support of one or several spare drives.

Figure 10 - 4 Partitioning of Logical Units



- Each logical unit can be associated (mapped) with a host ID (pre-configured as a Primary or Secondary ID) or the LUN numbers under host IDs.

System Drive Mapping:

Primary and Secondary IDs

- **Host Channel:**

When controllers are successfully combined, the array capacity is available through host port IDs, and these IDs are available as “Primary” or “Secondary” IDs.

- **Drive Channel:**

Since all channels are strung between two controllers, each channel is connected to two chip processors, and each processor must occupy one channel ID. In redundant mode, both a Primary and a Secondary ID must be present on all drive channels.

- **Primary-Secondary Relationship:**

The Primary-Secondary relationship between the controllers is automatically determined by firmware. For some subsystem models, the relationship is determined by the controller slot. Refer to your hardware manual for details.


- **Create IDs:**

You may have to create Primary and Secondary IDs separately on the host and drive channels if these IDs are not available. The configuration procedure will be discussed in section "10.3 Configuration".

Mapping


- A logical unit made available through a Primary ID will be managed by the Primary controller, and that through a Secondary ID by the Secondary controller.
- Each channel ID (or an LUN under ID) will act as one virtual storage volume to the host computer.

Figure 10 - 5 Mapping System Drives (Mapping LUNs)



- The diagram above displays a single host computer with two HBA cards allowing the connection of dual I/O paths. A host port ID is presented on each host port as Primary ID or Secondary ID. Users may then map any logical configuration of drives to these ID or LUN numbers. The result is that workload can be distributed across two host ports and managed by both controllers.

Figure 10 - 6 Mapping System Drives (IDs)



- Some operating systems do not read multiple LUNs under single ID. As diagrammed above, you may have the host channel to present several IDs and map logical configurations to these IDs. Each of these IDs can be identified as Primary or Secondary. As a rule for most operation systems, each configuration unit will be mapped to LUN0 under each ID.

10.1.3 Fault-Tolerance

What Is a Redundant Controller Configuration?

Hardware failures can occur. A simple parity error can sometimes cause a RAID system to completely hang up. Having two controllers working together will guarantee that at least one controller will survive catastrophes and keep the system working. This is the logic behind having the redundant controllers – to minimize the best we could the chance of down time for a storage subsystem.


A redundant controller system uses two controllers to manage the storage arrays. It requires two controllers to work together and both must be working normally. During normal operation, each controller serves its I/O requests. If one controller should fail, the existing controller will temporarily take over for the failed controller until it is replaced. The failover and failback processes are totally transparent to host and require only minimum efforts to restore the original configuration.

How does Failover and Failback Work?

A. Channel Bus

Below is a sample illustration of the redundant controller operation:

Figure 10 - 7 Redundant Controller Channel Bus



The host computer is connected to both the Primary and the Secondary controllers. Each controller has two of its SCSI/Fibre channels assigned as the host channels, and the other SCSI/Fibre channels assigned to drive connection.

There are two logical drives. Logical drive 0 is assigned to the Primary controller (mapped to the Primary ID), and logical drive 1 assigned to the Secondary controller (mapped to the Secondary ID). Should one controller fail, the existing controller will manage the logical drive once belonged to the failed controller via the once inactive ID (the standby ID).

The ID mapping is synchronized between the controllers. If one controller should fail, the surviving controller still keeps a replica of all configuration data. The related ID mapping on the controllers should look like the tables below:

Table 10 - 1 ID Mapping Status (Normal Operation)


Channel	ID	Status	Target Chip
0	0 (Primary ID)	Active	Pri. Controller channel 0
	1 (Secondary ID)	Standby	Sec. Controller channel 0
1	1 (Secondary ID)	Active	Sec. Controller channel 1
	0 (Primary ID)	Standby	Pri. Controller channel 1

In the event of controller failure (say, the Primary controller fails), the once inactive ID (chip) will become active:

Table 10 - 2 ID Mapping Status (Controller Failed)

Channel	ID	Status	Target Chip
0	0 (Primary ID)	Active	Pri. Controller channel 0 – Failed!
	1 (Secondary ID)	Standby- becomes Active!	Sec. Controller channel 0
1	1 (Secondary ID)	Active	Sec. Controller channel 1
	0 (Primary ID)	Standby	Pri. Controller channel 1- Failed!

Figure 10 - 8 Controller Failover



For every channel that is actively serving I/Os, there is another on the alternate controller that stays idle and will inherit the task should its counterpart fail.

As long as I/O bus bandwidth is not of the concern, many active IDs can co-exist on single or multiple host channels. Standby chips may not be necessary.

B. Controller Failover and Failback

In an unlikely event of controller failure, the surviving controller will acknowledge the situation and disconnect with the failed controller. The surviving controller will then behave as both controllers and serve all the host I/O requests.

System failover is transparent to host. System vendors should be contacted for an immediate replacement of the failed unit.

Replacing a Failed Unit:

Firmware Synchronization

The replacement controller should have the same amount of memory and running the same version of firmware. However, it is inevitable a replacement controller is usually running later revisions of firmware. To solve this problem, **Firmware Synchronization** is supported since firmware version 3.21. When the replacement controller is combined, the existing controller will downgrade the replacement's firmware so that both controllers will be running the same version of firmware.

Your system vendor should be able to provide an appropriate replacement controller.

Rolling Firmware Upgrade

When upgrading firmware in a redundant controller system, the Primary controller receives the new firmware. When appropriate time is found to reset both controllers, the Secondary controller's firmware is upgraded.

If host access is stopped and then firmware is upgraded, the controllers will flash new firmware and after controller reset, both controllers' firmware will be upgraded.

NOTE:

- Rolling firmware upgrade is not supported with controllers running firmware 3.27 and is to be upgraded to firmware 3.31.
-

Auto-Failback:

Once the failed controller is removed and a replacement controller is installed, the existing controller will acknowledge the situation. The existing controller should automatically attempt to combine with the replacement controller.

When the initialization process of the replacement controller is completed, the replacement controller will always inherit the status of the Secondary controller. The replacement controller will obtain all related configuration parameters from the existing controller. If the existing controller fails to re-establish this connection, you can also choose to "de-assert" the replacement controller through the existing controller so that both will serve the original system drive mapping.

C. Active-to-Active Configuration:


Active-to-active configuration conducts all system resources to performance. Storage volumes can be equally assigned to both controllers and thus both are actively serving I/Os. This allows a flexible association between logical units and host ID/LUNs. Workload can then be manually distributed between controllers.

D. Traffic Distribution

The diagram below illustrates a four-channel configuration using channel 0 as the communications path. Channel 1 serves as the host interface and multiple IDs are created to facilitate active-active operation. Each controller occupies either a Primary ID or a Secondary ID on drive channels. One logical unit is assigned to the Primary controller and the other the Secondary controller.

In the event when one controller fails, the existing controller will inherit IDs from the failed controller and continue I/Os.

Figure 10 - 9 Traffic Distribution




	Logical Drive 0	Logical Drive 1
Host LUN Mapping	ID0 / LUN* (PID)	ID1 / LUN* (SID)
Logical Drive Assignment	Primary	Secondary
Drive Channel	2	3

Users can assign a logical unit either to the Primary or to the Secondary controller. Once the assignment is done, logical unit(s) assigned to the Primary controller can only be mapped to the Primary IDs on host channel; Logical unit(s) assigned to the Secondary controller can only be mapped to the Secondary IDs on host channel.

The channel ID (Primary/Secondary) assignment for a SCSI controller should look like this:

	Primary Controller ID	Secondary Controller ID
Host Chl SCSI ID	PID = 0	SID = 1
Drive Chl SCSI ID	7 (or 8 for the dual redundant chassis)	6 suggested (or 9 for the dual redundant chassis)

Figure 10 - 10 Controller Failover



E. Controller Failure

Controller failure is managed by the surviving controller. The surviving controller disables and disconnects from its counterpart while gaining access to all signal paths. The existing controller then proceeds with the ensuing event notifications and take-over process. The existing controller is always the Primary controller regardless of its original status and any replacement combined afterwards will assume the role of the Secondary.

Symptoms

- LCD on the failed controller is off. LCD on the surviving controller displays controller failure message.
- The surviving controller sounds alarm
- The "ATTEN" LED flashing on the existing controller
- The surviving controller sends event messages notifying controller

Connection:

The channels of the two controllers that are connected together must be the same. For example, if controller A uses channel 2 to connect a group of drives, controller B must also use channel 2 to connect to the same group of drives.

10.2 Preparing Controllers

10.2.1 Requirements:

Cabling Requirements:

Communications Channels:

- Controller Communications (Cache Synchronization) Paths:

Controller	RCC cable
SentinelRAID	A SCSI cable (CH 0)
EonRAID 2510FR	Dedicated RCC or RCC over drive loops
EonStor	Pre-configured RCC routes over the system backplane

- Using one or two of the I/O channels for controller communications (as listed above) is necessary especially when write-back caching is preferred. If controllers are running in write-back mode, a battery module is recommended for each controller.

-

Out-of-Band Configuration

- RS-232C cable (for Terminal Interface Operation) connection.
- Ethernet connection: If management through Ethernet is preferred, connect the Ethernet interface from both controllers to ports on a hub. In the event of controller failure, the IP address assigned to the Primary controller will be inherited by the surviving controller. The Ethernet port connection will be continued.

Controller Settings: General Procedure

1. ***Enable Redundant Controller:***

"Main Menu"→ "View and Edit Peripheral Devices"→ "Set Peripheral Device Entry"→ "Redundant Controller Enable/Disable"

2. ***Controller Unique Identifier:***

Set unique identifier to each controller. "View & Edit Peripheral Devices"→ "Set Peripheral Device Entry"→ "Controller Unique Identifier." Enter a hex number between 0 and FFFFF (firmware 3.25 and above) for each controller.

3. ***Creating Primary and Secondary IDs on Drive Channels:***

"View and Edit SCSI Channels"→ Choose a Drive Channel→ "Primary/Secondary Controller SCSI ID."

4. ***Creating Primary and Secondary IDs on Host Channels:***

"View and Edit SCSI Channels"→ Choose a host channel→ "View and Edit SCSI ID"→ Choose a SCSI ID→ "Add/Delete Channel SCSI ID"→ "Primary/Secondary Controller"→ Add SCSI ID from the list. Reset the controller for the configuration to take effect.

5. ***Creating Logical Configurations of Drives and assigning each of them either to the Primary or the Secondary Controller:***

"View and Edit Logical Drives"→ Select a RAID level→ Select member drives→ "Logical Drive Assignments"→ Create Logical Drive.

6. ***Map Each Logical Configuration of Drives to the Primary/ Secondary ID on host channel(s):***

"View and Edit Host LUN"→ Choose a "host channel-ID-controller" combination→ Choose Logical Drive/Logical Volume/Physical SCSI Drive→ Map to Host LUN (Create Host LUN Entry).

NOTE:

- *The redundant controller function can be enabled via the front keypad or a terminal emulation program. Section 10.3 Configuration describes the procedures for using the terminal emulation and LCD front panel. The same result can be achieved regardless of the interface used.*
-

10.2.2 Limitations

- Both controllers must be exactly the same. Namely, they must operate with the same firmware version, the same size of memory, the same number of host and drive channels, etc. If battery backup is preferred, both should be installed with a battery module.
- The takeover process should take less than one second (using SCSI or Fibre for controller communications) to complete.
- In redundant mode, each controller takes an ID on each channel bus. This leaves the maximum number for disk drives on a SCSI bus to be 14.
- Connection through Fibre hubs or switches is necessary for joining host (Fibre) interfaces between controllers. The EonRAID 2510FR is an exception. Its type-1 ports come with an onboard hub.
- The controller defaults for ID settings are listed below:

Host interface	Host channel (Primary/Secondary)	Drive channel (Primary/Secondary)
SCSI	0 / 1...	7 / 6
Fibre	112 / 113...	119 / 120

- SCSI IDs 8 (PID) and 9 (SID) are the recommended defaults to the drive channels of the SCSI-based dual-controller chassis using an integrated backplane.

10.2.3 Configurable Parameters

Primary or Secondary

If necessary, users can specify a particular controller as Primary or Secondary. By setting each controller to the "Autocfg" mode, the controllers will decide between themselves which is the Primary and which is the Secondary.

The controller firmware recognizes the two controllers used in a redundant configuration as Primary or Secondary. Two controllers behave as one Primary controller.

Once the redundant configuration takes effect, user's configurations and settings can only be done on the Primary controller. The Secondary controller then synchronizes with the configuration of the Primary controller, making the configurations of two controllers exactly the same.

The two controllers continuously monitor each other. When a controller detects that the other controller is not responding, the working controller will immediately take over and disable the failed controller. However, it is not predictable which one of the controllers should fail. It is necessary to connect all other interfaces to both controllers so that a surviving controller can readily continue all the services provided for the RAID system.

Active-to-Active Configuration

Users can freely assign any logical configuration of drives to both or either of the controllers, then map the logical configurations to the host channel IDs/LUNs. I/O requests from host computer will then be directed to the Primary or the Secondary controller accordingly. The total drive capacity can be divided and equally serviced by both controllers.

The active-to-active configuration engages all system resources to performance. Users may also assign all logical configurations to one controller and let the other act as a standby.

Active-to-Standby Configuration

By assigning all the logical configurations of drives to one controller, the other controller will stay idle and becomes active only when its counterpart fails.

Cache Synchronization

The Write-back caching significantly enhances controller performance. However, if one controller fails in the redundant controller configuration, data cached in its memory will be lost and data inconsistency might occur when the existing controller attempts to complete the writes.

Data inconsistency can be avoided using one or several of the I/O channels as the communications path between the controllers. The cached data is always synchronized in each other's memory. Each controller saves an exact replica of the cache content on its counterpart. In the event of controller or power failure, the unfinished writes will be completed by the existing controller.

Battery Support

Unfinished writes will be cached in memory in write-back mode. If power to the system is discontinued, data stored in the cache memory will be lost. Battery modules can support cache memory for a period of several days allowing the controller to keep the cached data. When two controllers are

operating in write-back mode, it is recommended to install a battery module to each controller.


10.3 Configuration

Listed below are steps necessary for configuring a redundant controller system:

1. Configure, separately, each controller in the "**Autoconfig**" mode. When two controllers are powered on later, firmware will determine which is the Primary controller.
2. If a channel is used as the communications channel, firmware will display channel status as "**RCCOM** (Redundant Controller Communications)." This channel will then be excluded from the use of host/drive connection.
3. When powering on both controllers together, LCD will display "**RC connecting**." After the controller negotiation is completed, the communications between controllers should be established.
4. Configure your SCSI/Fibre channels as host or drive. The default configuration for SCSI channel termination is "enabled." Please refer to Appendix D of your controller *Hardware Manual* and examine whether the termination jumpers on controller backplane are shunted. If the associated jumpers are shunted, SCSI channels will be terminated on the controller side no matter firmware setting is "enabled" or "disabled."
5. Create both a "Primary ID" and a "Secondary ID" on every drive channel.
6. Reset controller for the configuration to take effect.
7. Create Logical drives/logical volumes and assign each logical unit to the Primary or to the Secondary controller.
8. Proceed with Host LUN mapping. After mapping each logical unit to a Primary or Secondary ID/LUN on the host channel(s), the redundant controller configuration is complete.

10.3.1 Setup Flowchart

Figure 10 - 1 Redundant Controller Configuration Flowchart



NOTE that some of Infortrend's dual-controller configurations come with pre-set IDs for users' ease of configuration. It is, however, always best to check these IDs before proceeding with configuration.

10.3.2 Via Front Panel Keypad

Redundant Configuration Using Automatic Setting

Power-on Controller 1. Make sure Controller 2 is powered-off.

1. Enable Redundant Controller

Press [ENT] for two seconds on the front panel of controller 1 to enter the main menu. Use ▼ or ▲ to navigate through the menus. Choose "View and Edit Peripheral Dev.. (View and Edit Peripheral Devices)," then press [ENT].

View and Edit
Peripheral Dev

Choose "Set Peripheral Devices Entry," then press [ENT].

Set Peripheral
Devices Entry

Choose "Redundant Ctlr Function__", and then press [ENT]. (Note: The current setting will be displayed on the LCD) If this controller has never been set as a redundant controller before, the default setting of the redundant controller function is "Disabled." The message "Redundant Ctlr Function Disable" will be displayed on the LCD. Press [ENT] to proceed.

```
Redundant Ctlr
Function Disable
```

Autoconfig.

The message "Enable Redundant Ctlr: **Autocfg**?" will appear. Use ▼ or ▲ to scroll through the available options ("**Primary**," "**Secondary**," or "**Autocfg**"), then press [ENT] for two seconds to select "Autocfg."

```
Enable Redundant
Ctlr: Autocfg ?
```

For the other controller is currently not connected, status will be indicated as "Inactive." Once set, press [ESC] for several times to return to the main menu.

```
Redundant Ctlr:
Autocfg Inactive
```

2. Controller Unique ID

Enter "View and Edit Config Parm"-> "Controller Parameters". Use ▼ or ▲ to find "Ctlr Unique ID- xxxxx".

```
View and Edit
Config Parm
```

```
Controller
Parameters ..
```

This value will be used to generate a controller-unique WWN node name and port names and to identify the controller during the failover process. Enter a hex number from 0 to FFFFF and press [ENTER]. The value you enter should be different for each controller.

```
Ctlr Unique
ID- 00012 ?
```

Power-off controller 1, and then power on controller 2. Set controller 2 to "**Autocfg**" as described previously. Power off controller 2.

When the redundant controller function is set to the "Autocfg" setting, the controllers will decide between themselves which will be the Primary controller. If you need to specify a particular controller as Primary or Secondary, do not set it as "autocfg;" choose "Primary" or "Secondary" instead. Please refer to the following section for more detail.

Redundant Configuration Using Manual Setting

Power on controller 1. Make sure controller 2 is powered-off.

1. Enable Redundant Controller

Press **[ENT]** for two seconds on the front panel of controller 1 to enter the main menu. Use ▼ or ▲ to navigate through the menus. Choose "View and Edit Peripheral Dev...", then press **[ENT]**.

```
View and Edit
Peripheral Dev
```

Choose "Set Peripheral Device Entry," then press **[ENT]**.

```
Set Peripheral
Devices Entry
```

Choose "Redundant Ctlr Function_," and then press **[ENT]**. (Note: The current setting will be displayed on the LCD. If this controller has never been set as a redundant controller before, the default setting of the redundant controller function is "disabled." The message "Redundant Ctlr Function Disable" will be displayed on the LCD screen. Press **[ENT]** to proceed.)

```
Redundant Ctlr
Function Disable
```

The message "Enable Redundant Ctlr: Autocfg?" will appear. Use ▼ or ▲ to scroll through the available options ("**Primary**," "**Secondary**," or "**Autocfg**"). Press **[ENT]** for two seconds on "Primary."

```
Enable Redundant
Ctlr: Autocfg ?
```

2. Controller Unique ID

Enter "View and Edit Config Parm"-> "Controller Parameters". Use ▼ or ▲ to find "Ctlr Unique ID- xxxxx".

```
View and Edit
Config Parm
```

```
Controller
Parameters ..
```

This value will be used to generate a controller-unique WWN node name and port names and to identify the controller during the failover process. Enter a hex number from 0 to FFFFF and press **[ENTER]**. The value you enter should be different for each controller.

```
Ctlr Unique
ID- 00012 ?
```

Power off controller 1, then power on controller 2. Set controller 2 to "Secondary" as described above.

Power off controller 2.

Starting the Redundant Controllers

Power on all hard drives and the two controllers. If drives are installed in a drive enclosure, wait for the drives to be ready, then power on the enclosure where the RAID controllers are installed.

```
RC connecting...
<ENT> to cancel
```

The message "RC (redundant controller) connecting... <ENT> to cancel" will appear on the LCD display of the two controllers. After a few seconds, the Primary controller will startup with the model number and firmware version displayed on the LCD, while the Secondary controller will display the message "RC Standing By.. <ENT> to Cancel" on its LCD. A few seconds later, the LCD display on the Secondary controller will be similar to the LCD display on the Primary controller. The upper right corner of LCD will then be displaying a "P" or "S," meaning "Primary" or "Secondary" respectively.

During normal operation, the controllers continuously monitor each other. Each controller is always ready to take over for the other controller in an unlikely event of a controller failure.

The Primary and Secondary controllers synchronize each other's configurations at frequent intervals through the communications channel(s).

Creating Primary and Secondary ID

Drive Channel

Enter "View and Edit SCSI Channels." Press **[ENT]** and use ▼ or ▲ to select the host or drive channel on which you wish to create Primary/Secondary IDs.

```
View and Edit
SCSI Channels ↓
```

```
CH1=Drive PID=7
SID=NA SXF=80.0M
```

Press **[ENT]** to proceed.

Use ▼ or ▲ to select "Set SCSI Channel Pri. Ctlr ID .." or "Set SCSI Channel Sec. Ctlr ID ..." Press **[ENT]** to proceed.

```
Set SCSI Channel
Sec. Ctlr ID ..
```

Use ▼ or ▲ to select a SCSI ID and press **[ENT]** to confirm. The configuration change will take effect only after controller reset.

```
Set Sec. Ctlr
ID:NA to ID: 6?
```

Host Channel

The process of creating Primary and Secondary IDs on host channels is basically the same.

In "View and Edit SCSI Channels", press **[ENT]** to select a host channel. Use ▼ or ▲ to select "Set SCSI Channel ID". A pre-configured ID will appear, press **[ENT]** to proceed. Use ▼ or ▲ to select "Add Channel SCSI ID" and then press **[ENT]** for two seconds on the "Primary" or "Secondary Controller?" to proceed.

```
CHL=0 ID=0
Primary Ctlr ..
```

```
Add Channel
SCSI ID ..
```

```
Primary
Controller ?
```

When prompted by this message, use ▼ or ▲ to select an ID. Press [ENT] to confirm and you will be prompted for resetting the controller.

```
Add CHL=0 ID=2
Primary Ctlr ?
```

A message will prompt to remind you to reset the controller. Press [ENT] to reset the controller or press [ESC] to move back to the previous menu. The change of ID will only take effect after controller reset.

```
Change Setting
Do Reset Ctlr ?
```

Assigning a Logical Drive/Logical Volume to the Secondary Controller

A logical drive, logical volume, or any of its logical partitions can be assigned to the Primary or Secondary controller. By default, a logical drive is automatically assigned to the Primary controller. It can be assigned to the Secondary controller if the host computer is also connected to the Secondary controller.

Note that the partitions of a logical drive that has previously been assigned to the Secondary controller will automatically be assigned to the Secondary controller.

Press [ENT] for two seconds on the front panel of the Primary controller to enter the Main Menu.

Use ▼ or ▲ to navigate through the menus. Choose "View and Edit Logical Drives.." then press [ENT].

```
View and Edit
Logical Drives
```

Create a logical drive or choose an existing logical drive, then press [ENT] to see the logical drive menu.

Choose "Logical Drive Assignment.." then press [ENT].

```
Logical Drive
Assignment..
```

The message "Redud Ctlr LG Assign Sec Ctlr?" will appear. Press [ENT] for two seconds to confirm. The logical drive has now been assigned to the Secondary controller.

```
Redud Ctlr LG
Assign Sec Ctlr?
```

Map the logical drive (or any logical unit) to a host ID or LUN number under the designated Secondary controller ID. The host channel must have a "Secondary" SCSI ID created. (Create the Secondary controller's SCSI ID on host channel and add a SCSI ID to every drive channel in "View and Edit SCSI Channels").

Mapping a Logical Drive/Logical Volume to the Host LUNs

Choose "View and Edit Host Luns" from main menu and press [ENT] to proceed.

```
View and Edit
Host Luns      ↓
```

Use ▼ or ▲ to navigate through the created IDs and press [ENT] to select one of them. Note that a logical unit previously assigned to a Primary controller can only be mapped a Primary ID, and vice versa.

```
Map Sec Ctlr
CH=0 ID= 000  ?
```

Use ▼ or ▲ to choose mapping "Logical Drive," "Logical Volume," or "Physical Drive" to host LUN. If the logical unit has been partitioned, map each partition to different ID/LUNs.

```
Map to
Logical Drive ?
```

Use ▼ or ▲ to choose a LUN number and press [ENT] to confirm.

```
CH0 ID0 LUN0
No Mapped
```

Press [ENT] again to confirm.

```
Map Host LUN  ?
```

Use ▼ or ▲ to choose a logical drive/logical volume if there are many.

```
LG0 RAID5 DRV=3
9999MB GD SB=0
```

Press [ENT] and choose a partition if the logical unit has been partitioned.

```
LG=0 PART=0
999MB      ?
```

Press [ENT] again to confirm or scroll down to "Edit Host Filter Parameter ..." You may refer to Chapter 8 for more details.

```
Map Host LUN  ?
```

Press [ENT] to confirm the mapping.
Press [ENT] to re-ensure.

```
CH0 ID9 LUN0 Map
to LG0 PRT0?
```

This message indicates that the logical unit has been successfully mapped to the ID/LUN combination. Use ▼ or ▲ to continue mapping other logical units or press [ENT] to delete the mapped LUN.

```
Map Sec. Ctlr
CH=0 ID= 0    ?
```

```
CH0 ID9 LUN0
Mapto LG0 PRT0
```

Repeat the process to map all the logical units to host ID/LUNs.

Front Panel View of Controller Failure

What will happen when one of the controllers fails?

Should one of the controllers fail, the existing controller will automatically take over within a few seconds.

The red ATTEN LED will light up, and the message "Redundant Ctlr Failure Detected" will

```
Redundant Ctlr
Failure Detected
```

appear on the LCD. Users will be notified by audible alarm.

NOTE:

- *Although the existing controller will keep the system working. You should contact your system vendor for a replacement controller as soon as possible. Your vendor should be able to provide the appropriate replacement unit.*
 - *Some operating systems (SCO, UnixWare, and OpenServer, for example) will not attempt to retry accessing the hard disk drives while controller is taking over.*
-

When and how is the failed controller replaced?


Remove the failed controller **after** the "working" controller has taken over. For a controller with hot-plug capability, all you have to do is to remove the failed controller.

The replacement controller has to be pre-configured as the "Secondary Controller." (The replacement controller provided by your supplier should have been configured as the Secondary controller. It is recommended to safety check the status of the replacement controller before installing it to your redundant system. Simply attach power to the replacement and configure it as "Secondary." When safety check is done, remove the failed controller and install the replacement controller into its place.)

By setting a replacement as a "Secondary controller" its "redundant controller" function is activated.


When the replacement is connected, the "Auto-Failback" will start automatically. If the replacement controller does not initialize, execute the following steps to bring the new controller online. Press [ENT] for 2 seconds on the existing controller to enter the main menu.

Use ▼ or ▲ to choose "View and Edit Peripheral Dev...", then press [ENT].




View and Edit
Peripheral Dev

Choose "Set Peripheral Device Entry...", then press [ENT].




Set Peripheral
Devices Entry ..

Choose "Redundant Ctlr Function__", then press [ENT].



Redundant Ctlr
Function__

The message "Redundant Ctlr Autocfg Degraded" will appear on the LCD.



Redundant Ctlr
Autocfg Degraded

Press **[ENT]** and the message "Deassert Reset on Failed Ctlr?" will appear.

```
Deassert Reset
on Failed Ctlr?
```

Press **[ENT]** for two seconds and the controller will start to scan for the new controller and bring it online.

```
Redundant Ctlr
Scanning
```

The new controller will then start to initialize.

```
Initializing...
Please Wait...
```


Once initialized, it will assume the role of the Secondary controller.

```
SR2500F v3.**
```

10.3.3 Via Terminal Emulation

Redundant Configuration Using Automatic Setting

Power on Controller 1. Make sure Controller 2 is powered-off.




Enter the Main Menu.

Use the arrow keys to navigate through the menus. Choose "View and Edit Peripheral Devices," then press **[ENTER]**.

Choose "Set Peripheral Devices Entry," then press **[ENTER]**. Choose "Redundant Controller [Function]," and then press **[ENTER]**. (Note: The current setting will be displayed on the screen. If this controller has never been set as a redundant controller before, the default setting is "Disabled." The message "Redundant Controller - Disabled" will be displayed on the screen. Press **[ENTER]** to proceed.)

The message "Enable Redundant Controller in **Autoconfigure** Mode" will appear.



Use the arrow keys to scroll through the available options ("Primary," "Secondary," or "Autoconfigure"), then press **[ENTER]** to select "Autoconfigure." When prompted by "enable redundant controller function in Autoconfigure mode?," choose **Yes**.



A "Controller Unique Identifier" box will appear. Enter a hex number from 0 to FFFFF, then press **[ENTER]** to proceed. The value you enter for controller unique ID should be different for each controller.

Power off controller 1, and then power on controller 2. Set controller 2 to "Autoconfigure" as described in the steps mentioned above. Power off controller 2.

When the redundant controller function is set to the "Automatic" setting, the controllers will decide between themselves which will be the Primary controller. If you need to specify a particular controller as Primary or Secondary, do not set it as "autocfg;" choose "Primary" or "Secondary" instead.

Redundant Configuration Using Manual Setting


Power on controller 1. Make sure controller 2 is powered-off.

Enter the main menu. Use the arrow keys to navigate through the menus. Choose "View and Edit Peripheral Devices," then press **[ENTER]**.


Choose "Set Peripheral Device Entry," then press **[ENTER]**.

Choose "Redundant Controller [Function]," and then press **[ENTER]**. (Note: The current setting will be displayed on the screen. If this controller has never been set as a redundant controller before, the default setting is "Disabled". The message "Redundant Controller - Disabled" will be displayed on the screen. Press **[ENTER]** to proceed.)

The message "Enable Redundant Controller in Autoconfigure Mode" will appear. Use the arrow keys to scroll through the available options ("Primary," "Secondary," or "Autoconfigure"). Press [ENTER] on "Primary."



- Power off controller 1, then power on controller 2. Set controller 2 to "Secondary" as described above.



- Power off controller 2.
- Power on drives, both controllers, and host computer(s) for the settings to take effect.
- The Primary and Secondary controllers synchronize each other's configurations at frequent intervals through the established communications path(s). Write-back cache will be disabled if no sync. cache path exists.
- Select "View and Edit SCSI Channels" from the Main Menu, the communications path will be displayed as "RCCOM (Redundant Controller Communications)."

```

    < Main Menu >
    Quick installation
    view and edit Logical drives
    view and edit Logical Volumes
  
```

Ch1	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
0(D)	RCCOM								
1	Drive	8	9	40.0MHz	Wide	L	0n		
2	Drive	8	9	40.0MHz	Wide	S	0n		
3	Drive	8	9	40.0MHz	Wide	L	0n		
4	Host	112	NA	1 GHz	Serial	F	NA		
5	Host	NA	113	1 GHz	Serial	F	NA		

Creating Primary and Secondary ID

Enter "View and Edit SCSI Channels." Press [ENTER] and select the host or drive channel on which you wish to create Primary/Secondary ID.

Drive Channel

Q	LG	ID	LV	RAID	Size(MB)	Status	0	#LN	#SB	#FL	NAME
V	P0	1F10E040	NA	RAID5	9998	GOOD	S	3	1	0	
V	View scsi drives										
V	Delete logical drive										
V	Partition logical drive										
V	logical drive Name										
V	logical drive Assignments										
V	Redundant Controller Logical Drive Assign to Secondary Controller ?										
						Yes	No				
	6		NONE								
	7		NONE								

The reassignment is evident from the "View and Edit Logical Drives" screen. "S0" indicates that the logical drive is logical drive 0 assigned to the Secondary Controller.

Q	LG	ID	LV	RAID	Size(MB)	Status	0	#LN	#SB	#FL	NAME
V	S0	1F10E040	NA	RAID5	98	GOOD	S	3	1	0	
V	P1	4DB655C0	NA	RAID3	98	GOOD	S	3	0	0	
V	2		NONE								
V	3		NONE								
V	4		NONE								
V	5		NONE								
V	6		NONE								
V	7		NONE								

Mapping a Logical Drive/Logical Volume to the Host LUNs

Cache Status: Clean

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit Logical Volumes
view and edit Host luns
v CHL 0 ID 0 (Primary Controller)
v Edit Logical Drive
v Logical Volume
system Physical SCSI Drive
view sy
view and edit Host luns

```

Choose "host channel-ID"
 Choose mapping to which "logical unit"

Select LUN number →

LUN	LV/LD	DRV	Partition	Size(MB)	RAID
0					

Select partition →

LG	ID	LV	RAID	Size(MB)	Status	0	#LN	#SB	#FL	NAME
P0	64BD0F51	NA	RAID5	98	GOOD	S	3	0	0	

Partition	Offset(MB)	Size(MB)
0	0	98
5		
6		
7		

Mapping option →

Map Host LUN	
Create Host Filter Entry	

Confirming mapping →

Map	Logical Drive:	0
To	Partition	: 0
	Channel	: 0
	ID	: 0
	Lun	: 0 ?
	Yes	No

Terminal Interface View of Controller Failure

What will happen when one of the controllers fails?

When one of the controllers fails, the other controller will take over in a few seconds.

```
Warning
[110F] CHL:0 SCSI Drive Channel ALERT: SCSI Bus Reset Issued
```

A warning will be displayed that a "SCSI Bus Reset Issued" for each of the SCSI channels.

In addition, there will be an alert message that reads "Redundant Controller Failure Detected."

Users will be notified by audible alarm.

```
Alert
[0111] Controller ALERT: Redundant Controller Failure Detected
```

After a controller takes over, it will act as both controllers. If it was the Primary controller that failed, the Secondary controller becomes the Primary controller. If the failed controller is replaced by a new one later, the new controller will assume the role of the Secondary controller.

NOTE:

- *Some operating systems (SCO, UnixWare, and OpenServer, for example) will not attempt to retry accessing the hard disk drives while the controller is taking over.*
-

10.3.4 When and How Is the Failed Controller Replaced?

Remove the failed controller **after** the take-over of the "working" controller has been completed. For a controller with hot-plug capability, all you have to do is to remove the failed controller.

The new controller has to be pre-configured as the "Secondary Controller." (The replacement controller provided by your supplier should have been configured as the Secondary controller. It is recommended to safety check the status of the replacement controller before installing it to your redundant system. Simply attach power to the new controller and configure it as the "Secondary." When safety check is done, remove the failed controller and install the replacement controller into its place.)

```

Cache Status: Clean

< Main Menu >
Quick installation
view and edit Logical drives
view and edit Logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
view and edit Peripheral devices
S
v
D
A
C
U
View Peripheral Device Status
Set Peripheral Device Entry
Redundant Controller - Disabled
enable redundant controller function in Autoconfigure mode
enable redundant controller function as Primary
enable redundant controller function as Secondary
Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

```

When the new controller is connected, the existing controller will automatically start initializing the replacement controller. If the existing controller does not initialize the replacement controller, execute the "Deassert Reset on Failed Controller" function.

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit Logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
view and edit Peripheral devices
S
v
D
A
C
U
View Peripheral Device Status
Set Peripheral Device Entry
Redundant Controller - Primary
Deassert Reset on Failed Controller ?
Yes No

```

If the replacement has been initialized normally, you may proceed to examine the system status. From the main menu, select "View and Edit Peripheral Devices" and then "View Peripheral Device Status" to see that the new controller is being scanned.

```

Cache Status: Clean

< Main Menu >
Quick installation
view and edit Logical drives
view and edit Logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
view and edit Peripheral devices
S
v
D
A
C
U
View Peripheral Device Status
ITEM STATUS LOCATION
Redundant Controller Enabled Primary
Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

```

When the scanning has completed, the status will change to "Enabled."

```

< Main Menu >
Quick installation
view and edit Logical drives
view and edit Logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
view and edit Peripheral devices
S
v
D
A
C
U
View Peripheral Device Status
ITEM STATUS LOCATION
Redundant Controller Scanning Primary

```

Forcing Controller Failover for Testing

```

      < Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
view and edit Peripheral devices
S
U
V
  View Peripheral Device Status
  Set Peripheral Device Entry
D
A
C
U
  Redundant Controller - Primary
  Disable redundant controller
  force Primary controller failure
  force Secondary controller failure

```

This function is reserved for de-bugging.

Testing the failover functionality can be performed using the following methods.

1. Pulling out one of the controllers to simulate controller failure

Pull out either the primary or the secondary controller. An error message will display immediately with sounded alarm. The existing controller takes over the workload within a second. Clear all errors by pressing the **ESC** key. You may now install the controller once removed after all activities have been taken over by the existing controller. It may take a while for the controllers to finish re-initialization and assuming their load.

2. Failover by "Forcing controller failure"

Select "View and Edit Peripheral Devices," "Set Peripheral Device Entry," and "Redundant Controller Primary/Secondary."

Select "Force Primary/ Secondary Controller Failure." You may now pull out the controller you had just disabled. I/Os should be continued by the existing controller. Continue the aforementioned procedure to complete the test.

WARNING!

- *This function should only be performed for testing the redundant controller functionality before any critical data is committed to drives. Although the controller is designed to be hot-swappable, unpredictable failures may occur during the process, e.g., improper handling of PCB boards while replacing the controller.*
-

RCC Status (Redundant Controller Communications Channel)

```
Wed Jun 26 17:10:48 2002 Cache Status: Clean
Write Cache: Enable
BAT:+++++
< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
v
s
v
v
C Redundant Controller Communication Channel - Fibre
C Secondary Controller RS-232 - Disabled
H Remote Redundant Controller - Disabled
D Cache Synchronization on Write-Through - Disable
D
Redundant Controller Parameters
Controller Parameters
Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen
```

The item is display only, showing the current communications route.

Secondary Controller RS-232


This is an option reserved for debug purposes. When enabled, you can access the secondary controller through its serial port. When combined into a redundant controller system, only status display is available through the terminal session with a secondary controller. No configuration change can be done through a secondary controller.

Remote Redundant Controller

```
< Main Menu >
Quick installation
view and edit Logical drives
view and edit logical Volumes
view and edit Host luns
view and edit scsi Drives
view and edit Scsi channels
view and edit Configuration parameters
v
s
v
v
C Redundant Controller Communication Channel - Fibre
C Secondary Controller RS-232 - Disabled
H Remote Redundant Controller - Disabled
D Cache Synchronization on Write-Through - Disable
D
Redundant Controller Parameters
Controller Parameters
```

This function enables two partner controllers to be connected by FC links over an extended distance; e.g., between two campus buildings. This is an advanced option reserved for system integrators. For more details, please contact Infortrend Technical Support.

Cache Synchronization on Write-Through



If your redundant controller system is not operating with Write-back caching, you may disable the synchronized cache communications. Your system can be spared of the efforts mirroring and transferring data between partner controllers. This tremendously increases array performance in the redundant controller configuration.

Record of Settings

In addition to saving the configuration data in NVRAM to disk, keeping a hard copy of the controller configuration is also recommended. This will speed the recreation of the RAID in the event of a disaster.

The following tables are provided as a model for recording the configuration data.

As a general rule, the configuration data in the NVRAM should be *saved to disk or as a file (using RAIDWatch Manager)* whenever a configuration change is made (see Chapter 6 and 7).

11.1 View and Edit Logical Drives


Wed Jun 26 16:38:24 2002											Cache Status: Clean			
BAT:											Write Cache: Enable			
LG	ID	LV	RAID	Size(MB)	Status	1	2	3	0	C	#LN	#SB	#FL	NAME
P0	20F7C6C5	NA	RAID0	277976	GOOD				7		8	-	0	
P1	6620CBA0	NA	RAID5	69694	GOOD				7		3	0	0	
2			NONE											
3			NONE											
4			NONE											
5			NONE											
6			NONE											
7			NONE											

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Logical Drive Information

LG	ID	LV	RAID Level	size (MB)	status	1	2	3	0	C

11.3 View and Edit Host LUN's



LUN Mappings

Host Channel	Pri. / Sec. Controller	SCSI ID	LUN	Logical Drive / Logical Volume	Partition	Size

Host-ID/WWN Name List

Host-ID/WWN	Name List

Access Restriction Setting

Logical Drive / Logical Volume	Partition	Read Only / Access Denied to / R/W by: HBA WWN list

11.5 View and Edit SCSI Channels

Cache Status: Clean


Q	Chl	Mode	PID	SID	DefSynClk	DefWid	S	Term	CurSynClk	CurWid
v	0(D)	RC000								
v	1	Drive	7	6	20.0MHz	Wide	S	0n	40.0MHz	Narrow
v	2	Drive	7	6	40.0MHz	Wide	L	0n	40.0MHz	Narrow
v	3	Drive	7	6	40.0MHz	Wide	L	0n	40.0MHz	Narrow
v	4	Drive	7	6	40.0MHz	Wide	L	0n	40.0MHz	Narrow
v	5	Drive	7	6	40.0MHz	Wide	L	0n	40.0MHz	Narrow
v	6	Host	112	NA	1 GHz	Serial	F	NA		
v	7	Host	NA	113	1 GHz	Serial	F	NA		

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Chl	Mode (Host / Drive)	Primary Controller SCSI ID(s)	Secondary Controller SCSI ID(s)	Default Sync Clock	Default Wide	Terminator Diff/Enable/ Disable/	Current Sync Clock	Current Width

Parity Check	View channel host- ID/WWN	View device port name list (WWPN)

11.6 View and Edit Configuration Parameters



Communication Parameters

RS-232 Port Configuration

COM 1 (RS-232 Port)

Baud Rate	2400	4800	9600	19200	38400
Data Routing	Direct to Port		Through Network		
Terminal Emulation	Enabled		Disabled		

COM 2 (Redundant Controller Port)

Baud Rate	2400	4800	9600	19200	38400
Data Routing	Direct to Port		Through Network		
Terminal Emulation	Enabled		Disabled		

Ethernet Configuration

IP address	_____
NetMask	_____
Gateway	_____

PPP Configuration

PPP Access Name	_____
PPP Access Password	_____

Modem Operation → Modem Setup

Configure Modem Port	Modem Port Not Configured	COM1	COM2
Modem Operation Mode	None (Default Used) Replace Default Append to Default		
Modem Initialization - Custom Init. Command	AT		
Dial-out Command	AT		
Auto Dial-out on Initialization	Enabled		Disabled
Dial-out Timeout	_____ Seconds		

Dial-out Retry Count	Retry _____ times
Dial-out Retry Interval	_____ Minutes
Dial-out on Event Condition	Disabled Critical Events Only Critical Events and Warnings All Events, Warnings and Notifications

Caching Parameters

Write-back Cache	Enabled Disabled
Optimization for	Random I/O Sequential I/O

Host Side SCSI Parameters

Maximum Queued I/O Count	Auto _____
LUNs per Host SCSI ID	LUNs
Number of Tags Reserved for each Host-LUN connection	_____
Peripheral Device Type Parameters	Peripheral Device Type - Device Qualifier - Removable media - LUN applicability -
Host Cylinder/Head/Sector Mapping configuration	Cylinder - Head - Sector -
Fibre Connection Options	_____

Drive Side SCSI Parameters

SCSI Motor Spin-up	Enabled Disabled
SCSI Reset at Power Up	Enabled Disabled
Disk Access Delay Time	No Delay _____ Seconds
SCSI I/O Timeout	Default _____
Maximum Tag Count	Disabled _____
Periodic Drive Check Time	Disabled _____
Periodic SAF-TE and SES Device Check Time	Disabled _____
Periodic Auto-Detect Failure Drive Swap Check Time	Disabled _____
Drive Predictable Failure Mode	Disabled Detect only Detect and Perpetual Clone Detect and Clone + Replace
Fibre Channel Dual Loop	Enabled Disabled

Disk Array Parameters

Rebuild Priority	Low	Normal	Improved	High
Verifications on Writes				
Verifications on LD Initialization Writes	Enabled	Disabled		
Verifications on LD Rebuild Writes	Enabled	Disabled		
Verifications on Normal Drive Writes	Enabled	Disabled		


Redundant Controller Parameters

Redundant Controller Communication Channel	_____		
Secondary controller RS-232	Enabled	Disabled	
Cache synchronization on write-through	Enabled	Disabled	

Controller Parameters

Controller Name	Not Set	_____		
LCD Tile Display	Controller Logo	Controller Name		
Password Validation Timeout	Disabled	1 minute	2 minutes	5 minutes
Controller Unique Identifier	_____			
SDRAM ECC	Enabled	Disabled		

11.7 View and Edit Peripheral Devices



Set Peripheral Device Entry

Redundant Controller	Enabled	Disabled
Power Supply Status	Enabled	Disabled
Fan Status	Enabled	Disabled
Temperature Status	Enabled	Disabled
UPS Status	Enabled	Disabled

Event Trigger Options

Controller Failure	Enabled	Disabled
BBU Low/Failed	Enabled	Disabled
UPS AC Power Loss	Enabled	Disabled
Power Supply Failed	Enabled	Disabled
Fan Failed	Enabled	Disabled
Temperature Exceeds Limits	Enabled	Disabled

Define Peripheral Device Active Signal

Power Supply Fail Signal	Active High	Active Low
Fan Fail Signal	Active High	Active Low
Temperature Alert Signal	Active High	Active Low
UPS Power Fail Signal	Active High	Active Low
Drive Failure Outputs	Active High	Active Low


View System Information

Total Cache Size	SDRAM _____ MB
Firmware Version	
Bootrecord Version	
Serial Number	
Battery Backup	On Off

Event Threshold Parameters


Thresholds for +3.3V	Upper _____ Lower _____
Thresholds for +5V	Upper _____ Lower _____
Thresholds for +12V	Upper _____ Lower _____
Thresholds for CPU temperature	Upper _____ Lower _____
Thresholds for Board Temperature	Upper _____ Lower _____

11.8 Save NVRAM to Disk, Restore from Disk



Update Firmware	Date	Save NVRAM to Disk or File	Date/Location	Restore NVRAM from Disk	Date

11.9 RAID Security: Password



RAID Security

Controller Name	Password _____
-----------------	----------------

Array Expansion

The array expansion functions allow you to expand storage capacity without the costs on buying new equipment. The expansion can be completed on-line while system is serving host I/Os.

This chapter is organized as follows:

12.1 Overview

Note on using the expansion functions

12.2 Mode 1 Expansion

Theory and configuration procedure: expansion by adding drives

12.3 Mode 2 Expansion

Theory and configuration procedure: expansion by copying and replacing drives

12.4 Making Use of the Added Capacity: Expand Logical Drive

Configuration procedure of the Expand function for logical drive

12.5 Expand Logical Volume

Configuration procedure of the Expand function for logical volume

12.6 Configuration Example: Volume Extension in Windows 2000

12.1 Overview

What is it and how does it work?

Before the invention of RAID Expansion, increasing the capacity of a RAID system meant backing up all data in the disk array, re-creating disk array configuration with new drives, and then restoring data back into system.

Infortrend's RAID Expansion technology allows users to expand a logical drive by adding new drives, or replacing drive members with drives of larger capacity. Replacing is done by copying data from the original members to larger drives, and then the smaller drives can be replaced without powering down the system.

Note on Expansion

1. Added Capacity:

When a new drive is added to an existing logical drive, the capacity brought by the new drive appears as a new partition. Assuming that you have 4 physical drives (each of the size of 36GB) in a logical drive, and that each drive's maximum capacity is used, you will have a logical drive of the size of 108GB. One drive's capacity is used for parity; e.g., RAID 3. A 36GB drive is added, the capacity will be increased to 144GB in two separate partitions (one is 108GB and the other 36GB).

2. Size of the New Drive:

A drive used for adding the capacity should have the same capacity as that of the array's members.

3. Applicable Arrays:

Expansion can only be performed on RAID 0, 3, and 5 logical drives. Expansion can not be performed on a logical configurations that do not have parity; e.g., NRAID or RAID 1.

NOTE:


- Expansion on RAID0 is not recommended, because the RAID0 array has no redundancy. Interruptions during the expansion process may cause unrecoverable data loss.
-

4. Interruption to the Process:

Expansion should not be canceled or interrupted once begun. A manual restart should be conducted after the occurrence of power failure or interruption of any kind.

Expand Logical Drive: Re-Striping

Figure 12 - 1 Logical Drive Expansion



RAID levels supported: RAID 0, 3, and 5

Expansion can be performed on logical drives or logical volumes under the following conditions:


1. There is an unused capacity in a logical unit
2. Capacity is increased by using member drives of larger capacity (see Copy and Replace in the discussion below)

Data is recalculated and distributed to drive members or members of a logical volume. On the completion of the process, the added or the previously unused capacity will become a new partition. The new partition must be made available through host LUN mapping in order for a host adapter to recognize its presence.

12.2 Mode 1 Expansion: Adding Drives to a Logical Drive

Use drives of the same capacity as that of the original drive members. Once completed, the added capacity will appear as another partition (new partition). Data is automatically re-striped across the new and old members during the add-drive process. See the diagram below to get a clear idea:

Figure 12 - 2 Expansion by Adding Drive



RAID levels supported: RAID 0, 3, and 5.

The new partition must be made available through a host ID/LUN.

Add-Drive Procedure

First select from the main menu, "View and Edit Logical Drive," and select a logical drive to add a new drive to. The drive selected for adding should have a capacity no less than the original member drives. If possible, use drives of the same capacity because all drives in the array is treated as though they have the capacity of the smallest member in the array.

Cache Status: Clean

Q	LG	ID	LV	RAID	Size(MB)	Status	0	#LN	#SB	#FL	NAME
v	P0	75597508	NA	RAID5	1279	GOOD	R	5	0	0	
v	1			NONE							
v	2			NONE							
v	3			NONE							
v	4			NONE							
v	5			NONE							
v	6			NONE							
v	7			NONE							

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Press **[ENTER]** to select a logical drive and choose “add SCSI drives” from the submenu. Proceed with confirming the selection.

Q	LG	ID	LV	RAID	Size(MB)	Status	0	#LN	#SB	#FL	NAME
v	P0	255167A	NA	RAID5	9999	GOOD	R	3	0	0	
v	View scsi drives Delete logical drive Partition logical drive logical drive Name logical drive Assignments Expand logical drive add scsi drives										
v	Add Drives to Logical Drive ? <input checked="" type="radio"/> Yes No										
v	6										
v	7			NONE							

Available drives will be listed. Select one or more drive(s) to add to the target logical drive by pressing **[ENTER]**. The selected drive will be indicated by an asterisk “*” mark.

Q	LG	ID	LV	RAID	Size(MB)	Status	0	#LN	#SB	#FL	NAME
v	P0	60F15A60	NA	RAID5	9999	GOOD	R	3	0	0	
v	View scsi drives										
v		Slot	Chl	ID	Size(MB)	Speed	LG_DRV	Status	Vendor and Product ID		
v	*	1	0	4999	40MB	NONE	NEW DRV				
v		1	1	4999	40MB	NONE	NEW DRV				
v		1	2	4999	40MB	NONE	NEW DRV				
v	6	1	4	4999	40MB	NONE	NEW DRV				
v	7	1	8	4999	40MB	NONE	NEW DRV				

Press **[ESC]** to proceed and the notification will prompt.

Q	LG	ID	LV	RAID	Size(MB)	Status	0	#LN	#SB	#FL	NAME
v	P0	60F15A60	NA	RAID5	9999	GOOD	R	3	0	0	
v	Adding Notification [2189] LG:0 Logical Drive NOTICE: Starting Add SCSI Drive Operation										
v	4			NONE							
v	5			NONE							
v	6			NONE							
v	7			NONE							

Press **[ESC]** again to cancel the notification prompt, a status bar will indicate the percentage of progress.


12.3 Mode 2 Expansion:

Copy and Replace Drives with Drives of Larger Capacity

You may also expand your logical drives by copying and replacing all member drives with drives of higher capacity. Please refer to the diagram below for a better understanding. The existing data in the array is copied onto the new drives, and then the original members can be removed.

When all the member drives have been replaced, execute the “Expand logical drives” function to make use of the added capacity.


Figure 12 - 3 Expansion by Copy & Replace




RAID levels supported: RAID 0, 3, and 5

Copy and Replace Procedure

Select from main menu “View and Edit Logical Drives.” Select a target array, press **[ENTER]** and scroll down to choose “copy and replace drive.” Press **[ENTER]** to proceed.

Q	LG	ID	LV	RAID	Size(MB)	Status	0	#LN	#SB	#FL	NAME
V	00	15A60	NA	RAID5	9999	GOOD	R	4	0	0	
V	1	Drive Copying									
V	2										
V	3	40% Completed									
V	4		NONE								
V	5		NONE								
V	6		NONE								
V	7		NONE								

Completion of the Copy and Replace process will be indicated by a notification message. Follow the same method to copy and replace every member drive. You may now perform “Expand Logical Drive” to make use of the added capacity, and then map the additional capacity to a Host LUN.




12.4 Making Use of the Added Capacity: Expand Logical Drive

In the following example, the logical drive is originally composed of three member drives and each member drive has the capacity of 1 gigabyte. “Copy and Replace” has been performed on the logical drive and each of its member drives has been replaced by a new drive with the capacity of 2 Gigabytes. The next step is to perform “Expand Logical Drive” to utilize the additional capacity brought by the new drives.

1. Select “View and Edit Logical Drives” from the main menu and select the logical drive with its members copied and replaced.
2. Select “Expand Logical Drive” in the sub-menu and press **[ENTER]** to proceed. A confirming box will appear.
3. Proceed by pressing **[ENTER]** or entering any value no larger than the "maximum drive expand capacity" and press **[ENTER]**.

12.5 Expand Logical Volume

To expand a logical volume, expand its logical drive member(s) and then perform “expand logical volume.”



When prompted by "Expand Logical Volume?", Choose **Yes** to confirm and the process will be completed immediately.

12.6 Configuration Example: Volume Extension in Windows 2000®

Limitations When Using Windows 2000

1. Applies only to the Windows NT Server or Windows 2000 Server Disk Management which includes the Extend Volume Set function; Windows NT Workstation does not support this feature. The volume set expansion formats the new area without affecting existing files on the original volume.
2. The system drive (boot drive) of a Windows NT/2000 system can not be expanded.
3. The drive to be expanded should be using the NTFS file system.

Example:

The following example demonstrates the expansion of a 16988MB RAID 5 logical drive. The HyperTerminal emulation software that comes with Windows Server is used to connect to the RAID controller via RS-232C.

```

Mon Jan 20 18:30:48 2003                               Cache Status: Clean
A0:92%

```


LG	ID	LU	RAID	Size(MB)	Status	1	2	3	0	C	#LN	#SB	#FL	NAME
P0	2092804D	NA	RAID5	16988	GOOD				7	B	3	0	0	
1			NONE											
2			NONE											
3			NONE											
4			NONE											
5			NONE											
6			NONE											
7			NONE											

```


Arrow Keys:Move Cursor  !Enter:Select  !Esc:Exit  !Ctrl+L:Refresh Screen

```

You can view information about this drive in the Windows 2000 Server's Computer Management -> Storage -> Disk Management.



Place the cursor on Disk 1, right-click your mouse, and select "Properties." You will see that the total capacity for the Drive E: is about 16.5GB.



Follow the steps described in the previous section to "add" or "copy & replace" SCSI disk drives and perform Logical Drive Expansion.

Mon Jan 20 18:30:48 2003 Cache Status: Clean
RA0:92%

LG	ID	LU	RAID	Size<MB>	Status	1	2	3	0	C	#LN	#SB	#FL	NAME
P0	2092804D	NA	RAID5	16988	GOOD				7	B	3	0	0	
1					Adding									
2					-----									
3					92% Completed_									
4			NONE											
5			NONE											
6			NONE											
7			NONE											

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

The 16.5GB logical drive has become a 25GB logical drive. Place the cursor on that logical drive, and then press [ENTER].

Mon Jan 20 18:32:34 2003 Cache Status: Clean

LG	ID	LU	RAID	Size<MB>	Status	1	2	3	0	C	#LN	#SB	#FL	NAME
P0	2092804D	NA	RAID5	25482	GOOD				7	B	4	0	0	
1			NONE											
2			NONE											
3			NONE											
4			NONE											
5			NONE											
6			NONE											
7			NONE											

Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

From the menu, select "Partition Logical Drive." You will see that the 25GB logical drive is composed of a 17GB partition and an 8.4GB partition.


Mon Jan 20 18:33:39 2003 Cache Status: Clean

LG	ID	LU	RAID	Size<MB>	Partition	Offset<MB>	Size<MB>	NAME
P0	2092804D	NA	RAID5	25482	0	0	16988	
1			NONE		1	16988	8494	
2			NONE		2			
3			NONE		3			
4			NONE		4			
5			NONE		5			
6			NONE		6			
7			NONE		7			


Arrow Keys:Move Cursor |Enter:Select |Esc:Exit |Ctrl+L:Refresh Screen

Follow the directions in chapter 5 and chapter 7 to map the new partition to a Host LUN. The new partition must be "mapped" to a host LUN in order for the HBA (host-bus adapter) to see it. Once you have mapped the partition, reboot your Windows server. The HBA should be able to detect an additional "disk" during the initialization process.


Return to Windows 2000 Server's Disk Management. There now exists a Disk 2 with 8.3GB of free space. You may use the "rescan disks" command to bring up the new drive.




Select an existing volume (Disk1) and then right-click on the disk column. Select "Extend Volume" to proceed.



The Extend Volume Wizard should guide you through the rest of the process.




The screen will display that volume set of Drive E: has been extended into a spanned volume by the 8.3GB in Disk2.



Logical Drive E: is now composed of two partitions with a total volume of 2500MB. To see this, hold down on the <Ctrl> key and select both Disk 1 and Disk2; then right-click your mouse and select "Properties."

Drive E: now has a capacity of about 25GB.



A


LCD Keypad Navigation Map


Firmware Version: 3.31


Symbols Used in this Map


- LCD display text
- Task to be performed, or the task to be performed for the configuration to take effect (red text)
- Press ENT on one menu item to access multiple options
- After selecting the option, press ESC or ENT to move on to the next item
- Optional approach to the same task
- Press ENT for multiple options
- Press Up/arrow key
- Press Down arrow key


NOTE: Normally, pressing ENT will confirm your selection or lead you to more options. Pressing ESC will cancel a notification message or end the current option.











B

Firmware Functionality Specifications

Basic RAID Management:

Specification	Feature
RAID Levels	0, 1(0+1), 3, 5, 10, 30, and 50 (Multi-level RAID with the logical volume implementation)
Maximum Number of logical drives	64 or 128 through OEM IAPPEND utility
Maximum Array Capacity	64TB – when optimization mode is set to Sequential 16TB – when optimization mode is set to Random
RAID level dependency to each logical drive	Independent. Logical drive configured in different RAID levels can co-exist in a logical volume and in a RAID system
Maximum number of drives for each logical drive	128
Configurable stripe size	4KB, 16KB, 32KB, 64KB, 128KB, or 256KB per logical drive <ul style="list-style-type: none"> ▪ 128KB is the default for earlier firmware with optimization for Sequential I/Os ▪ 32KB is the default for earlier firmware with optimization for Random I/Os
Configurable Write Policy (Write Policy per array)	Write-Back or Write-Through per logical drive. This policy can be modified later.
Logical drive identification	Unique, controller randomly generated logical drive ID; Logical drive name user-configurable
Maximum number of partitions for each logical drive	128, through OEM “iappend.exe” program
Maximum number of logical drives in a logical volume	128 (64 with ATA RAID subsystem)
Maximum number of logical volumes	32 (16 with ATA RAID subsystem)
Maximum number of LUNs Mappable	Up to 1024
Maximum number of LUNs	Up to 32, user configurable

per Host ID	
Concurrent I/O	Supported
Tag Command Queuing	Supported
Dedicated Spare Drive	Supported, hereby defined as the spare drive specifically assigned to a logical drive
Global Spare Drive	Supported, the spare drive serving all logical drives
Global Spare Auto-Assign	Supported, applies to non-configured drives
Co-Existing Dedicated and Global Spare Drives	Supported
Auto-rebuild onto spare drive	Supported
Auto-scan of replacement drive upon manually initiated rebuild	Supported
One-step rebuild onto a replacement drive	Supported
Immediate logical drive availability	Supported; Logical arrays are immediately ready for Host I/Os. Initialization task is completed in the background except when the logical array is stated as "INCOMPLETE" or "BAD," e.g., has a failed member right after creation.
Auto-rebuild onto failed drive replacement	Supported. With no spare drive, the controller will auto-scan the failed drive and starts rebuild automatically once the failed drive has been replaced.
Concurrent Rebuild / Expansion	Multiple logical drives can proceed with a Rebuild/Regenerating Parity, and/or Expansion/Initialization/Add Drive operation at the same time. Regenerate Parity and Rebuild can not take place on a logical drive at the same time. Create, Expansion, and Add Drive operation can not take place on a logical drive at the same time.
Background firmware download	Firmware can be downloaded during active I/Os. Administrators may find appropriate time to reset controller later.
Auto recovery from logical drive failure (Configuration on Drives)	Supported. When user accidentally removed the wrong drive to cause the 2 nd drive failure of a one-drive-failed RAID5 / RAID3 logical drive, fatal error may occur. However, you may force the controller to reaccept the logical drive by switching off the controller, installing the drive back to its original drive slot, and then power on the controller. The logical drive will be restored to the one-drive-failed status.

Advanced Features:

Media Scan	<p>Supported. Verify written data on drives to avoid bad blocks from causing data inconsistency. If bad blocks are found, data can be reconstructed by comparing and recalculating parity from adjacent drives (RAID1/3/5).</p> <p>The “Reconstruction Writes” are followed by “Write Verification” operation.</p>
Bad Block Handling in Degraded Mode	<p>A method for handling low quality drives. The operation is performed on both the logical drive in degraded mode or that being rebuilt. If bad blocks should be encountered during Rebuild, Add Drive, Host Write, or Regenerate Parity operation, the controller will first attempt to reconstruct affected data and those unrecoverable bad blocks are stated as bad and passed to host.</p> <p>Low quality drive handling comes with transparent resetting of hung hard drives.</p>
Transparent reset of hung HDDs	Supported
Auto Cache Flush on critical conditions (Caching Mode Dynamic Switch)	<p>When critical conditions occur, e.g., component failure, or BBU under charge, cached data will be flushed and the write policy will be changed to write-through mode.</p> <p>Configurable “Trigger Events” for Write-through/Write-Back Dynamic Switch. The configuration can also be set with the “lappend” utility.</p>
Drive Low-level format	Supported
Drive Identification(Flash Drive Function)	Supported. Force the drive to light on the activity indicator for user to recognize the correct drive.
Drive Information Listing	Supported. Drive vendor name, model number, firmware revision, capacity (blocks), serial number, narrow/wide and current sync. speed.
Drive Read/Write testing	Supported
Configuration on Disk	Supported. The logical drive information is recorded on drive media. The logical drives can still be accessed if using different Infortrend RAID controllers/subsystems.
Save/ Restore NVRAM to / from Disks	Supported. Save all the settings stored in the controller NVRAM to the logical drive members
Save / Restore NVRAM to / from a file	Supported. Save all the settings stored in the controller NVRAM to a file (via GUI manager) on user's computer.

Host LUN Geometry User Configurable Default Geometry:	<ol style="list-style-type: none"> 1. Capacity <64GB: Head=63, Sector=32, Cylinder=? (depends on capacity) 2. 64GB<capacity<128GB:Head=64, Sector=64, Cylinder=? (depends on capacity) 3. 128GB<capacity<256GB: Head=127, Sector=64, Cylinder=? (depends on capacity) 4. 256GB<capacity<512GB: Head=127, Sector=127, Cylinder=? 5. 512GB<capacity<1TB: Head=255, Sector=64, Cylinder=? (depends on capacity) 6. 1TB<capacity: Head=225, Sector=225, Cylinder=? (depends on capacity)
User Configurable Geometry range:	Sector: 32, 64, 127, 255 or Variable Head: 64, 127, 255 or Variable Cylinder: <1024, <32784,<65536 or Variable
Drive Motor Spin-up	Supported. The controller will send spin-up (start unit) command to each drive at the 4 sec. intervals.
Drive-side Tag Command Queue	Supported. User adjustable up to 128 for each drive
Host-side Maximum Queued I/O count	User adjustable up to 1024
Maximum concurrent Host LUN connection	User adjustable up to 64
Number of Tags Reserved for each Host-LUN connection	User adjustable up to 256
Controller/Logical Drive Shutdown	Turns controller or specific logical drive into a state that does not receive I/Os. This function is available through OEM "iappend" program.
Drive I/O timeout	User adjustable
IO channel diagnostics	Supported; please contact your dealer for more details
Drive Roaming	Supported

Caching Operation:

Write-back Cache	Supported.		
Write-through Cache	Supported.		
Supported Memory type	SDRAM memory for enhanced performance Fast Page Memory with Parity for enhanced data security		
Read-ahead Operation	Intelligent Dynamic read-ahead operation for sequential data accessing		
Multi-Threaded Operation	Yes		
Scatter / Gather	Supported		
I/O sorting	Supported. Optimized I/O sorting for enhanced performance		
Variable Stripe Size		Opt. for Sequential I/O	Opt. for Random I/O

	RAID0	128	32
	RAID1	128	32
	RAID3	16	4
	RAID5	128	32
Caching Optimization			
	<ul style="list-style-type: none"> • Cache buffer sorting prior to cache flush operation 		
	<ul style="list-style-type: none"> • Gathering of writes during flush operation to minimize the number of IOs required for parity update 		
	<ul style="list-style-type: none"> • Elevator sorting and gathering of drive IOs 		
	<ul style="list-style-type: none"> • Multiple concurrent drive IOs (tagged commands) 		
	<ul style="list-style-type: none"> • Intelligent, predictive multi-threaded read-ahead 		
	<ul style="list-style-type: none"> • Multiple, concurrent host IO threads (host command queuing) 		

RAID Expansion:

On-line RAID Expansion	Supported. Capacity brought by array expansion is immediately ready for Host I/Os when its status changes from "EXPAND" to "INITIALIZING." Initialization task is then completed in the background except when the logical array is stated as "INCOMPLETE" or "BAD;" e.g., has a failed member right after creation.
Mode-1 RAID Expansion-add Drive	Supported. Multiple drives can be added concurrently. Add Drive can even be performed in degraded mode.
Mode-2 RAID Expansion – Copy and Replace drives	Supported. Replace members with drives of larger capacity.
Expand Capacity with no extra drive bays required	Supported in Mode 2 RAID expansion. Provide "Copy and Replace Drive" function to replace drives with drives of greater capacity. No need to add another enclosure for the extra drives.
Operating system support for RAID Expansion	No. No operating system driver required. No software has to be installed for this purpose.

Fibre Channel Support:

Fibre Channel Support	All Firmware supports Fibre Channels
Channel Mode	All channels configurable to Host or Drive mode, RCC or Drive+RCC, user configurable.
Redundant controller	Redundant using FC controllers supported.
Host-side loop failure detection	Supported. The LIPs on the host channels will not be displayed to users.
Drive-side loop failure detection	Supported.
Point-to-point topology	Supported.
Arbitrated loop topology	Supported.
Fabric topology	Supported.
Host Redundant loop / dual-loop topology	Supported. (Also requires the host computer Fibre HBA driver support)
Drive side redundant loop load-sharing	Workloads can be automatically balanced between member loops for performance optimization.
Fibre channel ID	User selectable from ID 0 to 125.
Fibre channel CRC	Supported
Point-to-point and FC-AL protocol	User configurable.
LUN Filtering (RAID-Based Mapping)	<p>Host LUN mapping with user-configurable Filter entry and Filter type (access control), up to 128 Filter entries can be appended to Host-ID/LUN combinations.</p> <ul style="list-style-type: none"> ▪ Host channel HBA WWN browsing: a list of WWNs from detected HBAs on the host channel will be provided for user's convenience when masking LUN Filtering. ▪ Bit-masking: Based on the user provided WWN of the host HBA (user can enter the WWN manually from a list browsed or that provided by the controller). Users can also assign a bit-masking to group a certain group of WWNs to be included in the LUN Filtering. ▪ Read/Write Privilege: Users can choose the following privilege for each LUN Filtering: Read/Write, Read Only, and No Access.
WWN table stored in NVRAM	Each WWN number can be assigned with a nick name for ease of identification
Sync. cache channel over Fibre loops	Supported, no extra cabling between two controllers; communications data can be distributed to one or two dedicated channels or over all drive loops.

S.M.A.R.T. Support:

Copy & Replace Drive	Supported. User can choose to clone a member drive before drive failure.
Drive S.M.A.R.T. Support	Supported, with intelligent error handling implementations.
User selectable modes for S.M.A.R.T.	<ol style="list-style-type: none"> 1. Detect only 2. Perpetual Clone on detection of S.M.A.R.T. condition 3. Clone + Replace

Redundant Controller:

Active-active redundant controller	Supported
Synchronized cache	<p>Supported. Through single or redundant, dedicated synchronizing channels. Synchronized cache over Fibre loops is supported.</p> <p>Synchronized cache can be disabled when using write-through mode in redundant controllers to prevent performance trade-offs.</p>
Write-back cache enabled in redundant controller mode	Yes; with synchronized cache connection between controllers.
Automatic Failover	Yes for all PowerPC controllers (user's interaction necessary)
Automatic Failback	Yes for all PowerPC controllers (user's interaction necessary)
Fibre channel redundant controller	Supported.
Controller Hot-Swap	<ul style="list-style-type: none"> ▪ No need to shut down the failed controller before replacing the failed controller. (Customer's design-in hot-swap mechanism necessary) ▪ Support on-line hot-swap of the failed controller. There is no need to reset or shutdown the failed controller. One controller can be pulled out during active I/Os to simulate the destructive controller failure. (Customer's design-in hot-swap mechanism necessary)
Redundant Controller Communication channel	SCSI; RCC Reset signals built-in Fibre channel(s)
Parity Synchronization in redundant controller write-back mode to avoid write-hole	Supported.

Redundant Controller Communication over Fibre loops	Dedicated loops or distribution over drive loops selectable
No Single-point-of-failure	Supported.
Automatic engagement of replacement controller	Supported in PowerPC series
Dynamic cache memory allocation	Yes. Cache memory is dynamically allocated, not fixed.
Environment management	Supported. SAF-TE, S.E.S., ISEMS (I ² C interface); and on-board controller voltage/temp monitor are all supported in both single and redundant controller mode. In the event of controller failure, serves can be taken over by the existing controller.
Cache battery backup	Supported. Battery backup solutions for cache memory are supported in both single controller and redundant modes.
Load sharing	Supported. Workload can be flexibly divided between different controllers by assigning logical configurations of drives (LDs/LVs) to different controllers.
User configurable channel mode	Supported. Channel modes configurable (SCSI or Fibre) as HOST or DRIVE in both single controller and redundant controller mode.
Require a special Firmware for redundant controller?	No. All firmware and all Infortrend external RAID controllers support redundant controller function.
Redundant Controller rolling firmware upgrade	Firmware upgrade can be downloaded to the primary controller and then be adopted by both controllers, without interrupting host I/O.
Redundant Controller firmware synchronization	In the event of controller failure, a replacement controller running a different version of firmware can be combined to restore a redundant system with a failed controller. Different firmware versions can be auto-synchronized later.

Data Safety:

Regenerate Parity of logical drives	Supported. Can be performed every so often by user to ensure that bad sectors do not cause data loss in the event of drive failure.
Bad block auto-reassignment	Supported. Automatic reassignment of bad block
Battery backup for cache memory	Supported. The battery backup solutions provide long-lasting battery support to the cache memory when power failure occurs. The unwritten data in the cache memory can be committed to drive media when power is restored.
Verification on Normal Writes	Supported. Performs read-after-write during normal write processes to ensure data is properly written to drives.
Verification on Rebuild Writes	Supported. Performs read-after-write during rebuild write to ensure data is properly written to drives.

Verification on LD initialization writes	Supported. Performs read-after-write during logical drive initialization to ensure data is properly written to drives.
Drive S.M.A.R.T. support	Supported. Drive failure is predictable with reference to the variables detected. Reaction schemes are selectable from Detect only, Perpetual Clone and Copy + Replace. These options help to improve MTBF.
Clone Failing Drive	Users may choose to clone data from a failing drive to a backup drive manually
Automatic Shutdown on over-temperature condition	Controller automatically starts a shutdown sequence upon the detection of high-ambient temperature for an extended period of time.

System Security:

Password protection	Supported. All settings requires the correct password (if set) to ensure system security.
User-configurable Password validation timeout	Supported. After certain time in absence of user interaction, the password will be requested again. This helps to avoid unauthorized operation when user is away.
SSL-enabled RAIDWatch Agents	Agents communicate to the controller through limited set of authorization options.

Environment Management:

SAF-TE/S.E.S. support	Supported. The SAF-TE/S.E.S. modules can be connected to the drive channel, the controller will detect errors from SAF-TE/S.E.S. devices or notify drive failure via SAF-TE/S.E.S.. <ul style="list-style-type: none"> • Both SAF-TE/S.E.S. via drive and device-self-interfaced are supported. • Redundant SAF-TE/S.E.S. devices are supported • Multiple S.E.S. devices are supported
Dynamic on-lining of enclosure services	Once an expansion unit (JBOD) with supported monitoring interface is combined with a RAID system, its status will be automatically polled.
SAF-TE/S.E.S. polling period	User configurable (50ms, 100ms, 200ms, 500ms, 1~60sec)
ISEMS (Infotrend Simple Enclosure Management Service)	Supported.
Multiple SAF-TE/S.E.S. modules on the same channel	Supported.
Multiple SAF-TE /S.E.S. modules on different channels	Supported.
Mapping SAF-TE/S.E.S. device to host channel for use with Host-based SAF-TE/S.E.S. Monitor	Supported.
Dual-LED drive status indicators	Supported. Both single-LED and dual-LED drive status indicators are supported.
SAF-TE/ S.E.S. Temperature value display	Supported. Display the temperature value provided by enclosure SAF-TE module (if available).
Fault-bus support	Provides the simplest implementation for the enclosure management. All fault-bus input/output signals are active-high/active-low user adjustable.
On-board controller voltage monitors	Supported. Monitors the 3.3V, 5V, and 12V voltage status. Event trigger threshold user configurable.
On-board controller temperature sensors	Supported. Monitors the CPU and board temperature status. Event trigger threshold user configurable.
Enclosure redundant power supply status monitoring	Supported. SAF-TE/S.E.S./ISEMS
Enclosure Fan status monitoring	Supported. SAF-TE/S.E.S./ISEMS
Enclosure UPS status monitoring	Supported. SAF-TE/S.E.S./ISEMS
Enclosure temperature monitoring	Supported. SAF-TE/S.E.S./ISEMS

User Interface:

RAIDWatch on-board	Out-of-band configuration via LAN. Browser accessible configuration option by installing RAIDWatch to reserved space on drive via ftp.
RS-232C Terminal	Supports terminal modes: ANSI, VT-100, ANSI Color. Provides menu-driven user-friendly text-based interface.
Graphical User Interface (Java-based GUI Manager)	Provides user-friendly graphical interface. Communicates with RAID controller via In-band SCSI, In-band Fibre or SNMP (Windows-based GUI). Customers can use Infortrend RAIDWatch or develop their own GUI according to the "External Interface Specification" (contact Infortrend support for this OEM document).
External Interface API for customized host-based management	Supported.
LCD Front Panel	Provides easy access for user instinct operation.
Buzzer alarm	Warns user when any failure or critical event occurs.

Remote Manageability:

Modem Support	The COM 1 port of the controller can be connected to a MODEM for remote manageability.
Auto dial-out	Supported. Can be configured to dial-out to a remote terminal when controller is powered on – for remote administration.
Event dial-out to terminal	Supported. Can be configured to dial-out a remote terminal when an event occurs.
Event dial-out to pager	Supported. Can be configured to dial-out a pager number with message (user configured with AT commands) when an event occurs.
Terminal dial-in	Supported. Can be configured to accept a remote terminal dial-in for remote administration.
Custom Inquiry Serial Number	Custom Inquiry Serial Number (for support of multi-pathing software like Veritas, QLogic, etc)
Remote Redundant Controller Configuration	Supported. Remote redundant controller configuration (support fully automatic failback-user's interaction free)

JBOD-Specific:

Format	Restore controller-maintained defect list to default
Reassign Blocks	Add entry to the defect list maintained by controller on disk drives
Write-verification	Write following by a verify
SMART	Sense data and mode parameters support
Special mode parameters	Error handling page – Enable/Disable retry Caching page – Enable/Disable Read/Write caching SMART enable parameters Geometry – saved on format command completion

Others:

Customization of default settings	Via the IAPPEND utility
Private logo	Supported
WWN seed read from subsystem	Supported
Customizable SNMP trap messages	Supported
Customizable inquiry serial no. data to enable clustering customization	Supported

C

System Functions: Upgrading Firmware

Upgrading Firmware

The RAID controller's firmware resides in flash memory that can be updated through the COM port, LAN port, or via In-band SCSI/Fibre. New releases of firmware are available in the form of a DOS file in the "pub" directory of Infortrend's FTP site or on a 3.5" diskette. The file available at the FTP site is usually a self-extracting file that contains the following:

- FW30Dxyz Firmware Binary (where "xyz" refers to the firmware version)
- B30Buvw Boot Record Binary (where "uvw" refers to the boot record version)
- README.TXT Read this file first before upgrading the firmware/boot record. It contains the most up-to-date information which is very important to the firmware upgrade and usage.

These files must be extracted from the compressed file and copied to a directory in boot drive.

New Features Supported with Firmware 3.21

Background RS-232C Firmware Download:

Host I/Os will not be interrupted during the download process. After the download process is completed, user should find a chance to reset the controller for the new firmware to take effect.

Redundant Controller Rolling Firmware Upgrade:

When download is performed on a dual-controller system, firmware is flashed onto both controllers without interrupting host I/Os. After the download process is completed, the Primary controller will reset and let the Secondary take over the service temporarily. When the Primary comes back on-line, the Secondary

will hand over the workload and then reset itself for the new firmware to take effect. The rolling upgrade is automatically performed by controller firmware and user's intervention is not necessary.

Redundant Controller Firmware Sync-version:

A controller used to replace a failed unit in a dual-controller system is often running a newer release of firmware version. To solve the contention, firmware running on the replacement controller will be downgraded to that running on the surviving controller.

IMPORTANT!

- *Allow the downloading process to finish. Do not reset or turn off the computer or the controller while it is downloading the file. Doing so may result in an unrecoverable error that requires the service of the manufacturer.*
- *While the firmware is new, the boot record that comes with it may be the same version as the one in the controller. If this is the case, there is no need to upgrade the Boot Record Binary.*

NOTE:


- *Controller serial port COM 2 can not be used to download firmware.*
-

Upgrading Firmware Using In-band SCSI + RAIDWatch Manager

Establish the In-band SCSI connection in RAIDWatch Manager


Please refer to RAIDWatch *User's Manual* for details on establishing the In-band SCSI connection for RAIDWatch Manager.

Upgrade Both Boot Record and Firmware Binaries



1. Connect to the RAID system locally or from a remote host using RAIDWatch Manager. While connected to the RAID system, there will be icon(s) with IP address specified on the left of the menu screen. Select by double-clicking the icon of the RAID system which firmware is to be upgraded. Select the controller icon and then select the “RAID system-to-host bus” (usually appears as In-band SCSI). Double-click the RAID-to-host-bus to connect to the desired controller. Choose the “RAID view” icon on the controller panel or the RAID view icon on the control bar. The RAID view window will appear. Choose "Controller" > "Download" -> and click among the selections "Download FW/BR" (Firmware and Boot Record).
2. Provide the boot record binary filename, the RAIDWatch Manager will start to download the boot record binary to the controller.
3. After the boot record download is completed, provide the firmware filename to the RAIDWatch Manager. It will start to download the firmware to the controller.
4. Shutdown the system which is accessing the RAID, then reset the controller in order to use the new downloaded firmware. **With firmware release 3.21 and above**, host I/Os will not be interrupted by the download process. Users may find a chance to stop host I/O and reset the controller for new firmware to take effect.

Upgrade the Firmware Binary Only



1. Connect to the RAID system locally or from a remote host using RAIDWatch Manager. While connected to the RAID system, there will be icon(s) with IP address specified on the left of the menu screen. Select by double-clicking the icon of the RAID system which firmware is to be upgraded. Select the controller icon and then select the “RAID system-to-host bus” (usually appears as In-band SCSI or PCI bus...). Double-click the RAID-to-host-bus to connect to the desired controller. Choose the “RAID view” icon on the controller panel. The RAID view window will appear. Choose "Controller" > "Download" -> and click among the selections "Download FW" (Firmware). If both boot record and firmware are desired to upgrade, choose "Download Firmware".
2. Provide the firmware filename to the RAIDWatch Manager. It will start to download the firmware to the controller.
3. Shutdown the system which is accessing the RAID, then reset the controller in order to use the new downloaded firmware.


Upgrading Firmware Using RS-232C Terminal Emulation

The firmware can be downloaded to the RAID controller by using an ANSI/VT-100 compatible terminal emulation program. Whichever terminal emulation program is used must support the ZMODEM file transfer protocol. The following example uses the HyperTerminal in Windows NT®. Other terminal emulation programs (e.g., Telix and PROCOMM Plus) can perform the firmware upgrade as well.

Establishing the connection for the RS-232C Terminal Emulation


Please refer to chapter 4, "Connecting to Terminal Emulation," and also your hardware manual for details on establishing the connection.

Upgrading Both Boot Record and Firmware Binaries




1. From the Main Menu, scroll down to "System Functions."
2. Go to "Controller Maintenance."
3. Choose "Advanced Maintenance."
4. Select "Download Boot Record and Firmware."
5. Set ZMODEM as the file transfer protocol of your terminal emulation software.
6. Send the Boot Record Binary to the controller. In HyperTerminal, go to the "Transfer" menu and choose "Send file." If you are not using Hyper Terminal, choose "Upload" or "Send" (depending on the software).
7. After the Boot Record has been downloaded, send the Firmware Binary to the controller. In HyperTerminal, go to the "Transfer" menu and choose "Send file." If you are not using Hyper Terminal, choose "Upload" or "Send" (depending on the software).
8. When the Firmware completes downloading, the controller will automatically reset itself.


Upgrading the Firmware Binary Only



1. From the Main Menu, scroll down to "System Functions."
2. Go to "Controller Maintenance."
3. Choose "Download Firmware."
4. Set ZMODEM as the file transfer protocol of your terminal emulation software.
5. Send the Firmware Binary to the controller. In Hyper Terminal, select "Send file." If you are not using HyperTerminal, choose "Upload" or "Send" (depending on the software).



6. When the Firmware completes downloading, the controller will automatically reset itself.



D

Event Messages

The controller events can be categorized as follows:

Alert	Errors that need to attend to immediately
Warning	Errors
Notification	Command processed message sent from Firmware

The controller records all system events from power on, it can record up to 1,000 events. To power off or to reset the controller will cause an automatic deletion of all the recorded event logs.

RAIDWatch manager' sub-module, Event Monitor, can be used to record events on multiple controllers especially when controller reset or power-off is an expected action. The Event Monitor runs independently on a host computer and can store up to 1000 events (per controller unit) regardless of the controller's current status. The software program is Java-based and is usually bundled with RAIDWatch manager. Associated details can be found in the RAIDWatch user's manual.

Descriptions below may contain abbreviations. Abbreviations and Capitalized letters are preserved for the coherency with the event messages shown on LCD screen or terminal.

Event Index

Controller Event

Alert:

- [0104] Controller ALERT: DRAM Parity Error Detected
- [0105] Controller <primary/secondary> SDRAM ECC <multi-bits/single-bit> Error Detected
- [0110] CHL:_ FATAL ERROR (_)
- [0111] Controller ALERT: Redundant Controller Failure Detected
- [0111] Controller NOTICE: Redundant Controller Firmware Updated
- [0114] Controller ALERT: Power Supply Unstable or NVRAM Failed

Warning:

- [0107] Memory Not Sufficient to Fully Support Current Config.

Notification:

[0181] Controller Initialization Completed
[0187] Memory is Now Sufficient to Fully Support Current Config.
[0189] NVRAM Factory Defaults Restored
[0189] NVRAM Restore from Disk is Completed
[0189] NVRAM Restore from File is Completed

Drive SCSI Channel/Drive Error**Drive:****Warning:**

[1101] CHL:_ ID:_ SCSI Target ALERT: Unexpected Select Timeout
[1102] CHL:_ ID:_ SCSI Target ALERT: Gross Phase/Signal Error Detected
[1103] CHL:_ ID:_ SCSI Target ALERT: Unexpected Disconnect Encountered
[1104] CHL:_ ID:_ SCSI Drive ALERT: Negotiation Error Detected
[1105] CHL:_ ID:_ SCSI Target ALERT: Timeout Waiting for I/O to Complete
[1106] CHL:_ ID:_ SCSI Target ALERT: SCSI Parity/CRC Error Detected
[1107] CHL:_ ID:_ SCSI Drive ALERT: Data Overrun/Underrun Detected
[1108] CHL:_ ID:_ SCSI Target ALERT: Invalid Status/Sense Data Received ()
[110f] CHL:_ LIP() Detected
[110f] CHL:_ SCSI Drive Channel Notification: SCSI Bus Reset Issued
[110f] CHL:_ SCSI Drive Channel ALERT: SCSI Bus Reset Issued
[1111] CHL:_ ID:_ SCSI Target ALERT: Unexpected Drive Not Ready
[1112] CHL:_ ID:_ SCSI Drive ALERT: Drive HW Error ()
[1113] CHL:_ ID:_ SCSI Drive ALERT: Bad Block Encountered - ()
[1114] CHL:_ ID:_ SCSI Target ALERT: Unit Attention Received
[1115] CHL:_ ID:_ SCSI Drive ALERT: Unexpected Sense Received ()
[1116] CHL:_ ID:_ SCSI Drive ALERT: Block Reassignment Failed - ()
[1117] CHL:_ ID:_ SCSI Drive ALERT: Block Successfully Reassigned - ()
[1118] CHL:_ ID:_ SCSI Drive ALERT: Aborted Command ()
[1142] SMART-CH:_ ID:_ Predictable Failure Detected (TEST)
[1142] SMART-CH:_ ID:_ Predictable Failure Detected
[1142] SMART-CH:_ ID:_ Predictable Failure Detected-Starting Clone
[1142] SMART-CH:_ ID:_ Predictable Failure Detected-Clone Failed
[11c1] CHL:_ ID:_ SCSI Drive NOTICE: Scan SCSI Drive Successful

Channel:**Warning:**

[113f] CHL:_ ALERT: Redundant Loop Connection Error Detected on ID:_
[113f] CHL:_ SCSI Drive Channel ALERT: SCSI Channel Failure
[113f] CHL:_ ALERT: Fibre Channel Loop Failure Detected
[113f] CHL:_ ALERT: Redundant Loop for Chl:_ Failure Detected
[113f] CHL:_ ALERT: Redundant Path for Chl:_ ID:_ Expected but Not Found
[113f] CHL:_ ID:_ ALERT: Redundant Path for Chl:_ ID:_ Failure Detected

Notification:

[113f] CHL:_ NOTICE: Fibre Channel Loop Connection Restored

[113f] CHL:_ ID:_ NOTICE: Redundant Path for Chl:_ ID:_ Restored

Logical Drive Event

Alert:

[2101] LG: <NA/Logical Drive Index> Logical Drive ALERT: CHL:_ ID:_ SCSI Drive Failure
[2103] LG:_ Logical Drive ALERT: Rebuild Failed
[2106] LG:_ Logical Drive ALERT: Add SCSI Drive Operation Failed

Warning:

[2102] LG:_ Logical Drive ALERT: Initialization Failed
[2102] LG:_ Logical Drive ALERT: Off-line Initialization Failed
[2104] LG:_ Logical Drive ALERT: Parity Regeneration Failed
[2105] LG:_ Logical Drive ALERT: Expansion Failed
[2111] LG:_ Logical Drive ALERT: CHL:_ ID:_ Clone Failed
[2141] LG:_ Logical Drive ALERT: Logical Drive Bad Block Table FULL
[2142] LG:_ Logical Drive ALERT: Logical Drive Block Marked BAD
[2341] LG:_ Logical Drive ALERT: Logical Drive Bad Block Table BAD
[2343] CH:_ ID:_ ALERT: Media Scan Bad Block Recover FAILED-0x0
[2541] LG:_ Logical Drive ALERT: Logical Drive On-Line Init Table BAD

Notification:

[2143] CHL:_ ID:_ NOTICE: Media Scan Bad Block Recovered-0x0
[2144] LG:_ NOTICE: Inconsistent Parity Encountered Block _
[2181] LG:_ Logical Drive NOTICE: Starting Initialization
[2181] LG:_ Logical Drive NOTICE: Starting Off-line Initialization
[2182] Off-line Initialization of Logical Drive _ Completed
[2182] Initialization of Logical Drive _ Completed
[2183] LG:_ Logical Drive NOTICE: Starting Rebuild
[2184] Rebuild of Logical Drive _ Completed
[2185] LG:_ Logical Drive NOTICE: Starting Parity Regeneration
[2186] Parity Regeneration of Logical Drive _ Completed
[2187] LG:_ Logical Drive NOTICE: Starting Expansion
[2188] Expansion of Logical Drive _ Completed
[2189] LG:_ Logical Drive NOTICE: Starting Add SCSI Drive Operation
[218a] Add SCSI Drive to Logical Drive _ Completed
[218b] LG:_ Logical Drive NOTICE: Add SCSI Drive Operation Paused
[2102] LG:_ Logical Drive NOTICE: Starting Media Scan
[2xxx] LG:_ Media Scan of Logical Drive _ Completed
[218c] LG:_ Logical Drive NOTICE: Continue Add SCSI Drive Operation
[21a1] LG:_ Logical Drive NOTICE: CHL:_ ID:_ Starting Clone"
[21a2] LG:_ Logical Drive NOTICE: CHL:_ ID:_ Clone Completed"
[2344] LG:_ NOTICE: Media Error Encountered During Check Parity _
[2344] LG:_ NOTICE: Inconsistent Parity Block _ Regenerated
[2542] LG:_ Logical Drive NOTICE: Logical Drive Block Recovered
[2544] LG:_ NOTICE: Media Error During Check Parity Recovered _

General Target Events

Alert:

SAF-TE Device:

- [3f21] SAF-TE Device () ALERT: Power Supply Failure Detected ()
- [3f22] SAF-TE Device () ALERT: Cooling Fan Not Installed ()
- [3f22] SAF-TE Device () ALERT: Cooling Fan Failure Detected ()
- [3f23] SAF-TE Device () ALERT: Elevated Temperature Alert ()
- [3f24] SAF-TE Device () ALERT: UPS Power Failure Detected ()

Controller on-board:

- [3f23] Peripheral Device ALERT: CPU Temperature <high/low threshold> Temperature Detected (._C)
- [3f23] Peripheral Device ALERT: Board1 Temperature <high/low threshold> Temperature Detected (._C)
- [3f23] Peripheral Device ALERT: Board2 Temperature <high/low threshold> Temperature Detected (._C)
- [3f22] Peripheral Device ALERT: Controller FAN _ Not Present or Failure Detected
- [3f22] Peripheral Device ALERT: Controller FAN _ <high/low threshold> Speed Detected (_RPM)
- [3f21] Peripheral Device ALERT: +3.3V <upper/lower threshold> Voltage Detected ()
- [3f21] Peripheral Device ALERT: +5V <upper/lower threshold> Voltage Detected ()
- [3f21] Peripheral Device ALERT: +12V <upper/lower threshold> Voltage Detected ()

PC Device:

- [3f23] Peripheral Device ALERT: Temperature Sensor _ Failure Detected
- [3f23] Peripheral Device ALERT: Temperature Sensor _ Not Present
- [3f23] Peripheral Device ALERT: <high/low threshold> Temperature _ Detected (.(F/C))
- [3f22] Peripheral Device ALERT: FAN _ Failure Detected
- [3f22] Peripheral Device ALERT: FAN _ Not Present
- [3f22] Peripheral Device ALERT: <high/low threshold> FAN _ Speed Detected (._RPM)
- [3f21] Peripheral Device ALERT: Power Supply _ Failure Detected
- [3f21] Peripheral Device ALERT: Power Supply _ Not Present
- [3f21] Peripheral Device ALERT: <high/low threshold> Power Supply _ Voltage Detected ()
- [3f24] Peripheral Device ALERT: UPS _ AC Power Failure Detected
- [3f24] Peripheral Device ALERT: UPS _ Battery Failure Detected

SES Devices:

- [3f21] SES (C_ I_) Power Supply _: <Vendor descriptor strings/Device Not Supported>!
- [3f21] SES (C_ I_) Power Supply _: <Vendor descriptor strings/Device Not

Installed>!
[3f21] SES (C_I) Power Supply _: <Vendor descriptor strings/Device Unknown Status>!
[3f21] SES (C_I) Power Supply _: <Vendor descriptor strings/Device Not Available>!
[3f22] SES (C_I) Cooling element _: <Vendor descriptor strings/Device Not Supported>!
[3f22] SES (C_I) Cooling element _: <Vendor descriptor strings/Device Not installed>!
[3f22] SES (C_I) Cooling element _: <Vendor descriptor strings/Device Unknown Status>!
[3f22] SES (C_I) Cooling element _: <Vendor descriptor strings/Device Not Available>!
[3f23] SES (C_I) Temperature Sensor _: <Vendor descriptor strings/Device Not Supported>!
[3f23] SES (C_I) Temperature Sensor _: <Vendor descriptor strings/Device Not installed>!
[3f23] SES (C_I) Temperature Sensor _: <Vendor descriptor strings/Device Unknown Status>!
[3f23] SES (C_I) Temperature Sensor _: <Vendor descriptor strings/Device Not Available>!
[3f24] SES (C_I) UPS _: <Vendor descriptor strings/Device Not Supported>!
[3f24] SES (C_I) UPS _: <Vendor descriptor strings/Device Not installed>!
[3f24] SES (C_I) UPS _: <Vendor descriptor strings/Device Unknown Status>!
[3f24] SES (C_I) UPS _: <Vendor descriptor strings/Device Not Available>!
[3f21] SES (C_I) Voltage sensor _: <Vendor descriptor strings/Device Not Supported>!
[3f21] SES (C_I) Voltage sensor _: <Vendor descriptor strings/Device Not installed>!
[3f21] SES (C_I) Voltage sensor _: <Vendor descriptor strings/Device Unknown Status>!
[3f21] SES (C_I) Voltage sensor _: <Vendor descriptor strings/Device Not Available>!
[3f21] SES (C_I) Current sensor _: <Vendor descriptor strings/Device Not Supported>!
[3f21] SES (C_I) Current sensor _: <Vendor descriptor strings/Device Not installed>!
[3f21] SES (C_I) Current sensor _: <Vendor descriptor strings/Device Unknown Status>!
[3f21] SES (C_I) Current sensor _: <Vendor descriptor strings/Device Not Available>!

General Peripheral Device:

[3f21] Peripheral Device ALERT: Power Supply Failure Detected
[3f22] Cooling Fan Not Installed
[3f22] Cooling Fan Failure Detected
[3f24] Elevated Temperature Alert
[3f24] UPS Power Failure Detected

Notification:

SAF-TE Device:

[3fa2] SAF-TE Device () NOTICE: Fan Back On-Line (Idx:_)
[3fa3] SAF-TE Device () NOTICE: Temperature Back to Non-Critical Levels
(Idx:_)
[3fa1] SAF-TE Device () NOTICE: Power Supply Back On-Line (Idx:_)
[3fa4] SAF-TE Device () NOTICE: UPS Power Back On-Line (Idx:_)

Controller Self Diagnostics:

[3fa3] CPU <high/low threshold> Temperature Back To Non-Critical Levels (_
C)
[3fa3] Board _ <high/low threshold> Temperature Back To Non-Critical Levels
(_ C)
[3fa1] +3.3V <upper/lower threshold> Voltage Back within Acceptable Limits
[3fa1] +5V <upper/lower threshold> Voltage Back within Acceptable Limits
[3fa1] +12V <upper/lower threshold> Voltage Back within Acceptable Limits
[3fa2] NOTICE: Controller FAN _ Back On-Line (_ RPM)

PC Device:

[3fa3] NOTICE: Temperature _ Back to Non-Critical Levels
[3fa3] NOTICE: Temperature _ is present
[3fa3] NOTICE: Temperature _ Back to Non-Critical Levels (_(C/F))
[3fa2] NOTICE: FAN _ Back On-Line
[3fa2] NOTICE: FAN _ is Present
[3fa2] NOTICE: FAN _ Back On-Line
[3fa1] NOTICE: Power Supply _ Back On-Line
[3fa1] NOTICE: Power Supply _ is Present
[3fa1] NOTICE: Power Supply _ Back On-Line (<voltage>0
[3fa4] Peripheral Device NOTICE: UPS _ AC Power Back On-Line
[3fa4] Peripheral Device NOTICE: UPS _ Battery Back On-Line

SES Devices:

[3f21] SES (C_ I_) Power Supply _: Power Supply Failure Detected
[3f22] SES (C_ I_) Cooling element _: Cooling Fan Not Installed
[3f22] SES (C_ I_) Cooling element _: Cooling Fan Failure Detected
[3f23] SES (C_ I_) Temperature Sensor _: Elevated Temperature Alert
[3f24] SES (C_ I_) UPS _: UPS Power Failure Detected

General Peripheral Device:

[3f21] Peripheral Device ALERT: Power Supply Failure Detected
[3f22] Cooling Fan Not Installed
[3f22] Cooling Fan Failure Detected
[3f24] Elevated Temperature Alert
[3f24] UPS Power Failure Detected

Controller Event

Alert:

2-Line LCD	DRAM Parity Error Detected
Terminal	[0104] Controller ALERT: DRAM Parity Error Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	A DRAM parity error encountered.
What to Do?	Contact your RAID system supplier and replace with new module(s) if necessary.
2-Line LCD	DRAM Parity Error Detected
Terminal	[0105] Controller <primary/secondary> SDRAM ECC <multi-bits/single-bit> Error Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	A DRAM ECC detected error encountered.
What to Do?	Contact your RAID system supplier and replace with new module(s) if necessary.?
2-Line LCD	CHL:_ FATAL ERROR (_)
Terminal	[0110] CHL:_ FATAL ERROR (_)
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	One channel has failed.
What to Do?	Check if cable connectors are firmly seated and SCSI buses are properly terminated. With Fibre channels, disconnection may happen on the host side, hub or switch, etc. In redundant mode, the counterpart controller will take over and you may ask your system provider to remove the controller with a failed channel for a repair.
2-Line LCD	Redundant Ctlr Failure Detected
Terminal	[0111] Controller ALERT: Redundant Controller Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	One of the RAID controllers has failed.
What to Do?	Contact your RAID system supplier for a replacement controller.
2-Line LCD	Redundant Ctlr Failure Detected
Terminal	[0111] Controller NOTICE: Redundant Controller Firmware Updated
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	RAID controllers have finished shifting I/Os, resetting, and have come online with new version of firmware.
What to Do?	

2-Line LCD	Power Supply Unstable or NVRAM Failed
Terminal	[0114] Controller ALERT: Power Supply Unstable or NVRAM Failed
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The output voltage drops below preset thresholds or NVRAM component failure.
What to Do?	

Warning:

2-Line LCD	Memory Not Sufficient to Fully Support Current Config.
Terminal	[0107] Memory Not Sufficient to Fully Support Current Config.
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The installed size of memory does not support current configuration. Try increase memory size.
What to Do?	

Notification:

2-Line LCD	Controller Initialization Completed
Terminal	[0181] Controller Initialization Completed
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Controller initialization completed
What to Do?	

2-Line LCD	Memory is Now Sufficient to Fully Support Current Config.
Terminal	[0187] Memory is Now Sufficient to Fully Support Current Config.
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Memory size has been expanded.
What to Do?	

2-Line LCD	NVRAM Factory Defaults Restored
Terminal	[0189] NVRAM Factory Defaults Restored
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Firmware settings have been restored to factory defaults. Options for restoring defaults are not available to users and are only reserved for qualified engineers.
What to Do?	

2-Line LCD	NVRAM Restore from Disk is Completed		
Terminal	[0189] NVRAM Restore from Disk is Completed		
Event Type	<input type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input checked="" type="checkbox"/> Notification
What Happens?	Firmware configuration data previously saved to disk is restored.		
What to Do?			

2-Line LCD	NVRAM Restore from File is Completed		
Terminal	[0189] NVRAM Restore from File is Completed		
Event Type	<input type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input checked="" type="checkbox"/> Notification
What Happens?	Firmware configuration data previously saved as a file is restored.		
What to Do?			

Drive SCSI Channel/Drive Error

Drive

Warning:

2-Line LCD	C:_ I:_ SCSI Target ALERT
Terminal	[1101] CHL:_ ID:_ SCSI Target ALERT: Unexpected Select Timeout
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive SCSI target select timeout. The specified hard drive cannot be selected by the controller. Whether the drive has been removed, or the cabling/termination/canister is out of order.
What to Do?	Check drive-side SCSI cable/termination and drive canister connections.
2-Line LCD	C:_ I:_ SCSI Target ALERT: Gross Phase/Signal Error Detected
Terminal	[1102] CHL:_ ID:_ SCSI Target ALERT: Gross Phase/Signal Error Detected
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-side SCSI phase/signal abnormality detected.
What to Do?	Press <ESC> to clear the message.
2-Line LCD	C:_ I:_ SCSI Target ALERT: Unexpected Disconnect Encountered
Terminal	[1103] CHL:_ I:_ SCSI Target ALERT: Unexpected Disconnect Encountered
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-side SCSI target unexpected disconnect detected.
What to Do?	Check cabling/termination and canister connections.
2-Line LCD	C:_ I:_ SCSI Drive ALERT: Negotiation Error Detected
Terminal	[1104] CHL:_ ID:_ SCSI Drive ALERT: Negotiation Error Detected
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-side SCSI target sync/wide negotiation abnormality detected.
What to Do?	

2-Line LCD	C:_ I:_ Timeout Waiting for I/O
Terminal	[1105] CHL:_ ID:_ SCSI Target ALERT: Timeout Waiting for I/O to Complete
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-side SCSI target I/O timeout. Possible drive-side cabling/termination and canister connection abnormal or drive malfunctioning.
What to Do?	Check drive-side cabling/termination/canister connections and hard drive.
2-Line LCD	C:_ I:_ Parity Error
Terminal	[1106] CHL:_ ID:_ SCSI Target ALERT: SCSI Parity/CRC Error Detected
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-side SCSI channel parity or CRC error detected to the specified hard drive.
What to Do?	Check drive-side cable/termination or drive canister connection.
2-Line LCD	C:_ I:_ Data Overrun/Underrun
Terminal	[1107] CHL:_ ID:_ SCSI Target ALERT: Data Overrun/Underrun Detected
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-side SCSI target data overrun or underrun detected.
What to Do?	Check drive-side cabling/termination/canister connections and hard drive.
2-Line LCD	C:_ I:_ Invalid Data Received
Terminal	[1108] CHL:_ ID:_ SCSI Target ALERT: Invalid Status/Sense Data Received (<i>Sense_key Sense_code</i>)
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-side SCSI invalid status/sense data received from target
What to Do?	Check cabling/termination/canister connections.
2-Line LCD	C:_ LIP(__) Detected
Terminal	[110F] CHL:_ LIP(__) Detected
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Fibre Loop LIP issued.
What to Do?	Press [ESC] to clear the error message.

2-Line LCD	C:_ SCSI Drive Channel Notification: SCSI Bus Reset Issued
Terminal	[110f] CHL:_ SCSI Drive Channel Notification: SCSI Bus Reset Issued
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	SCSI bus reset issued
What to Do?	
2-Line LCD	C:_ I:_ SCSI Target ALERT: Unexpected Drive Not Ready
Terminal	[1111] CHL:_ ID:_ SCSI Drive ALERT: CHL:_ ID:_ Clone Failed
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive installed does not respond with "Ready"
What to Do?	Check hard drive and drive-side cabling/termination/canister connections.
2-Line LCD	C:_ I:_ Drive HW Error
Terminal	[1112] CHL:_ ID:_ SCSI Drive ALERT: Drive HW Error (<i>Sense_key Sense_code</i>)
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-Side SCSI drive unrecoverable hardware error reported
What to Do?	Replace hard drive and the rebuild may begin with a hot-spare or a replacement drive
2-Line LCD	C=_ I=_ Bad Block Encountered
Terminal	[1113] CHL:_ ID:_ SCSI Drive ALERT: Bad Block Encountered - <i>Block_number (Sense_key Sense_code)</i>
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Hard drive unrecoverable media error reported. A bad block is encountered in the specified hard drive. The RAID controller will ask the hard drive to retry.
What to Do?	Press [ESC] to clear the message.
2-Line LCD	C=_ I=_ Unit Attention Received
Terminal	[1114] CHL:_ ID:_ SCSI Target ALERT: Unit Attention Received (<i>Sense_key Sense_code</i>)
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-side SCSI target unit attention received.
What to Do?	Check hard drive and drive-side cabling/termination/canister connections.

2-Line LCD	C=_ I=_ Unexpected Sense Rec.
Terminal	[1115] CHL:_ ID:_ SCSI Drive ALERT: Unexpected Sense Received (<i>Sense_key Sense_code</i>)
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-side SCSI drive unexpected sense data received.
What to Do?	Checking drive-side cabling/termination/drive canister connections. This might result from a bad signal quality of poor connection, etc.
2-Line LCD	C=_ I=_ Block Reassign Failed
Terminal	[1116] CHL:_ ID:_ SCSI Drive ALERT: Block Reassignment Failed - <i>Block_number (Sense_key Sense_code)</i>
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Drive-side block reassignment failed. Drive will be considered failed.
What to Do?	Press [ESC] to clear this error message.
2-Line LCD	C=_ I=_ Block Success Reassign
Terminal	[1117] CHL:_ ID:_ SCSI Drive ALERT: Block Successfully Reassigned - <i>Block_number (Sense_key Sense_code)</i>
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Bad blocks have been reassigned successfully
What to Do?	Press [ESC] to clear this message.
2-Line LCD	CHL=_ ID=_ Aborted Command
Terminal	[1118] CHL:_ ID:_ SCSI Drive ALERT: Aborted Command (<i>Sense_key Sense_code</i>)
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	SCSI drive aborted command reported
What to Do?	Press [ESC] to clear the error message.

2-Line LCD	C:_ I:_ Predictable Failure Detected (TEST)
Terminal	[1142] SMART-CH:_ ID:_ Predictable Failure Detected (TEST)
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	This message appears when simulating the SMART detect function. This message shows that your drives support SMART functions.
What to Do?	Press [ESC] to clear the error message.

2-Line LCD	C:_ I:_ Predictable Failure Detected
Terminal	[1142] SMART-CH:_ ID:_ Predictable Failure Detected
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	SMART-related errors detected. This message will only be displayed when SMART detect is enabled.
What to Do?	

2-Line LCD	C:_ I:_ Predictable Failure Detected-Starting Clone
Terminal	[1142] SMART-CH:_ ID:_ Predictable Failure Detected-Starting Clone
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	SMART errors detected, a spare is conducted to rebuild and to replace the faulty drive. This is a response to the preset scheme.
What to Do?	

2-Line LCD	C:_ I:_ Predictable Failure Detected-Clone Failed
Terminal	[1142] SMART-CH:_ ID:_ Predictable Failure Detected-Clone Failed
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	SMART errors detected and a spare is conducted to rebuild. The cloning process is halted due to power interruption and some other reasons.
What to Do?	

2-Line LCD	C:_ I:_ Scan SCSI Drive Successful
Terminal	[11c1] CHL:_ ID:_ SCSI Drive NOTICE: Scan SCSI Drive Successful
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Scanning a new drive from on a SCSI drive successful.
What to Do?	

Channel:

Warning:

2-Line LCD	Chl:_ Redundant Loop Connection Error Detected on ID:_
Terminal	[113f] CHL:_ ALERT: Redundant Loop Connection Error Detected on ID:_
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	One of the dual loop members may have failed or been disconnected. Make sure all channels are properly connected and topological configuration properly set.
What to Do?	Check the redundant fibre channel loop connection is right.

2-Line LCD	Chl:_ SCSI Drive Channel ALERT: SCSI Channel Failure
Terminal	[113f] CHL:_ SCSI Drive Channel ALERT: SCSI Channel Failure
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Specific drive channel may have failed or disconnected.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Chl:_ Fibre Channel Loop Failure Detected
Terminal	[113f] CHL:_ ALERT: Fibre Channel Loop Failure Detected
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Fibre channel loop failure is detected.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Chl:_ Redundant Loop for Chl:_ Failure Detected
Terminal	[113f] CHL:_ ALERT: Redundant loop for Chl:_ Failure Detected
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The pair loop has failed.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Chl:_ Redundant Path for Chl:_ ID:_ Expected but Not Found
Terminal	[113f] CHL:_ ALERT: Redundant Path for Chl:_ ID:_ Expected but Not Found
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Disconnection with the pair loop may have occurred.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	C:_ I:_ -Red Path for C:_ I:_ Failure Detected
-------------------	--

Terminal	[113f] CHL:_ ID:_ ALERT: Redundant Path for Chl:_ ID:_ Failure Detected
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Disconnection with the pair loop may have occurred.
What to Do?	Press <ESC> to clear the message.

Notification:

2-Line LCD	C:_ Fibre Chl Loop Connection Restored
Terminal	[113f] CHL:_ NOTICE: Fibre Channel Loop Connection Restored
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Fibre loop connection restored
What to Do?	Press <ESC> to clear the message.

2-Line LCD	C:_ I:_ -Red Path C:_ I:_ Restored
Terminal	[113f] CHL:_ ID:_ NOTICE: Redundant Path for Chl:_ ID:_ Restored
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	The connection with pair loop regained.
What to Do?	Press <ESC> to clear the message.

Logical Drive Event:

Alert:

2-Line LCD	CHL:_ ID=_ Drive Failure
Terminal	[2101] LG: <NA/Logical Drive Index> Logical Drive ALERT: CHL:_ ID:_ SCSI Drive Failure
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The specified hard drive in the specified logical drive has failed.
What to Do?	If a spare is available, the controller will automatically start rebuild. If there is no spare, replace the faulty drive and rebuild will be automatically initiated.
2-Line LCD	LG ALERT: Rebuild Failed!
Terminal	[2103] LG:_ Logical Drive ALERT: Rebuild Failed
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Logical drive rebuild failed. It could result from one of the following reasons: <ol style="list-style-type: none">1. The rebuild has been canceled by user.2. The drive used for rebuild might have failed during rebuild.3. Bad blocks are encountered on another member drive during the rebuild.
What to Do?	Carefully identify and replace the faulty drive and perform logical drive initialization again.
2-Line LCD	LG ALERT: Add Drive Failed!
Terminal	[2106] LG:_ Logical Drive ALERT: Add SCSI Drive Operation Failed
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	This is a fatal error encountered when a new drive is being added to an existing logical drive. It could result from one of the following reasons: <ol style="list-style-type: none">1. Unrecoverable hardware failure during the expansion process.2. Errors are found concurrently on two member drives.3. Bad blocks are encountered on another member drive during the expansion.
What to Do?	Data in the target logical drive will be lost.

Warning:

2-Line LCD	LG ALERT: Init Failed!
Terminal	[2102] LG:_ Logical Drive ALERT: Initialization Failed
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Logical drive initialization failed. It could result from one of the following reasons: 1. Logical drive initialization canceled by user. 2. On of the member drives failed during logical drive initialization. 3. One of the member drive encountered bad block.
What to Do?	Carefully identify and replace the faulty drive and let the logical drive re-initialize and start rebuild.

2-Line LCD	LG=_ Parity Regen Failed !
Terminal	[2104] LG_ Logical Drive ALERT: Parity Regeneration Failed
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	During the parity-regeneration process, one member drive has failed.
What to Do?	Rebuild the logical drive first, then perform "Regenerate Parity." Regeneration can only be performed on a "Good" (GD) logical drive.

2-Line LCD	C:_ I:_ Clone Failed!
Terminal	[2111] LG_ Logical Drive ALERT: CHL:_ ID:_ Clone Failed
Event Type	<input type="checkbox"/> Alert <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The clone drive operation has failed or halted by system error.
What to Do?	One of the member drives might have failed during the process. Replace the faulty drive and let the system rebuild. Data on the source drive (from where the spare clone data) may still be intact. Locate and replace the faulty drive and rebuild.

Notification:

2-Line LCD	LG=_ Starting Init
Terminal	[2181] LG_ Logical Drive NOTICE: Starting Initialization
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	The controller starts initialize the logical drive.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	LG=_ Initialization Completed!
Terminal	[2182] Initialization of Logical Drive_ Completed
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	The initialization process of LG_ has been completed.
What to Do?	Press <ESC> to clear the message. See if host computer can recognize the RAID drive.

2-Line LCD	LG=_ Starting Rebuild !
-------------------	-------------------------

Terminal	[2183] LG_ Logical Drive NOTICE: Starting Rebuild
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	The rebuild process has begun.
What to Do?	This is the message displayed when a stand-by spare is available or when a faulty drive is replaced. The controller automatically detects a drive for rebuild.
2-Line LCD	LG=_ Rebuild Complete
Terminal	[2184] Rebuild of Logical Drive_ Completed
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	The controller has successfully rebuilt a logical drive.
What to Do?	Press <ESC> to clear the message.
2-Line LCD	LG=_ Starting Parity Regen
Terminal	[2185] LG=_ Logical Drive NOTICE: Starting Parity Regeneration
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Start regenerating parity of a logical drive.
What to Do?	Press <ESC> to clear the message.
2-Line LCD	LG=_ Parity Regen Completed
Terminal	[2186] Parity Regeneration of Logical Drive_ Completed
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	The regeneration process completed.
What to Do?	Press <ESC> to clear the message.
2-Line LCD	LG=_ Start Expand
Terminal	[2187] LG_ Logical Drive NOTICE: Starting Expansion
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Start expanding the logical drive.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	LG=_ Expansion Completed
Terminal	[2188] Expansion of Logical Drive_ Completed
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Logical drive expansion completed.
What to Do?	Press <ESC> to clear the message.
2-Line LCD	LG=_ Logical Drive NOTICE: Starting Add SCSI Drive Operation
Terminal	[2189] LG_ Logical Drive NOTICE: Starting Add SCSI Drive Operation
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Expansion “by adding new drive” has started.
What to Do?	Press <ESC> to clear the message.
2-Line LCD	LG=_ Add SCSI Drive Completed
Terminal	[218a] Add SCSI Drive to Logical Drive_ Completed
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	The expansion “by adding new drive” is completed.
What to Do?	Press <ESC> to clear the message.
2-Line LCD	LG=_ Add SCSI Drive Paused
Terminal	[218b] LG:_ Logical Drive NOTICE: Add SCSI Drive Operation Paused
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	The expansion process is halted by: <ul style="list-style-type: none"> 1. Logical drive expansion canceled by user. 2. On of the member drives failed during logical drive initialization. 3. One of the member drive encountered bad block 4. Hardware failure
What to Do?	If the target logical drive has failed, try to rebuild the logical drive.
2-Line LCD	LG=_ Continue Add SCSI Drive
Terminal	[218c] LG:_ Logical Drive NOTICE: Continue Add SCSI Drive Operation
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	The target logical drive has been restored to its previous status, and the add drive operation may continue.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	C:_ I:_ Starting Clone
Terminal	[21a1] LG:_ Logical Drive NOTICE: CHL:_ ID:_ Starting Clone
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	This message is displayed when a member drive is manually cloned to a spare, or that a spare is automatically applied to clone a faulty member according to the preset scheme.
What to Do?	Press <ESC> to clear the message. When cloning is completed, carefully identify and replace the faulty drive.
2-Line LCD	C:_ I:_ Clone Completed
Terminal	[21a2] LG:_ Logical Drive NOTICE: CHL:_ ID:_ Clone Complted
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	The clone process has been completed.
What to Do?	Press <ESC> to clear the message. When cloning is completed, carefully identify and replace the faulty drive.

General Target Events:

Alert:

SAF-TE Device:

2-Line LCD	SAFTE_ : Power () Failure Detected
Terminal	[3F21] SAF-TE Device () ALERT: Power Supply Failure Detected ()
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Power supply failure detected by SAF-TE enclosure management.
What to Do?	Check the power supply module, contact your RAID system supplier.

2-Line LCD	SAFTE_ : Fan () Not Installed
Terminal	[3F22] SAF-TE Device () ALERT: Cooling Fan Not Installed ()
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The installed fan () is missing.
What to Do?	See if the fan has been removed or a general failure has occurred. Contact your system supplier.

2-Line LCD	SAFTE_ : Fan () Failure Detected
Terminal	[3F22] SAF-TE Device () ALERT: Cooling Fan Failure Detected ()
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The cooling fan has failed.
What to Do?	Contact your system supplier for further diagnosis.

2-Line LCD	SAF-TE_ : Elevated Temperature Alert
Terminal	[3F23] SAF-TE Device () ALERT: Elevated Temperature Alert ()
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	High temperature detected.
What to Do?	High temperature may lead to malfunctioning and system failure. The most probable cause is the cooling system failure. Contact your system provider immediately.

2-Line LCD	SAF-TE_ : UPS Power Failure
Terminal	[3F24] SAF-TE Device () ALERT: UPS Power Failure Detected ()
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	UPS Power Failure.
What to Do?	If UPS protection is lost, inconsistency may occur to cached data upon power interruption. Auto-switch to write-through cache upon the detection of UPS failure will be available in future release of firmware. Contact your system provider for help.

Controller On-board:

2-Line LCD	CPU (._) Temp Detected		
Terminal	[3f23] Peripheral Device ALERT: CPU Temperature <high/low threshold> Temperature Detected (._C)		
Event Type	<input checked="" type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input type="checkbox"/> Notification
What Happens?	The detected CPU temperature is higher or lower than the preset thresholds.		
What to Do?	Check the enclosure ventilation condition. If necessary, temperature thresholds can be modified to suit different working conditions.		

2-Line LCD	Board 1 (._) Temp Detected		
Terminal	[3f23] Peripheral Device ALERT: Board 1 Temperature <high/low threshold> Temperature Detected (._C)		
Event Type	<input checked="" type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input type="checkbox"/> Notification
What Happens?	The detected main circuit board temperature is higher or lower than the preset thresholds.		
What to Do?	Check the enclosure ventilation condition. If necessary, temperature thresholds can be modified to suit different working conditions.		

2-Line LCD	Board 2 (._) Temp Detected		
Terminal	[3F21] ALERT: +5V Low Voltage Detected (<i>current_voltage</i>)		
Event Type	<input checked="" type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input type="checkbox"/> Notification
What Happens?	The detected main circuit board temperature is higher or lower than the preset thresholds.		
What to Do?	Check the enclosure ventilation condition. If necessary, temperature thresholds can be modified to suit different working conditions.		

2-Line LCD	Fan_ Not Installed		
Terminal	[3F22] Peripheral Device ALERT: Controller FAN_ Not Present or Failure Detected		
Event Type	<input checked="" type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input type="checkbox"/> Notification
What Happens?	This event refers to the cooling fan in front panel. Check cable connection and see if the fan(s) has failed.		
What to Do?	Check cable connection and see if the fan(s) is rotating. Some OEM solutions may have removed front panel fans and the “fan detect” signals should be disabled by setting jumpers. Please refer to your Hardware Manual for more details.		

2-Line LCD	Fan (._) Speed Detected		
Terminal	[3F22] Peripheral Device ALERT: Controller FAN_ <high/low threshold> Speed Detected (._RPM)		
Event Type	<input checked="" type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input type="checkbox"/> Notification
What Happens?	This event refers to the cooling fan in front panel. Higher or Lower rotation speed detected.		
What to Do?	Contact your system vendor for replacing the cooling fan.		

2-Line LCD	High/Low +3.3V Voltage Detected (._._)
Terminal	[3F21] Peripheral Device ALERT: +3.3V <upper/lower threshold> Voltage Detected (_)
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The detected +3.3V voltage source is now higher or lower than the preset voltage threshold.
What to Do?	Check power supply condition, voltage threshold settings and contact the your system supplier.
2-Line LCD	High/Low +5V Voltage Detected (._._)
Terminal	[3F21] Peripheral Device ALERT: +5V <upper/lower threshold> Voltage Detected (_)
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The detected +5V voltage source is now higher or lower than the preset voltage threshold.
What to Do?	Check power supply condition, voltage threshold settings and contact your system supplier.
2-Line LCD	High/Low +12V Voltage Detected (._._)
Terminal	[3F21] Peripheral Device ALERT: +12V <upper/lower> Voltage Detected (_)
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The detected +12V voltage source is higher or lower than the preset voltage threshold.
What to Do?	Check power supply condition, voltage threshold settings and contact your system supplier.

I²C Device:

2-Line LCD	Temp Sensor_ Failure Detected
Terminal	[3F23] Peripheral Device ALERT: Temperature Sensor_ Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The designated temperature sensor has failed. This may be caused by mistakes with device target setting or device failure.
What to Do?	Check I ² C cable connection and contact your system supplier.

2-Line LCD	Temp Sensor_ Not Present
Terminal	[3F23] Peripheral Device ALERT: Temperature Sensor_ Not Present
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The controller failed to detect the presence of the designated temperature sensor.
What to Do?	Check I ² C cable connection, I ² C device setting, and contact your system supplier.

2-Line LCD	High/Low () Temperature_ Detected
Terminal	[3F23] Peripheral Device ALERT: <high/low threshold> Temperature_ Detected ((F/C)
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Critical high or low temperature detected.
What to Do?	Check enclosure ventilation status, and then contact your system provider for help. .

2-Line LCD	Fan_ Failure Detected
Terminal	[3F22] Peripheral Device ALERT: FAN_ Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Cooling fan failure detected by I ² C enclosure management.
What to Do?	Check cooling fan(s) status, and contact your system supplier.

2-Line LCD	Fan_ Not Present
Terminal	[3F22] Peripheral Device ALERT: FAN_ Not Present
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The controller failed to detect the presence of the designated temperature sensor.
What to Do?	Check I ² C cable connection, I ² C device setting, and contact your system supplier.

2-Line LCD	Fan () Speed Detected ()RPM)
-------------------	--------------------------------

Terminal	[3F22] Peripheral Device ALERT: <high/low threshold> Fan_ Speed Detected (_RPM)
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Enclosure fans higher or lower rotation speed detected.
What to Do?	Contact your system vendor for replacing the cooling fan.
2-Line LCD	Power Supply_ Failure Detected
Terminal	[3f21] Peripheral Device ALERT: Power Supply_ Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Power supply failure detected.
What to Do?	Contact your system provider for help.
2-Line LCD	Power Supply_ Not Present
Terminal	[3f21] Peripheral Device ALERT: Power Supply_ Not Present
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Could not detect power supply.
What to Do?	Check I ² C cable connection, I ² C device setting, and contact your system supplier.
2-Line LCD	High/Low Power Supply_ Voltage Detected
Terminal	[3f21] Peripheral Device ALERT: <high/low threshold> Power Supply_ Voltage Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Voltage exceeding preset thresholds
What to Do?	Contact your system supplier.
2-Line LCD	UPS_ AC power Failure Detected
Terminal	[3f24] Peripheral Device ALERT: UPS_ AC Power Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	UPS power failure.
What to Do?	If UPS protection is lost, inconsistency may occur to cached data upon power interruption. Contact your system provider for help.
2-Line LCD	UPS_ Battery Failure Detected
Terminal	[3f24] Peripheral Device ALERT: UPS_ Battery Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	UPS battery failure.
What to Do?	If UPS protection is lost, inconsistency may occur to cached data upon power interruption. Contact your system provider for help.

SES Device:

2-Line LCD	(_) Power Supply_: Device Not Supported
Terminal	[3f21] SES (C_I_) Power Supply_: <Vendor descriptor strings/Device Not Supported>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Unrecognizable device type.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	(_) Power Supply_: Device Not Installed
Terminal	[3f21] SES (C_I_) Power Supply_: <Vendor descriptor strings/Device Not Installed>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The installed power supply is missing.
What to Do?	Check loop connection and contact your system provider for help.

2-Line LCD	(_) Power Supply_: Device Unknown Status
Terminal	[3f21] SES (C_I_) Power Supply_: <Vendor descriptor strings/Device Unknown Status>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Device reports unknown status strings.
What to Do?	Check loop connection and contact your system provider for help.

2-Line LCD	(_) Power Supply_: Device Not Available
Terminal	[3f21] SES (C_I_) Power Supply_: <Vendor descriptor strings/Device Not Available>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Device missing???
What to Do?	Check loop connection and contact your system provider for help.

2-Line LCD	(_) Cooling element_: Device Not Supported
Terminal	[3f22] SES (C_I_) Cooling element_: <Vendor descriptor strings/Device Not Supported>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Unrecognizable device type
What to Do?	Check loop connection and contact your system provider for help.

2-Line LCD	(_) Cooling element_: Device Not Installed
-------------------	--

Terminal	[3f22] SES (C_I) Cooling element_: <Vendor descriptor strings/Device Not Installed>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	The installed device is missing
What to Do?	Check loop connection and contact your system provider for help.
<hr/>	
2-Line LCD	(._) Cooling element_: Device Unknown Status
Terminal	[3f22]] SES (C_I) Cooling element_: <Vendor descriptor strings/Device Unknown Status>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Device reports unknown status strings.
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(._) Cooling element_: Device Not Available
Terminal	[3f22]] SES (C_I) Cooling element_: <Vendor descriptor strings/Device Not Available>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Device missing???
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(._) Temp Sensor_: Device Not Supported
Terminal	[3f23] SES (C_I) Temperature Sensor_: <Vendor descriptor strings/Device Not Supported>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(._) Temp Sensor_: Device Not Installed
Terminal	[3f23] SES (C_I) Temperature Sensor_: <Vendor descriptor strings/Device Not Installed>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(._) Temp Sensor_: Device Unknown Status

Terminal	[3f23] SES (C_I_) Temperature Sensor_: <Vendor descriptor strings/Device Unknown Status>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(_.) Temp Sensor_: Device Not Available
Terminal	[3f23] SES (C_I_) Temperature Sensor_: <Vendor descriptor strings/Device Not Available>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(_.) UPS_: Device Not Supported
Terminal	[3f24] SES (C_I_) UPS_: <Vendor descriptor strings/Device Not Supported>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Voltage monitor detects the abnormal voltage has back to the normal range.
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(_.) UPS_: Device Not Installed
Terminal	[3f24] SES (C_I_) UPS_: <Vendor descriptor strings/Device Not Installed>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(_.) UPS_: Device Unknown Status
Terminal	[3f24] SES (C_I_) UPS_: <Vendor descriptor strings/Device Unknown Status>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(_.) UPS_: Device Not Available

Terminal	[3f24] SES (C_I) UPS_: <Vendor descriptor strings/Device Not Available>!		
Event Type	<input checked="" type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input type="checkbox"/> Notification
What Happens?			
What to Do?	Press <ESC> to clear the message.		
2-Line LCD	(._.) Voltage Sensor_: Device Not Supported		
Terminal	[3f21] SES (C_I) Voltage Sensor_: <Vendor descriptor strings/Device Not Supported>!		
Event Type	<input checked="" type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input type="checkbox"/> Notification
What Happens?			
What to Do?	Press <ESC> to clear the message.		
2-Line LCD	(._.) Voltage Sensor_: Device Not Installed		
Terminal	[3f21] SES (C_I) Voltage Sensor_: <Vendor descriptor strings/Device Not Installed>!		
Event Type	<input checked="" type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input type="checkbox"/> Notification
What Happens?			
What to Do?	Press <ESC> to clear the message.		
2-Line LCD	(._.) Voltage Sensor_: Device Unknown Status		
Terminal	[3f21] SES (C_I) Voltage Sensor_: <Vendor descriptor strings/Device Unknown Status>!		
Event Type	<input checked="" type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input type="checkbox"/> Notification
What Happens?			
What to Do?	Press <ESC> to clear the message.		
2-Line LCD	(._.) Voltage Sensor_: Device Not Available		
Terminal	[3f21] SES (C_I) Voltage Sensor_: <Vendor descriptor strings/Device Not Available>!		
Event Type	<input checked="" type="checkbox"/> Alert	<input type="checkbox"/> Warning	<input type="checkbox"/> Notification
What Happens?			
What to Do?	Press <ESC> to clear the message.		
2-Line LCD	(._.) Current Sensor_: Device Not Supported		

Terminal	[3f21] SES (C_I_) Current Sensor_: <Vendor descriptor strings/Device Not Supported>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(_.) Current Sensor_: Device Not Installed
Terminal	[3f21] SES (C_I_) Current Sensor_: <Vendor descriptor strings/Device Not Installed>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(_.) Current Sensor_: Device Unknown Status
Terminal	[3f21] SES (C_I_) Current Sensor_: <Vendor descriptor strings/Device Unknown Status>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	(_.) Current Sensor_: Device Not Available
Terminal	[3f21] SES (C_I_) Current Sensor_: <Vendor descriptor strings/Device Not Available>!
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.

General Peripheral Device:

2-Line LCD	Power Supply Failure Detected
Terminal	[3f21] Peripheral Device ALERT: Power Supply Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Power supply failure detected
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Cooling Fan Not Installed
Terminal	[3f22] Cooling Fan Not Installed
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Cooling Fan Failure Detected
Terminal	[3f22] Cooling Fan Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Elevated Temperature Alert
Terminal	[3f24] Elevated Temperature Alert
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.

2-Line LCD	UPS Power Failure Detected
Terminal	[3f24] UPS Power Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	
What to Do?	Press <ESC> to clear the message.

Notification:

SAF-TE Device:

2-Line LCD	SAF-TE_: Fan() Back to On-Line
Terminal	[3fa2] SAF-TE () NOTICE: Fan Back On-Line
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Failed fan back to on-line state.
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	SAF-TE_: Temp() Back Non-Critical
Terminal	[3fa3] SAF-TE Device () NOTICE: Temperature Back to Non-Critical Levels ()
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Temperature back to non-critical level.
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	SAF-TE_: Power Supply Back On-Line
Terminal	[3fa1] SAF-TE Device () NOTICE: Power Supply Back On-Line ()
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Power supply restored.
What to Do?	Press <ESC> to clear the message.
<hr/>	
2-Line LCD	SAF-TE_: UPS Back On-Line
Terminal	[3fa4] SAF-TE Device () NOTICE: UPS Power Back On-Line
Event Type	<input type="checkbox"/> Critical <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	UPS power restored..
What to Do?	Press <ESC> to clear the message.

Controller Self Diagnostics:

2-Line LCD	CPU Temp Back Non-Critical
Terminal	[3fa3] CPU <high/low threshold> Temperature Back to Non-Critical Levels
Event Type	<input type="checkbox"/> Critical <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	CPU operating temperature back to non-critical level.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Board_ Temp Back Non-Critical
Terminal	[3fa3] Board_ <high/low> Temperature Back To Non-Critical Levels
Event Type	<input type="checkbox"/> Critical <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Board_ temperature back to non-critical level.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	+3.3V Back to Non-Critical
Terminal	[3fa1] +3.3V <high/low> Voltage Back within Acceptable Limits
Event Type	<input type="checkbox"/> Critical <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	+3.3V voltage source back within acceptable limits.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	+5V Back to Non-Critical
Terminal	[3fa1] +5V <high/low> Voltage Back within Acceptable Limits
Event Type	<input type="checkbox"/> Critical <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	+5V voltage source back within acceptable limits.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	+12V Back to Non-Critical
Terminal	[3fa1] +12V <high/low> Voltage Back within Acceptable Limits
Event Type	<input type="checkbox"/> Critical <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	+12V voltage source back within acceptable limits.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Contlr FAN_ Back On-Line (_)
-------------------	--------------------------------

Terminal	[3fa2] NOTICE: Controller FAN_ Back On-Line (_RPM)
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Controller fan operating status back to normal
What to Do?	Press <ESC> to clear the message.

I²C Device:

2-Line LCD	Temp_ Back to Non-Critical
Terminal	[3fa3] NOTICE: Temperature_ Back to Non-Critical Levels
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Detected temperature back to non-critical levels.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Temperature_ is present
Terminal	[3fa3] NOTICE: Temperature_ is present
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Temperature sensor_ detected.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	FAN_ Back On-Line
Terminal	[3fa2] NOTICE: FAN_ Back On-Liine
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	FAN_ back online.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	FAN_ is present
Terminal	[3fa2] NOTICE: FAN_ is present
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	FAN_ detected.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Power Supply_ Back On-Line
Terminal	[3fa1] NOTICE: Power Supply_ Back On-Line
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Power supply back online.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	Power Supply_ is present
Terminal	[3fa1] NOTICE: Power Supply_ is present
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	Power supply_ detected.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	UPS_ AC Power Back On-Line
Terminal	[3fa4] Peripheral Device NOTICE: UPS_ AC Power Back On-Line
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	UPS_ AC Power Back On-Line.
What to Do?	Press <ESC> to clear the message.

2-Line LCD	UPS_ Battery Back On-Line
Terminal	[3fa4] Peripheral Device NOTICE: UPS_ Battery Back On-Line
Event Type	<input type="checkbox"/> Alert <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification
What Happens?	UPS_ battery back online.
What to Do?	Press <ESC> to clear the message.

SES Device:

Alert:

2-Line LCD	Power Supply_ Failure Detected
Terminal	[3f21] SES (C_I_) Power Supply_: Power Supply Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Power supply failure detected.
What to Do?	Check power module status and contact your supplier for a replacement unit.

2-Line LCD	Cooling Fan_ Not Installed
Terminal	[3f22] SES (C_I_) Cooling element_: Cooling Fan Not Installed
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Cooling fan missing or not detected.
What to Do?	Check proper fan installation or contact your supplier to replace a failed unit.

2-Line LCD	Cooling Fan_ Failure Detected
Terminal	[3f22] SES (C_I_) Cooling element_: Cooling Fan Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Contact your system provider for an immediate replacement of fan modules.
What to Do?	Contact your system provider for an immediate replacement of fan modules.

2-Line LCD	C_I_: Elevated Temperature Alert
Terminal	[3f23] SES (C_I_) Temperature Sensor_: Elevated Temperature Alert
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Detected temperature exceeding safety range.
What to Do?	Check cooling fan status. Contact your system provider for an immediate replacement of fan modules.

2-Line LCD	UPS Power Failure Detected
Terminal	[3f24] SES (C_I_) UPS_: UPS Power Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	UPS power failure detected.
What to Do?	Check UPS status. If power should fail and UPS is not able to sustain power, data loss might occur.

General Peripheral Device:

2-Line LCD	Power Supply Failure Detected
Terminal	[3f21] Peripheral Device ALERT: Power Supply Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Power Supply Failure Detected.
What to Do?	Check power module status and contact your supplier for a replacement unit.
<hr/>	
2-Line LCD	Cooling Fan_ Not Installed
Terminal	[3f22] Cooling Fan Not Installed
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Cooling fan missing or not detected.
What to Do?	Check proper fan installation or contact your supplier to replace a failed unit.
<hr/>	
2-Line LCD	Cooling Fan_ Failure Detected
Terminal	[3f22] Cooling Fan_ Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	Cooling fan failure detected.
What to Do?	Contact your system provider for an immediate replacement of fan modules.
<hr/>	
2-Line LCD	Elevated Temperature Alert
Terminal	[3f24] Elevated Temperature Alert
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	General overheating warning.
What to Do?	Check cooling fan status and proper installation of dummy plate. Consult your enclosure vendor's document for probable cause.
<hr/>	
2-Line LCD	UPS Power Failure Detected
Terminal	[3f24] UPS Power Failure Detected
Event Type	<input checked="" type="checkbox"/> Alert <input type="checkbox"/> Warning <input type="checkbox"/> Notification
What Happens?	UPS device failure detected.
What to Do?	Check UPS status. If power should fail and UPS is not able to sustain power, data loss might occur.

E

Remote Administration Using Dial-Out Modem

Infortrend's RAID controllers or subsystems can be remotely managed through the following:

- RAIDWatch Manager running on hybrid TCP/IP agents
- Remote Terminal Emulation using dial-out modem
- Automatic dial-out to pager for event notification

Details on the use of RAIDWatch manager can be found in the RAIDWatch User's Manual. This chapter focuses on preparing your RAID controller or subsystem to use the dial-out functionality.

E.1 Remote Terminal Emulation Using Modem




Figure E - 1 Remote Terminal Emulation

An Infortrend controller or RAID subsystem can be configured and monitored remotely through a modem. If there are several RAID systems in several different places, the administrator can remotely administer all arrays on his desk by using a terminal emulation program.

There is no need to install a RAS (Remote Access Server) to the controller. Simply connect a modem to controller. The controller can manage by itself the dial-in remote administration and dial-out event notifications through proper settings.

Both COM 1 and COM 2 can be used as the local RS-232C terminal interface or to provide a remote administration service by connecting a Modem. If a RAID controller is not connected in a redundant controller configuration, COM1 can be used as the local RS-232C terminal interface. COM2 can be used for a remote administration by connecting to a modem.

Terminal emulation screens over simultaneous COM1 and COM2 connections are exactly the same and synchronized. It is, however, always best to return to the terminal's initial screen whenever one of the terminal connection is to be left unattended. You may also set "password checking timeout" to "Always Check." If set to "Always Check," access to the controller is denied unless a correct password is provided when entering the Main Menu from the initial screen or when making changes to a configurable option.

NOTE:


- *The terminal emulation screen for both COM 1 and COM 2 connections are synchronized. Users connected to COM 1 and COM 2 can see each other's operating screen.*

Hardware Connection


Use a standard external modem that receives standard AT command set. Connect the modem to COM 1 or COM 2 of your RAID controller unit. Complete the other connections of the modem (power cables and phone wires) and switch on the power of the Modem.

Setting Controller using the RS-232C Terminal Interface

The following example shows connecting COM 1 to the local terminal emulation, and COM 2 to the modem:




Configuring the Modem Port




Choose "Modem Operation" from the "Communication Parameters" menu,


then select “Modem Setup” in the next menu.



In the Modem Setup menu, choose Configure Modem Port.




The current setting of the modem port will be displayed on the screen. If there is no modem port configured yet, it will display “Modem Port Not Configured.” Press [Enter] on the selection, and choose “Configure Modem on COM 2” by pressing [Enter].



Choose “Yes” to configure the modem on the COM2 port.

To delete the configured modem port, press [Enter] on the configured modem port item and choose “Deconfigure Modem Port.”

Modem Initialization Command



In the Modem Setup menu, choose “Modem Initialization.” A dialog box will appear showing the default initialization command and the current custom initialization command. Enter the AT command in the “New Custom Init Cmd” field, if required.

Modem Operating Modes

To send the initialization command to the modem, there are three selectable options:

- Sending Default Init command only - “None <Default Used>”
- Sending Custom Init command only - “Replace Default”
- Sending Default Init command and Custom Init command - “Append to Default”




Choose “Modem Operating Modes” in the Mode Setup menu. The current setting will be displayed on the screen. Press [Enter] to see a list of choices. Choose the desired setting.

IMPORTANT:


- *It is a must to enable “Auto answer mode” of the connected modem in order to answer the dial-in calls and establish the connections automatically.*
-

Initializing Modem



Choose “Modem Operations” in the Communication Parameters menu, then select “Modem Functions.” A dialog box will appear. Choose **Yes** to scan and send initialization command to the Modem.

Baud rate, Data Routing and Enable Terminal Emulation



In the Communication Parameter menu, select “RS-232 Port Configuration.” Choose “COM 2 Configuration” to configure the COM 2 port of the controller.

Set the baud rate of the modem and the client terminal emulation program. In this example, COM 1 and COM 2 are used for terminal emulation at the same time. The baud rate for both COM 1 and COM 2 must be the same.

Set the “Data Routing...” to “Data Routing Direct to Port,” and enable the Terminal Emulation. The Modem is now ready to answer the dial-in connections.


IMPORTANT:

- *If COM 1 and COM 2 are both used as terminal emulation, the baud rate must be the same.*
 - *The baud rate setting in the client (remote site) terminal emulation program must be the same as the baud rate setting of the controller’s COM port.*
-

Connection from the Remote Terminal

Use a terminal emulation program that supports ANSI or VT-100 terminal emulation modes. From the remote terminal program, dial the phone number of the modem connected to the controller. The modem should answer the call and start “handshaking” with the modem on the remote site. After the connection is established, the screen on the remote terminal program will look the same as the screen on the local site.

Viewing Connection Status



Choose "Communication Status" from the Communication Parameters menu and press **[Enter]**. The configured COM port and its current status will be shown on the screen. The message "Modem Present and Connected" means the modem is connected now.

Setting the Controller Using the Front Panel

Here is an example of connecting COM 1 to the modem:

Configure Modem Port

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Config Parm," then press **ENT**.

View and Edit
Config Parm

Select "Communication Parameters ..," then press **ENT**.

Communication
Parameters

Select "Modem Operation ..," then press **ENT**.

Modem Operation

Select "Modem Setup ..," then press **ENT**.

Modem Setup

Select "Configure Modem Port ..," then press **ENT**.

Configure Modem
Port

The LCD displays "Modem Port Not Configured," then press **ENT**.

Modem Port
Not Configured..

Select "Configure Modem on COM1?," then press **ENT** for two seconds to set.

Modem Operation

To delete the configured Modem port, choose the configured Modem port, then press **ENT**.


Select "Deconfigure Modem Port," then press

Deconfigure
Modem Port

ENT for two seconds to delete.


Modem Initialization Command

In the “Modem Setup” menu, press **ENT**.




Modem Setup

Select "Modem Initialization ...," then press **ENT**.



Modem
Initialization..

Enter the AT command, if required, then press **ENT** for two seconds when finished.




Custom Init Cmd:
AT

Modem Operating Modes

To send the initialization command to the Modem, there are three selectable options:


- Sending Default Init command only - “None”
- Sending Custom Init command only - “Replace”
- Sending Default Init command plus Custom Init command - “Append”

In the “Modem Setup” menu, press **ENT**.




Modem Setup

Select "Modem Operation Modes ...," then press **ENT**.




Modem Operation
Modes

The current setting of this item will be displayed on LCD. Press **ENT**.



Custom ModemInit
None-

Choose None, Replace or Append, then press **ENT** for two seconds.




Custom Modem
Init - None

IMPORTANT:


- *It is a must to enable “Auto answer mode” of the connected Modem in order to answer the dial-in calls and establish the connections automatically.*
-

Initializing Modem


In the "Modem Operation" menu, press **ENT**.

A screenshot of a menu item labeled "Modem Operation". The text is centered within a rectangular box that has a thick black border on its right and bottom sides.

Select "Modem Functions ..," then press **ENT**.

A screenshot of a menu item labeled "Modem Functions ..". The text is centered within a rectangular box that has a thick black border on its right and bottom sides.

Select "Re-Init Modem?," then press **ENT** for two seconds to scan and send initialization command to the Modem.

A screenshot of a menu item labeled "Re-Init Modem ?". The text is centered within a rectangular box that has a thick black border on its right and bottom sides.

Baud Rate, Data Routing and Enable Terminal Emulation


Set the desired baud rate, Data Routing direct to port and enable the Terminal Emulation. Please refer to Section one on how to set the Baud rate, Data Routing and Terminal Emulation. The modem is now ready to answer the dial-in connection.

Establish the Connection from the Remote Terminal


Use a terminal emulation program that supports ANSI or VT-100 terminal emulation modes. In the remote terminal program, dial the phone number of the modem connected to the controller. The modem should answer the call and start "handshaking" with the modem on the remote site. After the connection is established, the screen on the remote terminal program will look the same as the screen on the local site.

Verifying Modem Connection


In the "Communication Parameters .." menu, press **ENT**.

A screenshot of a menu item labeled "Communication Parameters ..". The text is centered within a rectangular box that has a thick black border on its right and bottom sides.


Select "Communication Status ..," then press **ENT**.

A screenshot of a menu item labeled "Communication Status ..". The text is centered within a rectangular box that has a thick black border on its right and bottom sides.

Select "Modem Status..," then press **ENT**.

A screenshot of a menu item labeled "Modem Status..". The text is centered within a rectangular box that has a thick black border on its right and bottom sides.

The current connection status will be shown on the LCD.

A screenshot of a status message "Modem on COM1 Connected". The text is centered within a rectangular box that has a thick black border on its right and bottom sides.

E.2 Dial-out for Event Notifications




Figure E - 2 Dial-out for Event Notifications

The controller can be set to dial-out a pager for event notification, or dial-out to a remote computer with terminal emulation program as well as dial-in via a remote computer.

Dial-out to a Terminal or a Pager?


If the Dial-out function is used as an event notification to a pager, the terminal emulation of the COM port has to be disabled. If the Dial-out function is used with a remote terminal, enable the terminal emulation.

Configure the controller in order to use the remote terminal with the modem. Please refer to the previous section, Remote Terminal Emulation Using Modem, for details.

IMPORTANT:


- *If the controller is dialing-out to a pager, the Terminal Emulation of the corresponding COM port must be disabled.*
 - *If the controller is dialing-out to a remote administration terminal, the Terminal Emulation of the corresponding COM port must be enabled.*
-

Setting Dial-out Function Through the Terminal Emulation



Choose "View and Edit Configuration Parameters" in the Main Menu, then select "Communication Parameters." Choose "Modem Operation," then select "Modem Setup" and "Dial-out Function" in the menu. A Dial-out Function menu will appear on the screen.


Dial-out Command



Choose "Dial-out Command" in the Dial-out Function menu. A dialog box will appear showing the current dial-out commands. Enter the new dial-out command in the New Dial-out command column, then press **[Enter]**.

The Dial-out command is the only command that will be sent to the modem when dialing-out. If it's dialing to a pager, the pager number and message (if applicable) have to be composed in this column. If it's dialing to a remote terminal, the phone number of the remote modem has to be entered in this column. Refer to the manual of your modem for the AT command set.

Auto Dial-out on Initialization



Choose "Auto Dial-out on Initialization" from the Dial-out Function menu. A dialog box will appear. Choose **Yes** to confirm the change.

If the "Auto Dial-out on Initialization" has been enabled after the modem

initializes, it will send the Dial-out Command to the modem automatically.

Dial-out Timeout

Dial-out Command - Not Set
Auto Dial-out on Initialization Disabled
Dial-out Timeout - None
D
D Dial-out Timeout: 0 seconds
D

Dial-out Timeout(seconds):

Choose “Dial-out Timeout” in the Dial-out Function menu. The current setting in this column will appear. Press **[Enter]**. A dialog box will appear to input the Dial-out Timeout. Enter the desired dial-out timeout time (in seconds) in this column.

When the modem is dialing out, the controller will start to count the dial-out timeout period. If the connection cannot be established within the dial-out timeout period, the controller will send a ‘hang-up’ command to the modem to hang up the phone.

Dial-out Retry Count

Dial-out Command - Not Set
Auto Dial-out on Initialization Disabled
Dial-out Timeout - None
Dial-out Retry Count - 3
D
D Dial-out Retry Count: 3
D

Dial-out Retry Count: _

Choose “Dial-out Retry Count” in the Dial-out Function menu. The current setting in this column will appear. Press **[Enter]**. A dialog box will appear for entering the Dial-out Retry Count. Enter the desired Dial-out Retry count in this column.

When the modem cannot establish the connection when dialing-out, the controller will retry another dial-out, that is, if the Dial-out Retry Count is not set as “0.” The default retry count is “3” - which means the controller will retry the dial-out process three times after the first dial-out process failed.

Dial-out Retry Interval

The Dial-out Retry Interval is the interval period between the dial-out retries.

```

Dial-out Command - Not Set
Auto Dial-out on Initialization Disabled
Dial-out Timeout - None
Dial-out Retry Count - 3
Dial-out Retry Interval - 5 minutes

```

```

Dial-out Retry Interval: 5 minutes

```

```

Dial-out Retry Interval<minutes>:

```

Choose "Dial-out Retry Interval" in the Dial-out Function menu. The current setting in this column will appear. Press **[Enter]**. A dialog box will appear for entering the Dial-out Retry Interval. Enter the desired dial-out retry interval in this column (in minutes).

Dial-out on Event Condition

```

Dial-out Command - Not Set
Auto Dial-out on Initialization Disabled
Dial-out Timeout - None
Dial-out Retry Count - 3
Dial-out Retry Interval - 5 minutes
Dial-out on Event Condition - Disabled

```

```

Disabled
Critical Events Only
Critical Events and Warnings
All Events, Warnings and Notifications

```

Choose "Dial-out on Event Condition" in the Dial-out Function menu. A list of selections will appear. Move the cursor bar on the desired selection, then press **[Enter]** to choose.

Choosing one of the options will enable the "Dial-out on Event Condition" (except "Disable"). The controller will send the "Dial-out command" to the modem when an event has occurred.

Setting Dial-out Function Through the Front Panel

Press **ENT** for two seconds to enter the Main Menu. Press **▼** or **▲** to select "View and Edit Config Parm," then press **ENT**.

```

View and Edit
Config Parm

```

Select "Communication Parameters ..," then press **ENT**.

```

Communication
Parameters

```

Select "Modem Operation ..," then press **ENT**.

```

Modem Operation

```

Select "Modem Setup ..," then press **ENT**.

```

Modem Setup

```

Select "Dial-out Functions ..," then press **ENT**. Press ▼ or ▲ to see the Dial-out Functions menu.

```
Dial-out
Functions
```

Dial-out Command

Select "Dial-out Command .." in the Dial-out Functions menu, then press **ENT**.

```
Dial-out Command
```

Enter the Dial-out command in this column. Press ▼ or ▲ to change the current character, then press **ENT** to move the cursor to the next space. Press **ENT** for two seconds when finished.

```
Dial-out Cmd:
ATD
```

The Dial-out command is the only command that will be sent to the modem when dialing-out. If it's dialing to a pager, the pager number and message (if applicable) have to be composed in this column. If it's dialing to a remote terminal, the phone number of the remote modem has to be entered in this column. Refer to your modem's manual for the AT command set.

Auto Dial-out on Initialization

Select "Auto Dial-out on Init .." in the Dial-out Functions menu, then press **ENT**.

```
Auto Dial-out
on Init
```

Press **ENT** for two seconds to set.

```
Enable Auto
DialOut on
```

Dial-out Timeout

Select "Dial-out Timeout .." in the Dial-out Functions menu, then press **ENT**.

```
Dial-out Timeout
None
```

Enter the Dial-out Timeout period in this column. Press ▼ or ▲ to change the current character, press **ENT** to move the cursor to the next space. Press **ENT** for two seconds when finished.

```
Dial-out Timeout
 seconds
```

When the modem is dialing out, the controller will start to count the dial-out timeout period. If the connection cannot be established within the dial-out timeout period, the controller will send a 'hang-up' command to the modem to hang up the phone.

Dial-out Retry Count

Select "Dial-out Retry Count .." in the Dial-out Functions menu, then press **ENT**.

```
Dial-out Retry
Count - 3
```

Enter the Dial-out retry count in this column. Press **▼** or **▲** to change the current character, then press **ENT** to move the cursor to the next space. Press **ENT** for two seconds when finished.

```
Dial-out Retry
Count - █
```

When the modem cannot establish the connection when dialing-out, the controller will retry another dial-out, that is, if the Dial-out Retry Count is not set as "0." The default retry count is "3" - which means the controller will retry the dial-out process three times after the first dial-out process failed.

Dial-out Retry Interval

The Dial-out Retry Interval is the interval period between the dial-out retries.

Select "Retry Interval .." in the Dial-out Functions menu, then press **ENT**.

```
Retry Interval
5 minutes
```

Enter the Dial-out Retry Interval in this column. Press **▼** or **▲** to change the current character, then press **ENT** to move the cursor to the next space. Press **ENT** for two seconds when finished.

```
Retry Interval-
█ minutes
```

Dial-out on Event Condition

Select "Event Condition .." in the Dial-out Functions menu, then press **ENT**.

```
Event Condition
Disabled
```

Press **▼** or **▲** to change the setting, then press **ENT** for two seconds.

```
Event Condition?
Critical
```

There are four options in this column:

Disabled	Disable
Critical Events	Critical Events Only
Critical&Warning	Critical Events and Warnings
All Events	All Events, Warnings and Notifications

Choosing one of the options will enable the "Dial-out on Event Condition" (except "Disable"). The controller will send the "Dial-out command" to the

modem when an event occurs.

Cache Status	6-1, 6-2	modem	
Cache Synchronization	10-18	Connection Type	8-11
Cache Synchronization on Write-Through	10-37	Controller behaviors	10-17, 10-33
Caching Parameters	5-1, 5-5, 5-6, 9-29	Controller	8-14
Caching Parameters: LCD	5-1	Communications over Fibre Loops	
Caching Parameters: terminal	7-1	Controller Date and Time	5-49, 7-48
Change Password: LCD	5-43	Controller Failover	10-10
Change Password: terminal	7-40	Controller Failover and Failback	10-9
Changing password	5-43~44, 7-40	Controller failure	10-13, 10-33
Changing the Password: terminal	7-40	Controller Failure: LCD	10-26
Channel Bus: Redundant config	10-9	Controller Failure: terminal	10-33
Channel failure protection	1-14	Controller Maintenance	5-45, C-5
Channel ID, setting	5-34	Controller Name	5-47, 6-1
Channel Mode	B-5	Controller Name: LCD	5-47
Channel Mode – Fibre	8-7	Controller Name: terminal	7-43
Channel mode – redefining	7-29	Controller naming	7-43
Channel-ID combination	8-18	Controller Parameter Settings	2-11
Check time		Controller Parameter Settings - Fault Management	
Choosing Member Drives: LCD	5-9	Controller Parameter Settings - Fibre Channel Parameters	2-11
Choosing Member Drives: terminal	7-8	Controller Parameter Settings - Optimization Mode	2-11
Choosing RAID Level: terminal	7-8	Controller Parameter Settings - SCSI Parameters	2-11
Clone drive	9-4, 9-7	Controller Parameter Settings - Spin-Up Parameters	2-11
Clone failing drive	9-3, B-8	Controller Parameters	2-12, 5-47, 7-43, 10-22
Clone plus Replace	9-8	Controller Parameters: LCD	5-47
Cloning progress	9-11	Controller Parameters: terminal	7-43
Co-existing spares	B-1	Controller Peripheral Device Configuration	9-34
COM port	C-1	Controller reset	5-44, 7-41
Communication Parameters	3-9	Controller Self-Monitoring	9-34
Communications Channel	10-36	Controller Settings – Redundant config.	10-16
Communications Channel: Fibre	8-8	Controller temperature sensors	B-9
Communications Channels	10-15	Controller Unique ID	8-13, 10-22~23
Communications Loops	8-14, 10-4	Controller Unique Identifier	5-48, 8-12, 10-16, 10-29
Communications path	10-30	Controller Unique Identifier: LCD	5-48
Communications traffic distributed over all drive loops	8-14	Controller Unique Identifier: terminal	7-46
Concurrent Rebuild	1-11	Controller Voltage and	4-6
Configurable parameters: redundant controller	10-1		
Configuration flowchart – redundant controller	10-21		
Configuration on Disks	B-2		
Connection Status –	E-7		

Temperature: LCD		deleting partition of logical drive	5-22, 7-20
Controller Voltage and Temperature: terminal	6-10	deleting SCSI channel ID	5-35
Controller voltage monitors	B-9	deleting SCSI ID	7-31
Controller/Logical Drive Shutdown	B-3	Deleting Spare Drive: LCD	5-33
Copy and Replace Drives expansion	12-7	Deleting Spare Drive: terminal	7-28
Copy and Replace Procedure	12-7	deleting spare drive, global or local	5-33, 7-28
Creating a Logical Drive: LCD	5-9	Destination Drive	12-8
Creating a Logical Drive: terminal	7-6	Detect Clone plus Replace	9-12
Creating a Logical Volume: LCD	5-13	Detect Only	9-11
Creating a Logical Volume: terminal	7-12	Detect Only - SMART	9-7
Creating LUN Masks	8-17	Detect Perpetual Clone	9-11
Creating Primary and Secondary IDs	10-30	Detection idle drive failure	9-27
Cursor Bar	6-1	Detection of Drive Hot Swap	9-25
CurSynClk	6-9	Detection of Drive Hot Swap followed by Auto Rebuild	9-25
CurWid	6-9	Device Check Time	9-25
Cylinder	9-18	Device Qualifier Support	9-16
Cylinder Head Sector Mapping	9-18, 9-20	Device Support for Removable Media	9-17
Cylinder Ranges	9-20	Device Type	9-16
		Dial-in remote administration	E-2
D		Dial-out automatically on initialization	E-14
Data bus setting	8-1	Dial-out command	E-11, E-14
Data cached	10-18	Dial-out conditions	E-13
Data Rate	7-38	Dial-out event notifications	E-2
Data Routing	E-6, E-9	Dial-out for event notification	E-10
Date & Time	5-49, 6-1, 7-48	Dial-out Function	E-11
Deassert Reset on Failed Ctlr	10-28	Dial-Out Modem	E-1
Dedicated Communications loops	8-14	Dial-out pager	E-10
Default setting restoring	5-42	Dial-out retry count	E-12, E-15
DefSynClk	6-8	Dial-out retry interval	E-12
DefWid	6-9	Dial-out setting	E-13
Deleting a Logical Drive: LCD	5-20	Dial-out setting via terminal emulation	E-11
Deleting a Partition of a Logical Drive: LCD	5-22	dial-out timeout	E-12, E-14
Deleting a Partition of a Logical Drive: terminal	7-20	dial-out to pager	E-1
Deleting a SCSI Channel's ID: LCD	5-35	dial-out to pager or terminal	E-10
Deleting a SCSI ID: terminal	7-31	Disabling Password: LCD	5-44
Deleting logical drive	5-20, 7-20	Disabling the Password: terminal	7-41
Deleting Logical Drive: terminal	7-20	Disconnecting Support : LCD	5-41
		Disconnecting Support: terminal	7-37
		disk access delay time	9-23

Disk Array Parameters:	9-31
Advanced config.	
Disk Reserved Space	3-7, 5-10, 7-9
Disk spanning	1-3
Download Boot Record and Firmware	C-5
Download FW	C-4
Download FW/BR	C-3
Drive + RCC	10-4
Drive Entry	7-27
Drive failure	1-6
Drive I/O timeout	B-3
Drive Identification	B-2
Drive IDs Fibre Channel	8-6
Drive Information terminal	7-49
Drive members	2-8
Drive Motor Spin-up	B-3
Drive plus RCCOM	8-14
Drive Predictable Failure Mode	9-8
Drive side redundant loop	B-5
Drive Space Allocation	7-20
Drive Swap Check Time	9-25, 9-26
Drives SCSI, viewing and editing	7-26
Drive-side Parameters Advanced config.	9-21
Dual I/O paths	10-7
Dual Loop	8-11
Dynamic on-lining	B-9
Dynamic Switch Write-Policy	9-29

E

EMAIL	3-13
Enable Terminal Emulation	E-6
Enclosure implementation	9-30
Environmental setting management	B-7
Ethernet Requirements	3-1
Event Logs terminal	6-11
event logs viewing and editing	4-6, 4-7
event message	1-5
Event Trigger Option	9-30, 9-31
Exclude	8-21
Expand Logical Drive	12-7, 12-9
Expand Logical Volume	12-11
expansion interrupted	12-6
Expansion: Re-Striping	12-3

F

F_ports	8-11
Failback	10-11
Failed Drive Swap Detect	1-9
Failover	10-11
failover process	10-22
Fault Management	2-11
Fault Prevention	9-1
Fault-Tolerance	10-1, 10-8
Fibre	8-7, 8-11
Fibre Channel Connection Options	8-11
Fibre Channel Dual Loop	8-11
Fibre Channel Parameters	2-12
Fibre Chip	8-5
filter entries	8-22
Filter Entry	8-23
Filter Type	8-21
Filter Type Include or Exclude	8-21
filtering mask	8-16
Firmware Binaries	C-3, C-5
Firmware Binary	C-1, C-4
Firmware Synchronization	10-11
Firmware Sync-version	C-2
firmware upgrading	C-1
FL_ports	8-11
Flash memory	C-1
flashing all but selected drives	1-8
flashing all SCSI drives	1-8
flashing selected SCSI drives	1-8
Forcing Controller	10-35
Failover for Testing	
format low-level	5-51, 7-50

G

Gateway	3-10
Gauge Range	6-1
global spare drive	1-6
global spare drive deleting	7-28
Global Spare: LCD	5-19
Global Spare Rebuild	1-6
Global Spare: terminal	7-19
GMT Greenwich Mean Time	7-48
Grouping hard drives	10-1, 10-5

H

Hard drives	7-8
Head and Sector counts	9-18
Head Ranges	9-20
Head sector count	9-18
Hex number	7-46, 8-13
Host application	2-2, 2-11
Host Channel: terminal	7-34
Host Channel: LCD	5-34
Host ID	8-17
Host ID/WWN Mask	8-20
Host LUN Geometry	B-3
Host port ID	10-7
Host-ID/WWN Name List	7-25
Host-side and Drive-side SCSI Parameters Advanced Config.	9-13
Host-side Maximum Queued I/O count	B-3
Host-side SCSI Parameters: Advanced config.	9-13
http server	3-7

I

I/O timeout SCSI	9-23
ID Mapping Status	10-10
ID Range	8-20
Identify Drive	5-25
Identifying a Drive: LCD	5-31
Identifying Drives: terminal	7-27
Identifying drives	1-8, 5-31, 7-27
Idle drive failure detection	9-26~27
Inactive ID	10-9
In-band Fibre	8-6
in-band SCSI	9-16, C-1~2
Include	8-21
Infortrend's Implementation to SMART	9-7
Initial Screen	6-1
Initial Screen: LCD	4-1
Initialization	6-6
Initialization Command	E-4, E-8
Initialization Mode	5-13, 7-10
Initializing modem	E-9
Initiator ID	8-17
Internet Protocol	3-9
Interruption to RAID	12-2

expansion	
I/O sorting	B-3
IP address	3-5, C-3~4
IP Address assignment	3-9
Iteration Count	5-26, 7-23

J

Java Runtime	3-5
JBOD	1-3

L

LAN port	C-1
LBA	2-4, 7-23
LCD	5-7, 5-11
LCD Title Display Controller Name: terminal	7-43
LCD Title Display Controller Name: LCD	5-47
LD Initialization Writes	9-33
LD Rebuild Writes	9-33
Level (0+1) disk striping with mirroring	1-4
Level 0 disk striping	1-4
Level 1 disk mirroring	1-4
Level 3 disk striping with dedicated parity disk	1-5
level 5 striping with interspersed parity	1-5
Limitations on array config.	2-4
Limitations on optimization modes	5-1
Limitations: redundant config.	10-17
Local Spare	6-3
local spare drive deleting	7-28
Local Spare: LCD	5-17
Local Spare: terminal	7-17
Logical drive assigning a name	5-24, 7-21
Logical Drive Assignment	10-25, 10-31
Logical Drive Assignments: terminal	7-9
logical drive deleting	7-20
logical drive expansion in Windows 2000®	12-12
logical drive explained	1-1
Logical drive identification	B-1
logical drive parity check	5-25
logical drive preferences	5-10~11
Logical Drive Preferences: LCD	5-10
Logical Drive Preferences: terminal	7-8
logical drive status	4-2

Logical Drive Status: LCD	4-2	Mappings, viewing and deleting	5-29
Logical Drive Status: terminal	6-4	Maximum Concurrent Host LUN Connection	9-13, B-3
logical drive viewing drive members	5-20, 7-19	Maximum Drive Capacity: LCD	5-10
Logical Unit to Host LUN Mapping	8-18	Maximum Drive Capacity: terminal	7-8
logical volume	1-12~17	Maximum drive expand capacity	12-9
Logical Volume Assignment	5-14	Maximum number of drives	B-1
Logical Volume Status: LCD	4-3	Maximum number of logical drives	B-1
Logical Volume Status: terminal	6-5	Maximum number of logical volumes	B-1
Logical Volumes	2-6	Maximum number of LUNs	B-1
loop ID	8-12	Maximum number of LUNs per Host ID	B-1
LUN Applicability	9-16	Maximum number of partitions	B-1
LUN Application	9-16	Maximum Queued I/O Count	9-15
LUN entries	7-16	Maximum synchronous transfer clock	5-40, 7-36
LUN explained	2-7, 9-13	Maximum Synchronous Transfer Clock: LCD	5-40
LUN Filtering	8-16, 8-22, 8-24, B-5	Maximum Synchronous Transfer Clock: terminal	7-36
LUN Filtering Configuration Procedure	8-23	Maximum tag count	5-42, 7-37, 9-24
LUN map	8-16, 8-23	Maximum Tag Count (Tag Command Queuing)	9-24
LUN mapping	10-1	Maximum Tag Count: LCD	5-42
LUN mappings, viewing and deleting	7-25	Maximum Tag Count: terminal	7-37
LUN Mask	8-20	Maximum transfer width	5-41, 7-36
LUN Mask (ID Range) Configuration	8-20	Maximum transfer width: LCD	5-41
LUN-0's only	9-16	Maximum transfer width: terminal	7-36
LUNs per host ID	9-15	Media Scan	5-26, 7-23, B-2
LUNs per Host SCSI ID	9-15	Media Scan Priority	7-23
		Memory	10-17
		meta-filesystem	3-9
		Mirroring	1-4
		Mode-1 RAID Expansion	B-4
		Mode-2 RAID Expansion	B-4
		Modem Connection	E-9
		Modem Initialization	E-4
		Modem initializing	E-9
		Modem Operation	E-7
		Modem Port	E-3, E-7
		Modem Setup	E-4
		Monitoring Thresholds	9-34
		Motor Spin-up	9-22

M

MAC addresses	7-46
Main Menu: terminal	6-2
Manual rebuild	1-10
Manual Setting – redundant controller	10-22
Mapping a Logical Volume to Host LUNs: terminal	7-15
Mapping a Logical Volume/Logical Drive to Host LUN: LCD	5-16
Mapping LUNs	10-7
Mapping Partitions	2-9
mapping scheme	8-19
Mapping System Drives Redundant config.	10-7~8
Mapping to Host LUNs	10-32
Mapping to Host LUNs Redundant config: LCD	10-26

Motor spin-up SCSI	9-21
Multi-level RAID	1-17
Multiple drive failures	1-11
Multiple IDs	7-15
Multi-Level RAID	1-12
Multiple LUNs	10-8
Multiple ranges	8-21
Multiple target IDs	7-31, 8-5
Multi-Threaded Operation	B-3
Mute Beeper: LCD	5-43
Mute Beeper: terminal	7-39

N

named adapter	8-18
naming controller	7-43
naming logical drive	5-24
navigation keys: terminal emulation	3-1, 3-3
NetMask	3-10
NEW DRV	6-6
node name	8-13
Normal Drive Writes	9-33
Notification	D-1
NPC	3-12
NRAID	1-3
NRAID disk spanning	1-3
Number of Tags	9-14
Reserved for each Host-LUN Connection	
NVRAM	B-2

O

Off-Line Mode	5-12
Initialization	
online initialization	7-10
On-Line Mode	5-12
Initialization	
Operating Modes	E-8
Operating Modes: modem	E-5
Operational Theory	2-7
Optimization for Random or Sequential I/Os	7-4
Optimization mode	2-3, 2-12, 5-1
Optimization Mode: terminal	7-1
Optimization mode thresholds	7-5
Out-of-Band	3-5, 3-8
Out-of-band	10-15
Configuration: redundant config.	

P

Pager	E-10
Parameters cache	5-1, 5-3, 7-2
Parameters controller	7-43
Parity blocks	7-22
Parity Check	5-41, 7-37
Parity check: logical drive	5-25
Parity Check: terminal	7-37
Partition logical drive, deleting	5-22, 7-20
Partitioning a Logical Drive/Logical Volume: LCD	5-15
Partitioning a Logical Drive/Logical Volume: terminal	7-13
Partitioning of Logical Units	10-6
Partitioning the logical volume	1-15
Partitions mapping them to LUNs	2-10
Partitions the number of	2-6
Pass-through SCSI commands	5-29, 7-25
Password changing	7-40
Password disabling	5-44, 7-41
Password setting a new	7-41
Password Validation Timeout: LCD	5-47
Password Validation Timeout: terminal	7-45
Periodic Auto-Detect	9-25, 9-26
Periodic auto-detection of failed drive swap	9-26
Periodic check time	9-25
Periodic Drive Check	9-10
Periodic Drive Check Time	7-21, 9-8, 9-26, 9-27
Periodic drive swap auto check	9-26
Peripheral device	9-17
Peripheral Device Status	9-29, 9-34
Peripheral Device Type	9-16, 9-18
Peripheral Device Type Parameters for Various Operating Systems	9-17
Peripheral Device Type Settings	9-18
Perpetual Clone Failing Drive	9-4
Perpetual Clone SMART	9-7
Physical drives	2-1
PID	6-8

Port name	8-12, 8-13, 8-17, 8-19, 8-23, 10-23	Read/Write Test: terminal	7-51
Predictable Failure Test	9-10	Rebuild	6-6
Preparing Controllers	10-15	Rebuild concurrent in RAID (0+1)	1-11
Redundant config.		rebuild degrade mode	7-23
Primary and Secondary ID	10-24	rebuild logical drive	5-24
Primary and Secondary ID: LCD	10-24, 10-30	rebuild priority	5-20, 9-32
Primary and Secondary IDs	10-6	Rebuild Settings	5-19
Primary controller	10-17, 10-25, 10-29, 10-31	Rebuild Settings: LCD	5-17
Primary controller setting	7-32	Rebuild Settings: terminal	7-17
SCSI ID/drive channel for Primary ID	10-9, 10-12, 10-20, 10-26	rebuild with spare	1-9
Primary ID, setting	5-36	Rebuilding a Logical Drive: LCD	5-24
Primary/Secondary Controller ID: terminal PROCOMM	7-30 C-5	Rebuilding Logical Drive: terminal	7-21
		Redefining Channel Mode: LCD	5-33
		Redefining Channel Mode: terminal	7-29
		Redundant Cache Coherency Channels (RCC)	8-3
		Redundant Configuration Fibre interface	10-3
		Redundant Configuration SCSI interface	10-2
		Redundant controller assigning logical drives to secondary	10-25, 10-31
		Redundant controller automatic config.	10-21, 10-28
		Redundant Controller Configuration	10-8
		Redundant controller explained	10-8
		Redundant controllers - if one fails	10-26
		Redundant controller manual config.	10-29
		Redundant controller manual configuration of	10-22
		Redundant controller starting up	10-23, 10-30
		Redundant Ctlr Failure Detected	10-26
		Redundant Ctlr Function	10-22~23
		Regenerate Parity	B-7
		Regenerating Logical Drive Parity: LCD	5-25
		Regenerating Logical Drive Parity: terminal	7-22
		Re-Init Modem	E-9
		Remote Redundant Controller	10-36
		Remote Terminal Emulation	E-6, E-9
		Replace After Clone	E-1~2
		Replace after Clone	9-3
			9-3

Q

Quick Installation: LCD	4-1
Quick Installation: terminal	6-3

R

RAID	1-1, 7-8
RAID (0+1)	1-11, 1-17
RAID (3+0)	1-17
RAID (5+0)	1-17
RAID 0	1-4
RAID 1	1-4
RAID 3	1-5
RAID 5	1-5
RAID advantages	1-1
RAID Expansion	12-1
RAID Expansion Example	12-12
RAID expansion with logical volume	1-16
RAID Level	5-9, 6-4
RAID Levels	1-2, 2-4, B-1
RAID levels definition of	1-2
RAID-to-host-bus	C-3
RAIDWatch	3-5
RAIDWatch Manager	C-2
RC connecting	10-20, 10-24
RC Standing By	10-24
RCC	8-8
RCC Status	10-36
RCCOM	6-8, 8-14, 10-20, 10-30

Clone Failing Drive Replacement controller	10-12, 10-27, 10-33	SCSI commands pass-through	5-29, 7-25
Replacing a Failed Unit	10-11	SCSI Drive Low-level Format: LCD	5-51
Requirements and Limitations: redundant controller	10-1	SCSI Drive Low-level Format: terminal	7-50
Requirements for Redundant config.	10-15	SCSI Drive Read/Write Test: LCD	5-52
Reserved Space	3-9, 7-50	SCSI drive status	6-6
Reset at Power-Up	9-22	SCSI Drive Status: LCD	4-4
Reset Controller: LCD	5-44	SCSI Drive Utilities: LCD	5-51
Reset Controller: terminal	7-41	SCSI Drive Utilities: terminal	7-49
Restore NVRAM from Disks: LCD	5-46	SCSI Drive's Status: terminal	6-6
Restore NVRAM from Disks: terminal	7-44	SCSI drives, viewing and editing	7-26
Restoring the Default Setting: LCD	5-42	SCSI ID, explained	9-13
Retry count dial-out	E-12	SCSI ID, deleting	7-31
Retry interval for dial-out	E-12	SCSI IO Timeout	9-23
Rolling Firmware Upgrade	10-11, B-7, C-1	SCSI motor spin-up	9-21
RS-232C	3-1	SCSI Parameters	2-12
RS-232C upgrading firmware via	C-4	SCSI target/drive channel, viewing and editing	5-39
		SCSI, deleting	7-31
		SCSI, viewing and editing	5-39
		Secondary controller	10-12, 10-17, 10-25, 10-31
		Secondary Controller RS-232	10-36
		Secondary controller setting SCSI ID/drive channel for	7-32
		Secondary ID	10-9, 10-12, 10-20
		Secondary ID SCSI channel, setting	5-36
		Sector Ranges	9-20
		Select "Controller Peripheral Device Configuration"	9-34
		Serial Port	3-1
		serial port: connection and setup	3-1, 3-8
		S.E.S.	9-25
		Set Peripheral Device Entry	9-31, 10-16, 10-29
		Setting a New Password: terminal	7-41
		Setting a Primary Controller's SCSI ID: terminal	7-32
		Setting a SCSI Channel's ID: LCD	5-34
		Setting a SCSI Channel's Primary ID: LCD	5-36
		Setting a SCSI Channel's	5-36
S.E.S.	5-29		
S.M.A.R.T.	9-1, 9-2, 9-6, 9-7, 9-10, B-6		
Safety range	9-34		
Safety range thresholds	9-35		
SAF-TE	5-29, 9-25		
SAF-TE and S.E.S. Enclosure Monitoring	9-25		
SAF-TE/S.E.S. polling period	B-9		
Sample Configuration: LUN Filtering	8-22		
Saving NVRAM to Disks: LCD	5-45		
Saving NVRAM to Disks: terminal	7-44		
Scan SCSI drive	7-27		
Scanning New Drive: terminal	7-27		
Scanning New SCSI Drive: LCD	5-30		
SCSI channel explained	9-13		
SCSI channel ID, deleting	5-35		
SCSI channel terminator	5-37, 7-33		
SCSI Channel's Status: terminal	6-8		
SCSI channels, viewing and editing	7-29		

Secondary ID: LCD			
Setting a SCSI Channel's Secondary ID: LCD	5-36		
Setting a SCSI Channel's Terminator: LCD	5-37		
Setting a SCSI Channel's Terminator :terminal	7-33		
Setting a Secondary Controller's SCSI ID: terminal	7-32		
Setting a Transfer Speed: terminal	7-33		
Setting a Transfer Width: terminal	7-34		
Setting Transfer Speed: LCD	5-37		
Setting Transfer Width: LCD	5-39		
Shutdown Controller: LCD	5-45		
Shutdown Controller: terminal	7-42		
SID	6-8		
Single drive control	1-3		
Slot number	5-40, 7-27		
Slot Number: LCD	5-40		
Slot Number: terminal	7-35		
SMART	9-1, 9-3, 9-6, 9-7, 9-8, 9-10, 9-11		
SMART attributes	9-6		
SNMP TRAP	3-13		
Source drive	9-3, 9-4, 9-12, 12-8		
Spanning	1-3		
Spare drive	1-14, 2-4, 5-7, 6-7, 9-11		
Spare Drive Assignments: LCD	5-10		
Spare Drives	1-6, 1-11		
Spin-up	9-21		
Spin-Up Parameters	2-12		
Standby	6-6, 7-17, 9-3, 9-5		
Standby ID	10-9		
Standby spare	9-3		
Stripe size	7-2, 7-10, B-1		
Stripe Size for different RAID levels	5-3		
Stripe Size: LCD	5-11		
Stripe Size Preset Values	7-4		
Striping with interspersed parity	1-5		
Striping with mirroring	1-4		
Striping with parity disk	1-5		
Sun Solaris configuration	9-19		
Support Removable media	9-16		
Symptoms controller failure		10-13	
Synchronized cache		B-6	
Synchronized terminal screen		E-2	
System drive mapping		8-1, 10-6	
System Drive Mapping Redundant config		10-4	
System Functions		C-5	
System Functions: LCD		5-43	
System Functions: terminal		7-39	
T			
Tag Command Queue		B-3	
Tag Command Queuing		9-24	
Tag count maximum	5-42, 7-37, 9-24		
Target member drive		9-5	
TCP/IP		3-5, 3-6, E-1	
Telix		C-5	
Terminal		3-1, 3-3	
Terminal emulation terminology		6-2	
Terminator jumpers		5-37	
Terminator SCSI channel	5-37, 7-33		
The AT command		E-4	
The RAID controller		9-13	
Time Zone		7-48	
Timeout default		9-23	
Timeout for dial-out to simulate controller failure		E-12	
Traffic Distribution		10-12	
Transfer clock maximum synchronous	5-40, 7-36		
Transfer protocol		C-4	
Transfer Rate		6-2	
Transfer Rate Indicator		6-1	
Transfer speed setting	5-37, 7-33		
Transfer width maximum	5-41, 7-36		
Transfer width setting	5-39, 7-34		
Trigger Thresholds		9-35	
Tunable Parameters		2-11	
U			
Unfinished writes		10-18	
Unique ID		6-4	
Upgrading firmware		C-1	
Upgrading using RAIDWatch		C-2	
URL		3-6, 3-11	

Used drive	9-3	Voltage and Temperature Parameters	9-34
USED DRV	6-6	Volume capacity	7-14
User Configurable Geometry range	B-3	VT-100 connection and setup	3-1, 3-8
User-Assigned ID	8-9	VT-100 Mode	6-1

V

Validation timeout	7-40
Variable Stripe Size	B-3
Verification on Writes	9-33, B-7
View and Edit Event Logs: LCD	4-7
View and Edit Fibre Drive	8-9
View and Edit Host-Side Parameters: Fibre	8-10
View Channel WWN	8-8
View clone progress	9-4
View Connected Drives	5-7
View Device Port Name List	8-9
View Drive Information	8-10
View Drive Information: terminal	7-49
Viewing and Deleting LUN Mappings: LCD	5-29
Viewing and Editing Host LUNs: LCD	5-29
Viewing and Editing Host LUNs: terminal	7-25
Viewing and Editing Logical Drive and Drive Members: terminal	7-19
Viewing and Editing Logical Drives: LCD	5-20
Viewing and Editing SCSI Channels: LCD	5-33
Viewing and Editing SCSI Channels: terminal	7-29
Viewing and Editing SCSI Drives: LCD	5-30
Viewing and Editing SCSI Drives: terminal	7-26
Viewing and editing SCSI ID/host channel	7-30
Viewing and Editing SCSI IDs: terminal	7-30
Viewing and Editing SCSI Target: LCD	5-39
Viewing and Editing SCSI Target: terminal	7-35
Viewing and editing SCSI target/drive channel	7-35
Viewing and redefining a channel mode	5-33
Viewing or Deleting LUN Mappings: terminal	7-25
Viewing the Connected Drives: terminal	7-5

W

Warning	D-1
Workflow	10-4
Write Policy	5-13, 5-28, 6-1, 7-24, B-1
Write Policy: array	7-9
Write Policy: LCD	5-11
Write-Back	5-5
Write-Back caching	5-28, 10-37
Write-back mode	10-19
Write-Back/Write-Through Cache	7-5
Write-Policy	9-29
Write-Through	5-5
WWN Name List	8-18
WWN node name	7-46, 10-22~23
WWN table	B-5
WWPN	8-23

Z

ZMODEM	C-4~6
--------	-------