





configuration space only. Extended configuration space is accessible with memory read and write accesses through a special 4KB memory mapped image. Read only access to configuration space

